Default simulator	Ngspice	<b>‡</b>
Ngspice executable location		
/usr/local/bin/ngspice		Select
Xyce executable location		
'Xyce-Release-6.2.0-OPENSOURCE/bin/runxyce		Select
Xyce Parallel executable location (openMPI installed required)		
ase-6.2.0-OPENMPI-OPENSOURCE/bin/xmpirun Select		
Number of processors in a system: 4		
SpiceOpus executable location		
/usr/local/bin/spiceopus		Select
Directory to store netlist and simulator output		
/home/mike/spice4qucs		Select
Apply changes Cancel		