

Tabell 1 Kurva för omgivningstemperatur för inställning av låg temperatur för uppvärmning

T4	≤ -20	- 19	- 18	- 17	- 16	- 15	- 14	- 13	- 12	- 11	- 10	- 9	- 8	- 7	- 6	- 5	- 4	- 3	- 2	- 1	0
1-T1S	38	38	38	38	37	37	37	37	37	37	36	36	36	36	36	36	36	35	35	35	35
2- T1S	35	35	35	35	34	34	34	34	34	34	34	34	33	33	33	33	33	33	33	33	32
3- T1S	33	33	33	33	33	33	33	32	32	32	32	32	32	32	32	32	32	32	32	32	31
4- T1S	35	35	35	34	34	34	34	34	34	33	33	33	33	33	33	32	32	32	32	32	31
5- T1S	33	33	33	33	32	32	32	32	32	32	32	31	31	31	31	31	31	31	31	31	30
6- T1S	31	31	31	31	30	30	30	30	30	30	30	29	29	29	29	29	29	29	29	29	28
7- T1S	29	29	29	29	29	29	29	28	28	28	28	28	28	28	28	28	28	28	28	28	27
8- T1S	29	29	29	29	28	28	28	28	28	28	28	27	27	27	27	27	27	27	27	27	26
T4	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	≥ 20	
1-T1S	35	35	35	35	34	34	34	34	33	33	33	33	33	33	33	32	32	32	32	32	32
2- T1S	32	32	32	32	32	32	32	31	31	31	31	31	31	31	31	30	30	30	30	30	30
3- T1S	31	31	31	31	31	31	31	31	31	31	31	31	31	30	30	30	30	30	30	30	30
4- T1S	31	31	31	31	31	30	30	30	30	30	30	29	29	29	29	29	28	28	28	28	28
5- T1S	30	30	30	30	30	30	30	29	29	29	29	29	29	29	28	28	28	28	28	28	28
6- T1S	28	28	28	28	28	28	28	27	27	27	27	27	27	27	27	26	26	26	26	26	26
7- T1S	27	27	27	27	27	27	27	27	27	27	27	27	27	26	26	26	26	26	26	26	26
8- T1S	26	26	26	26	26	26	26	25	25	25	25	25	25	25	24	24	24	24	24	24	24

Tabell 2 Kurva för omgivningstemperatur för inställning av hög temperatur för uppvärmning

T4	≤ -20	- 19	- 18	- 17	- 16	- 15	- 14	- 13	- 12	- 11	- 10	- 9	- 8	- 7	- 6	- 5	- 4	- 3	- 2	- 1	0
1-T1S	55	55	55	55	54	54	54	54	54	54	54	54	53	53	53	53	53	53	53	53	52
2- T1S	55	55	54	54	54	54	53	53	53	53	52	52	52	52	52	51	51	51	50	50	50
3- T1S	55	54	54	53	53	53	52	52	52	51	51	50	50	50	49	49	49	48	48	48	47
4- T1S	50	50	50	50	49	49	49	49	49	49	49	49	48	48	48	48	48	48	48	48	47
5- T1S	50	50	49	49	49	49	48	48	48	48	47	47	47	47	46	46	46	46	45	45	45
6- T1S	45	45	45	45	44	44	44	44	44	44	44	44	43	43	43	43	43	43	43	43	42
7- T1S	45	45	44	44	44	44	43	43	43	43	42	42	42	42	41	41	41	41	40	40	40
8- T1S	40	40	40	40	39	39	39	39	39	39	39	39	38	38	38	38	38	38	38	38	37
T4	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	≥ 20	
1-T1S	52	52	52	52	52	52	52	51	51	51	51	51	51	51	50	50	50	50	50	50	50
2- T1S	50	49	49	49	49	48	48	48	47	47	47	47	46	46	46	46	45	45	45	45	45
3- T1S	47	46	46	46	45	45	45	44	44	44	43	43	43	42	42	41	41	41	40	40	40
4- T1S	47	47	47	47	47	47	47	46	46	46	46	46	46	46	45	45	45	45	45	45	45
5- T1S	45	44	44	44	44	43	43	43	42	42	42	42	41	41	41	41	40	40	40	40	40
6- T1S	42	42	42	42	42	42	41	41	41	41	41	41	41	40	40	40	40	40	40	40	40
7- T1S	40	39	39	39	39	38	38	38	37	37	37	37	36	36	36	35	35	35	35	35	35
8- T1S	37	37	37	37	37	37	37	36	36	36	36	36	36	35	35	35	35	35	35	35	35