


Press  and you can see the interface below.



 **NOTE**

Boost mode is only available for specific models.