



Current Status	Indicates the status of Holiday home mode.
From*	The day on which Holiday home mode starts (00:00 on that day)
Until*	The day on which Holiday home mode ends (24:00 on that day)
Zone 1 holiday timer*	Zone 1 holiday timer.
Zone 2 holiday timer*	Zone 2 holiday timer.
DHW holiday timer*	DHW holiday timer.

* Invisible if Holiday home mode is inactive.