Energy metering	You can check the produced energy, consumed power and efficiency of the unit for every type. Three types in all: -Heating energy data* -Cooling energy data* -DHW energy data* Two functions: -Energy data: you can check the hourly, daily, weekly, monthly, or yearly data or total data. -Historical data: you can check the historical data. **NOTE** • COP/EER is calculated under normal operating conditions.
Device info.	The SN code and software version of the wired controller, outdoor unit or indoor unit (if applicable). Press $\wedge$ to $\vee$ switch information page (SN code and software) You can check both the master units and slave units. Press $<$ or $>$ to switch the unit (master units and slave units).
Service call	The phone number of your installer or dealer.

* Visible with --- displayed, if the function is disabled accordingly.