

Heating Mode*	Indicates the status of heating mode.
Heating Temp.*	The target temperature of the unit in heating mode.
DHW Mode**	Indicates the status of DHW heating mode.
DHW Temp.**	The target temperature of the unit in DHW heating mode.
Disinfect***	Indicates the status of disinfect function.

\* Invisible if Heating mode is inactive.

\*\* Invisible if DHW mode is inactive.

\*\*\* Invisible if DHW mode or disinfection is inactive.

### NOTE

You might see less items than what is illustrated above. The number of visible items depends on your actual application.

Quit Holiday away mode in advance:

When Holiday away mode is active, press any button on the wired controller. Then, a confirmation page appears.

For more information, see FAQ.