

5 OTHER FUNCTIONS AND SETTINGS	25
• 5.1 Schedule.....	25
• 5.2 Weather temp. settings	36
• 5.3 DHW settings.....	42
• 5.4 Settings.....	45
• 5.5 Unit Status.....	52
• 5.6 Error Info.....	56
• 5.7 FAQ.....	57
6 INSTALLATION CONFIGURATION.....	59
7 OPERATING PARAMETERS.....	65

