

## NOTE

You might see less items than what is illustrated above. The number of visible items depends on your actual application.

This function is based on the current time displayed on the wired controller. Make sure the time is correct.

### Zone 1 daily timer

For daily schedule for Zone 1, 4 parameters can be set. Up to 6 commands can be set..

Zone 1 daily timer				
No.	Time	Mode	Temp.	
01	01:00		26 °C	<input checked="" type="checkbox"/>
02	20:00		26 °C	<input checked="" type="checkbox"/>
03	00:30	OFF	0 °C	<input checked="" type="checkbox"/>
04	00:30		26 °C	<input checked="" type="checkbox"/>

## NOTE

Daily schedule: The commands repeat every day.