



Troubleshooting of networking failures

When connecting the product to a network, please keep the product as close to your phone as possible.

At present, the product only supports 2.4 GHz band routers.

Special characters, such as punctuation and space, are not recommended as a part of the WLAN name.

The number of devices connecting to the same router should not exceed 10. Otherwise, the devices may be disconnected due to unstable signals.

If the password of the router or WLAN is changed, clear all settings and reset the appliance.

The contents of APP might change in version updates and actual operation shall prevail.

WIFI information

WIFI transmission frequency range: 2.400~2.4835 GHz

EIRP ≤ 20 dBm