


- If the set start time is later than the set end time, the unit will operate in Silent or Boost mode throughout a day. The Start time and End time cannot be set to the same value. Otherwise, the most recent setting is invalid, and a notice window appears.

Backup Heater

- Invisible when IBH/AHS function is disabled.

The status indicator will turn OFF automatically after the function is off.



Display Setting

