

• 10.2 Initial start-up at low outdoor ambient temperature	54
• 10.3 Pre-operation checks	55
• 10.4 The circulation pump	55
• 10.5 Field settings	57
11 TEST RUN AND FINAL CHECKS	68
• 11.1 Final checks	68
• 11.2 Test run operation (manually).....	68
12 MAINTENANCE AND SERVICE.....	68
13 TROUBLE SHOOTING.....	69
• 13.1 General guidelines	69
• 13.2 General symptoms.....	69
• 13.3 Operation parameter	71
• 13.4 Error codes.....	73
14 TECHNICAL SPECIFICATIONS.....	80
• 14.1 General	80
• 14.2 Electrical specifications	80
15 CONTROLLER WITH COLOUR DISPLAY	81
• 15.1 Installation of wired controller	81
• 15.2 Field settings	85
• 15.3 Operation settings	89
• 15.4 Commissioning.....	92
• 15.5 Hand-over to the user	94
16 INFORMATION SERVICING.....	98