



Maker Vault — Quick-start guide

Keep every file, setting and result for your 3D printing, laser and cutting projects in one place.

Maker Vault is a free organizer that runs in your web browser: nothing to install, no account. It keeps your files on your own computer, reads your print and laser settings out of them, and lets you log results and compare runs so you can repeat what worked. This guide takes about five minutes.

1 Open it

Save **maker-vault.html** somewhere permanent (such as Documents) and double-click it. It works best in Chrome or Edge (Firefox and Safari should work too but are less tested). Bookmark it for next time.

Two things to know from the start. Your vault is kept inside your browser, so **(1) make a backup now and then** (step 7), and **(2) don't move or rename the file** once you've started; some browsers tie the vault to where the file is saved.

2 Add your files


- **Drag and drop** files anywhere on the page, or click **Add files**.
- Or click **Import folder...** to bring in a whole folder. Your originals are copied in and never touched.
- Adding the same file twice is safe; duplicates are skipped.

Files that belong together become one **project**, based on the start of the file name:

You add	You get
Cable clip.stl + Cable clip_0.2mm_PLA.gcode	Project "Cable clip"
Coaster.svg + Coaster.lbrn2	Project "Coaster"

Read for you: settings from G-code and 3MF (most reliable with PrusaSlicer; OrcaSlicer, Bambu Studio and Cura are newer and less tested); LightBurn layer settings (new, so check them); SVG size and colours; STL size.

Cricut users: Design Space can't be read directly, so add the SVG files you cut from (downloaded, bought or made in other software).



Your projects, with machine, key settings and tags. The green line shows the space compression has saved.

3 Your project page

Click a project. **Files**, **runs** and **notes** are on the left; the **recipe** and details on the right.

- **Recipe:** the settings read from your files. Click any value to change it, or **+ Add setting** for your own. It saves automatically.
- **Machine:** a project with only an SVG shows as "Unsorted" until you pick Laser or Cutter from the drop-down.
- **Files:** **Download** gives back the exact original. **Remove** deletes it from the vault. Add tags, a source link and a license under **Origin**.

4 Log a run, then compare

1. After a print or burn, fill in **Runs**: machine, material, how it went (Worked / Partial / Failed), grams used, and a note. Click **Log run**.
2. The recipe is saved *with* that run. Change a setting (say, a lower nozzle temperature) and log the next run.
3. Tick two runs and click **Compare selected**. Only the settings that **differ** are shown, so you see exactly what fixed (or broke) it.

RUNS (2) Compare selected

MINI Material (optional) Worked grams used

What happened? What would you change? Log run

☒ **Worked** Sep 29, 2026 MINI Galaxy PLA 17 g Settings x
Clean. 205°C fixed it.

☒ **Failed** Sep 29, 2026 MINI Galaxy PLA 18 g Settings x
Stringing on the overhang, nozzle too hot

SETTING	OLDER	NEWER
nozzle_temp	240	205

13 settings unchanged.

NOTES

What worked, what to change next time, where the design came from...

Above right: a failed run compared with a good one. The only change was the nozzle temperature, 240 → 205.

5 Materials and your own fields

Materials (top menu): add spools, sheets and vinyl with what's left. Log a run with the material and grams used and the amount comes off automatically.

Materials

Spools, sheets and vinyl. Log grams on a run and the remaining amount updates itself.

Name (e.g. Blue PETG)

Type (PLA, birch ply...)

Brand

Color

Remaining (0) Cost / kg Add

Settings → **Custom fields**: track anything: bed surface, wood species, vinyl brand, customer. They appear under **Details** on matching projects.

Settings

Shape the vault around how you work.

CUSTOM FIELDS

Add anything you want to track — bed surface, wood species, vinyl brand, customer, finish. Fields appear on every matching project.

Field name (e.g. Bed surface) text All machines Options, comma separated (for select) Add field

FIELD	TYPE	APPLIES TO
Bed surface	select (Textured PEI, Smooth PEI, Glass)	All x
Customer	text	All x

BACKUP STORAGE

6 Find things fast

The search box looks through project names, notes, tags, file names *and settings* (try “PETG” or “0.16”). Use the machine buttons and tag menu to narrow the list.

7 Back up your vault

Your vault lives in your browser's storage on this computer. Clearing the browser's site data, or using a private window, erases it.

1. **Settings** → **Download backup**. One zip holds everything: files, settings, run logs, materials.
2. Keep it somewhere safe (cloud or external drive).
3. To restore, or move to another computer or browser, open Maker Vault there and click **Restore from backup...** (it replaces what's in that vault).

BACKUP & STORAGE

This page keeps your vault inside your web browser, on this computer. Nothing is uploaded anywhere. Clearing your browser's site data, or using a private window, will erase it — so download a backup now and then.

Using 3.9 MB of about 907.8 MB available. Your browser may delete this data if the disk runs low — keep a backup.

Stored compressed: your vault is 13.2 MB smaller than the original files (68% saved).

Files are stored compressed to save space (formats that are already compressed, like 3MF and photos, are kept as they are). Downloads and "Export package" always give you the original files, byte for byte. A backup keeps the compressed form so it stays small — it is meant to be restored here; use "Export package" when you want ordinary files.

Download backup

Restore from backup...

Settings → Backup & storage.

Good habit: back up after every big import, and monthly after that.

8 Share or export a project

Open a project and click **Export package**: an ordinary zip with your original files, a `recipe.json` (settings and run history) and a readable `README.md`. Use it to share, archive, or open a project without Maker Vault.

9 Good to know

- **Files are stored compressed** to save space. In our tests G-code, STL and SVG were roughly 65–90% smaller; 3MF files and photos are already compressed and stay about the same. Downloads and **Export package** always return your originals byte for byte. A **backup** keeps the compressed form so it stays small and is meant to be restored into Maker Vault.
- Everything stays on your computer. Nothing is uploaded, and it works with the internet off.
- It's an organizer, not a slicer, and it has no 3D preview. If a file's settings aren't recognised, the file is still stored and you can type them in.

© 2026 Bert's CNC Woodworking. Maker Vault is free and open source (MIT license).