



Enable pin where to connect
name it sensor bias or sth the sheet

Sheet: /		
File: AnalogFrontEnd.kicad_sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. 10.0.0		Id: 1/6

△SIPM_TEMP
△VCC_SIPM_TEMP_COMP

△VCC_SIPM_RAW
△VCC_SIPM_EN

△VCC_SIPM_STABILIZED



Sheet: /BiasSupply/
File: BiasSupply.kicad_sch

Title:

Size: A4

Date:

KiCad E.D.A. 10.0.0

Rev:
Id: 2/6

	1	2	3	4	5	6
A						
B						
C						
D						
	1	2	3	4	5	6


⏏FAULT_SIPM_LIGHTED


⏏VCC_SIPM_STABILIZED

⏏VCC_SIPM_PROT

Sheet: /SensorProtection/ File: SensorProtection.kicad_sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. 10.0.0		Id: 3/6







Sheet: /ExternalConnector/ File: ExternalConnector.kicad_sch	
Title:	
Size: A4	Date:
KiCad E.D.A. 10.0.0	Rev: Id: 6/6