Calculos times 0: Lo que se busca es 500mz

Prescaler = 0.500s * 500 KHz

Prescaler 2 976.56

Prescaler = 1024

Valor de TCNTO:

10101 00 1011 10

Calculos de times 23

TCNTL = 256 - 500 kHz = 0.005 s = 254 1024

TCNT0 = 256 - 500 KHz * 0.55 = 12

1024