Kramer Boxes

Power


-The boxes are powered on if the green lights are glowing green. If they are not, please look in the lectern for the remotes to turn them on. The VP-435 should display 1080I for best results.

Inputs

- -There are two inputs that can be used, VGA (desktop computer input 1) and HDMI (Input 2)
- Note: The VGA has an audio cord that has to be plugged in with it for sound. Sound volume is controlled at each device through either the Panasonic of Sharp remotes.

Switching Between Inputs

- The front of the top Kramer box should look like the image below. To toggle between the two inputs, press the **Input Selector** button in the middle of the box. It is identified by the number 7 in the picture below. The number 8 indicates the two inputs you are switching through. Whichever input you are currently on will have the green glowing light.



- The Outputs on the right side of the top Kramer box are the four displays in the room, two TVs and two projectors. The glowing Output lights only glow when the displays are on. If a display isn't turned on, its corresponding light will not glow. In the picture below both boxes are on and the four outputs are displaying because the lights are glowing.

Note: The picture below shows the Kramer box is in Input 2.

Please note, it can take up to 15 seconds to switch between inputs. Please be patience.

