

1. Connect a USB webcam to your computer, install any required drivers, and verify that the webcam works by opening the default camera app and capturing a photo.

Here is a quick, step-by-step guide to getting your USB webcam up and running.

Step- 1: Connect the webcam

- Unpack your webcam and position it on your monitor or desk.
- Plug the webcam's USB cable into an available USB port directly on your computer.

Step-2: Install Drivers

- For Windows 10/11 and macOS: Modern USB webcams are UVC (USB Video Class) compliant. This means they are "plug-and-play." Your operating system will automatically recognize the device and install the necessary generic drivers within a few seconds. You should see a notification saying your device is ready to use.
- For Older Systems or Specialty Cameras: If your webcam requires specific drivers, it will usually come with an instruction slip directing you to the manufacturer's website (e.g., Logitech, Razer) to download their software suite.

Step-3: Verify and Capture a Photo

To ensure everything is working perfectly, open your system's built-in camera application:

1. Press the Windows Key, type Camera and press enter.
 2. If the app opens and you see yourself, the webcam is working.
 3. Click the camera icon on the right side of the screen to take a test photo.
2. Set up a local printer (USB or network), install the correct driver, and print a test page to confirm successful installation.

To set up a local printer (USB or network), install the correct driver, and print a test page, follow these steps based on your operating system.

Windows 10 / Windows 11

- **Connect the Printer**

USB Printer

- Connect the printer to your computer using the USB cable.
- Turn on the printer.
- Wait for Windows to detect it automatically.

Network Printer (Wi-Fi/Ethernet)

- Ensure the printer is connected to the same network as your computer.
- Note the printer's IP address if available.
- **Install the Driver**

Automatic Installation

- Open Settings/ Bluetooth & devices/Printers & scanners.
- Click Add device.
- Select your printer when it appears and click Add device.

Manual Driver Installation

If windows does not find the correct driver:

- Visit the printer manufacturer's website.
- Download the driver for your printer model and Windows version.
- Run the installer and follow the prompts.
- **Verify the Printer**
 - Go to Settings/Bluetooth & devices/ Printers & scanners.
 - Select the printer.
 - Click Printer properties.
- **Print a Test Page**
 - In Printer properties, click Print Test Page.
 - Confirm the page prints successfully.

MacOS

- **Connect the Printer**
- **USB Printer**
- Connect the USB cable.
- Turn on the printer.
- **Network Printer**
- Connect the printer to your network.
- Ensure your Mac is on the same network.
- **Install the Driver**
- Open System Settings/Printers & Scanners.
- Click Add Printer, Scanner, or Fax.
- Select the printer from the list.
- MacOS will typically download the required driver automatically.
- If necessary, download the driver from the manufacturer's website.
- **Print a Test Page**
- Open any document or text file.
- Select File/Print.
- Choose the newly installed printer.
- Print the document as a test page.

Confirm Successful Installation

The installation is successful if:

- The printer appears in your system's printer list.
- No error or offline status is shown.
- A test page prints correctly with readable text and graphics.

3. Simulate a connectivity issue by unplugging the printer's USB cable, and then use Windows Device Manager to identify and resolve the 'printer not detected' problem.

To simulate and resolve a "printer not detected" issue using Windows Device Manager, follow these steps:

A. Simulate the connectivity Issue

- Ensure the printer is powered on and working normally.
- Disconnect (unplug) the printer's USB cable from the computer.
- Wait a few seconds.

B. Verify the Problem in Device Manager

- Press Windows + X and select Device Manager.
- Expand Printers, Print queues, or Universal Serial Bus controllers.
- Look for: The printer missing from the list or a device with a yellow warning icon indicating a hardware problem.

C. Reconnect the Printer

- Plug the USB cable back into the computer.
- Wait a few moments for Windows to attempt detection.

d. Use "Scan for Hardware Changes"

- In Device Manager, click the Action menu.
- Select Scan for hardware changes.
- Observe whether the printer reappears under Printers or Print queues.

e. Confirm Resolution

- Verify that the printer is listed without any warning icons.
- Open Settings > Bluetooth & devices > Printers & scanners.
- Confirm the printer appears and shows a status such as Ready.
- Print a test page if available.

4. A user reports that their webcam video is not displaying in Zoom, but it works in the default camera app. Troubleshoot and resolves the issue so the webcam works in both applications.

To troubleshoot a webcam that works in the system Camera app but not in Zoom, follow these steps:

1. Verify Zoom is Using the Correct Camera

- Open Zoom.
- Click Settings/Video.
- Under Camera. Select the correct webcam from the dropdown list.
- Confirm that the video preview appears.

2. Check Whether Another Application is Using the Webcam

Only one application may be able to access the camera at a time on some systems.

- Close applications that may be using the webcam:
- Camera app
- Microsoft Teams
- Skype
- Reopen Zoom and test the camera again.

3. Verify Camera Permission for Zoom

- Open Settings/Privacy&Security/Camera.
- Ensure: Camera access is enabled and Let desktop apps access your camera is enabled.
- Confirm Zoom appears in the list of allowed applications.

4. Restart Zoom and the Computer

- Completely exit Zoom.
- Reopen Zoom.
- If the issue persists, restart the computer.