


1. Create a table listing 3 types of printers, 2 types of scanners, and 2 types of webcams, and for each, write one real-life use case.

Device Category	Type	Real-life Use Case
Printer	Inkjet Printer	Printing colourful photos and school projects at home.
Printer	Laser Printer	Printing large volumes of documents quickly in an office.
Printer	Dot Matrix Printer	Printing multi-part invoices and receipts in business.
Scanner	Flatbed Scanner	Scanning photographs and important documents into a computer.
Scanner	Handheld Scanner	Scanning barcodes and inventory in warehouses or stores.
Webcam	USB Webcam	Attending online meetings and video conferences.
Webcam	Network(IP) Webcam	Monitoring a home or office remotely for security purposes.

2. Draw a labeled diagram showing how a typical home printer connects to a laptop or PC, including the connection interface used (USB, Wi-Fi, or Bluetooth).

How a Home Printer Connects to a Laptop or PC

A home printer can connect using USB, Wi-Fi, or Bluetooth.



3. List three different connection interfaces (such as USB, Wi-Fi, Bluetooth) used by peripherals like printers, scanners, and webcams, and for each, name one advantage and one disadvantage.

Interface	Advantage	Disadvantage
USB(Universal Serial Bus)	Fast and reliable data transfer, easy plug and play setup.	Requires a physical cable, limiting mobility and distance.
Wi-Fi	Wireless connection allows devices to be used from multiple computers without cables.	Can be affected by network issues, interference or slower speed than a wired connection.
Bluetooth	Convenient wireless connection with low power consumption and simple pairing for nearby devices.	Shorter range and generally slower data transfer speeds compared to Wi-Fi or USB.

4. Pick any one device you use at home or college (printer, scanner, or webcam). Write step-by-step instructions for how you would connect it to your computer, including what cable or wireless method you would use and any setup steps required.

- **Printer (USB Connection)**

Steps to Connect a Printer to a Computer

1. Unpack the Printer

- Remove the printer from its box.
- Take off all protective tapes and packaging materials.

2. Place the Printer

- Put the printer on a stable surface near your computer and a power outlet.

3. Connect the Power Cable

- Plug the printer's power cable into wall socket.
- Press the power button to turn on the printer.

4. Connect the USB Cable

- Take a USB printer cable.
- Connect one end to the printer's USB port.

- Connect the other end to a USB port on your computer.

5. Install Printer Drivers

- Your computer may automatically detect the printer and install the necessary drivers.
- If not, insert the driver CD that came with the printer or download the latest driver from the printer manufacturer's website.

6. Add the Printer

- Open Settings/ Bluetooth & Devices/ Printers & Scanners.

7. Load Paper and Ink

- Insert paper into the paper tray.
- Insert Ink cartridges or toner if they are not already installed.