
Greenhouse user manual

In order for this application to work it needs to have a running server. To run server run command - node server.js

Then user can open the web application by going to 192.168.7.2:8888 on his browser



- User can see every 5 seconds updated temperature (1)
- User can see every 5 seconds updated humidity(2)
- User can see every 5 seconds updated light level (3)

- User can see led light level (4)
- User can control the led light level by inputting percentage 0 100 and pressing set value (5)
- User can see the window status open or closed(6)
- User can control the window position by pressing the buttons open or close (7)
- User can see the heater status on or off(8)
- User can control the heater by pressing the buttons on or off(7)