


58 Series

3D view



HOW TO ACTIVATE 3D?

To activate the interactive 3D view in Acrobat Reader, you need to select, at the top of the page, **Options** and then **Trust this document**

Zoom

Приближает или отдаляет объекты при вертикальном движении курсора. Инструмент 'рука' также позволяет масштабировать объекты. Зажмите для этого при движении клавишу Shift.

Pan

Перемещает модель только горизонтально или вертикально. Инструмент 'рука' также позволит Вам панорамировать модель. Зажмите для этого при движении клавишу Ctrl.

Вращать

Вращает 3D-объекты относительно экрана. Движение объектов зависит от исходного вида, точки начала движения и направления вращения.

Augmented Reality (AR) - Digital meets real


Augmented Reality, often shortened to AR, is a technology that blends digital information into the real world.
For more information, please click here or directly try yourself by scanning the QR code with your phone.

SCAN ME




58 Series

2D derivation



ISO view



Bill-Of-Materials

N°	Наименование	Количество
1.1		45



58 Series

Technical drawings



58 Series

Technical data


CODE (Code)	583490120050SPB
VAR0 (Description)	Type 58. 34 is a relay interface module, 4 CO 7 A, with screw terminals, 27 mm wide. For interfacing with PLC systems. Available Atex compliant version (HazLoc Class I Div. 2 Groups A, B, C, D – T5 compliant): 58. 34-x0xx, 4 CO 6 A, with scren terminals or push-in terminals. Features include: AC or DC coil, Coil Indication and EMC suppression module, Identification label, UL Listing (relay/socket/jumper link), 35 mm rail (EN 60715) mounting, Cadmium-free contacts



58 Series

CAD plugins

With our CAD integrations, you can use 3Dfindit directly in your CAD system and make your work easier with additional comfort functions, such as replacing a part and many more.



To the plugins