



























Insert the sash into the frame and align the sash as shown in Window Fitting Instructions.

See pages 6 & 7 (pictures 17 - 24).



