
Example 48-1

This example is from problem 4.8 in Basic Electric Circuit Analysis. Testing E and F type sources and inductor.



* C:\Users\Jim\Documents\Python SciPy\NETWORK\spice test circuits\example48-1.asc

R2 1 2 1

R3 4 3 1

R4 2 5 2

V1 1 0 2

I1 4 0 9

V2 0 5 0

E130142

F1 2 3 V2 2

L1 1 4 2

.op

.backanno

.end

--- Operating Point ---

V(1): 2 voltage

V(2): 4 voltage

V(4): 1.98903 voltage V(3): 0.0219342 voltage

V(5): 0 voltage

I(F1): -4 device_current

I(L1): 10.9671 device_current

I(I1): 9 device_current

I(R4): 2 device_current

I(R3): 1.9671 device_current

I(R2): -2 device_current

I(E1): -2.0329 device_current

I(V2): -2 device_current

I(V1): -8.9671 device_current