




H80.41/0057

H80.42/0051

L60.11/0010
L60.11/0030
L60.21/0010
L60.21/0030L60.11/0017
L60.11/0112
L60.21/0017
L60.21/0112

L20.48/2893

L20.48/2907

L20.48/2914

H99.02/1836

L20.48/1251

H30.15/0044
H30.15/0457
H30.15/0647
H50.58/0077
H99.02/1782
H99.02/1900
L20.48/2178
L60.11/0139
L60.21/0034H30.15/0086
H30.15/0521
H30.15/0650
H50.58/0087
H99.02/1792
H99.02/1907
L60.11/0026
L60.11/0158
L60.21/0139

12	40/63	MB075850 (Sol) STR1 Area1 Vacuum Off	MB075851 (Sol) STR1 Area2 Vacuum Off	MB075852 (Sol) STR1 Area3 Vacuum Off	MB075853 (Sol) STR1 Area4 Vacuum Off		MB076898 [Response] STR1 Vacuum All Off	[MB076898] L20.48/0510	L20.48/2182	
Stick Transfer 1 Vacuum Signal										
13	51/68	MB075888 [Request] STR1 Vacuum All On	DB000013 ---		DB000400 Area1		MB075840 (Sol) STR1 Vacuum 1 On	[MB075840] .../0053 L10.58/0006i L10.68/0240i [MB075841] .../0055	.../0091 L10.58/0011w L20.48/0259	H50.48/0637 L10.68/0156i L20.48/1931
					DB000401 Area2		MB075841 (Sol) STR1 Vacuum 2 On	L20.48/0267 [MB075842] .../0057 L20.48/0275 [MB075843] .../0059	.../0092 L20.48/1939	H50.48/0648
					DB000402 Area3		MB075842 (Sol) STR1 Vacuum 3 On	L20.48/0283 [MB075898] .../0080	.../0093 L20.48/1947	H50.48/0659
					DB000403 Area4		MB075843 (Sol) STR1 Vacuum 4 On	L20.48/0283 [MB075898] .../0080	.../0094 L20.48/1955	H50.48/0670
							MB075898 [Request] STR1 Vacuum All Off	.../0096w	.../0101w	L20.48/0511
							MB07589C [Request] STR1 Vacuum Break All-	.../0096w	.../0100w	.../0102
14	63/69	MB075898 [Request] STR1 Vacuum All Off	DB000014 ---				MB075850 (Sol) STR1 Area1 Vacuum Off	[MB075850] .../0063 L10.58/0009i L20.48/0263 [MB075851] .../0064	H50.48/0813 L10.68/0158i L20.48/1935	L10.58/0008w L10.68/0238i
							MB075851 (Sol) STR1 Area2 Vacuum Off	L20.48/1943 [MB075852] .../0065 L20.48/1951 [MB075853] .../0066	H50.48/0824	L20.48/0271
							MB075852 (Sol) STR1 Area3 Vacuum Off	L20.48/1959 [MB075888] .../0068	H50.48/0835	L20.48/0279
							MB075853 (Sol) STR1 Area4 Vacuum Off	H50.48/0846	L20.48/0287	
							MB075888 [Request] STR1 Vacuum All On	H30.15/0456	L20.48/0507	
Stick Transfer 1 Blow Status										
15	70/67	MB076860 (Sensor) STR1 Vacuum Break On S-					MB07688C [Response] STR1 Vacuum Break All-			
16	72/69	MB076870 (Sensor) STR1 Vacuum Break Off S-					MB07689C [Response] STR1 Vacuum Break All-			
Stick Transfer 1 Vacuum Break Signal										
17	74/61	MB075840 (Sol) STR1 Vacuum 1 On	DB000020 ---				MB07589C [Request] STR1 Vacuum Break All-	[MB07589C] .../0079w	.../0100w	.../0102
		MB075841 (Sol) STR1 Vacuum 2 On								
		MB075842 (Sol) STR1 Vacuum 3 On								
		MB075843 (Sol) STR1 Vacuum 4 On								

18	80/97	MB07588C	DB000011							MB075860 (S)	[MB075860] H50.48/0989 L10.58/0030iw L20.48/0515 [MB07589C] .../0079w [MB075898] .../0078w	L10.18/0580i L10.68/0320i L20.48/2187 .../0096w .../0080	L10.58/0025i L10.68/0404i .../0102 L20.48/0511
		[Request] S TR1 Vacuum Break All-								[Request] S TR1 Vacuum Break All- MB075898 (S)			
										[Request] S TR1 Vacuum Break All- MB07589C (R)			
										[Request] S TR1 Vacuum Break All- MB07589C (S)			
19	85/102	MB07589C	DB000012							MB075870 (S)	[MB075870] H50.48/1149 L10.68/0322i L20.48/2191 [MB07588C] .../0097	L10.58/0027iw L10.68/0402i	L10.58/0028i L20.48/0519
		[Request] S TR1 Vacuum Break All-								(Sol) STR1 Vacuum Bre ak Off MB07588C (R)			
										[Request] S TR1 Vacuum Break All- MB07588C (S)			
		Stick Transfer 1 Align Camera Blow Signal											
20	89/103	MB000004	MB000800							MB075861 (S)	[MB075861] H50.48/0999	L20.48/0523	L20.48/2195
		Automatic Dr iving	MCTAG_Idli ng							(Sol) STR1 Align Camer a Blow On			
21	92/109	MB000001	DB000010							MB075871 (S)	[MB075871] H50.48/1159	L20.48/0527	L20.48/2199
		Stopping								(Sol) STR1 Align Camer a Blow Off			
22	95/112	IF	"Vision Seperate(0:Unuse 1:Use)" == 1 CW00055 == 1;										
23	96/113	NL 2	!=	[WLFQD]SrcA MQ22816 ---	[WLFQD]SrcB MQ97320 ---		COPYW	[W]Src MW22816 ---	[W]Dest MW97320 ---	[W]Width 00008			
			!=	[WLFQD]SrcA MQ22820 ---	[WLFQD]SrcB MQ97324 ---								
24	99/123	NL 2	!=	[WLFQD]SrcA MQ22816 ---	[WLFQD]SrcB MQ97350 ---		COPYW	[W]Src MW22816 ---	[W]Dest MW97350 ---	[W]Width 00008			
			!=	[WLFQD]SrcA MQ22820 ---	[WLFQD]SrcB MQ97354 ---								
25	102/141	END_IF											
26	103/142	END											
				H50.18 : Mode Status_Unit8 (STR1)							P00003		