

H10:IO Signal Management									
0	0/0	CB000000	CB000000				SEE	Name H10.11 Sensor In_Unit1 (SP)	
1	3/5	SC Unit Type (0: SCT / 1 : CCT)	SC Unit Type (0: SCT / 1 : CCT)				SEE	Name H10.12 Sensor In_Unit2 (SC)	
2	4/6						SEE	Name H10.13 Sensor In_Unit3 (BKP)	
3	5/7						SEE	Name H10.14 Sensor In_Unit4 (BKT)	
4	6/9	CB000000					SEE	Name H10.15 Sensor In_Unit5 (SP)	
5	8/12	SC Unit Type (0: SCT / 1 : CCT)					SEE	Name H10.16 Sensor In_Unit6 (MBT)	
6	9/13						SEE	Name H10.17 Sensor In_Unit7 (MTR)	
7	10/14						SEE	Name H10.18 Sensor In_Unit8 (STR1)	
8	11/15						SEE	Name H10.19 Sensor In_Unit9 (SBT)	
9	12/16						SEE	Name H10.98 Table Level Input Management	
10	13/17						SEE	Name H10.99 LoadCell Input Management	
11	14/18				END				