

| H50.13:BKPb ModeStatus |          |          |                                                   |                                                        |    |                      |                                                        |                                                            |                                                                                                                                                                                                                             |
|------------------------|----------|----------|---------------------------------------------------|--------------------------------------------------------|----|----------------------|--------------------------------------------------------|------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Motor Status           |          |          |                                                   |                                                        |    |                      |                                                        |                                                            |                                                                                                                                                                                                                             |
| 0                      | 0000     | ==       | [WLFQD]SrcA<br>00000                              | [WLFQD]SrcB<br>OWB008<br>BKPBY1~M<br>otion comm<br>and | == | [WLFQD]SrcA<br>00000 | [WLFQD]SrcB<br>OWB088<br>BKPBY2~M<br>otion comm<br>and | MB050690<br>○<br>Break Pushe<br>r Bar Y Not<br>Cmd         | [ MB050690 ]<br>.../0018<br><br>H50.53/0100<br><br>H50.53/0328                                                                                                                                                              |
| 1                      | 0000     | ==       | [WLFQD]SrcA<br>00000                              | [WLFQD]SrcB<br>OWB108<br>BKPbZ1~M<br>otion comm<br>and | == | [WLFQD]SrcA<br>00000 | [WLFQD]SrcB<br>OWB188<br>BKPbZ2~M<br>otion comm<br>and | MB050692<br>○<br>Break Pushe<br>r Bar Z Not<br>Cmd         | [ MB050692 ]<br>.../0019<br>H50.53/0218<br>H50.54/0086<br>H50.54/0189<br>H50.54/0278<br>H50.53/0123<br>H50.53/0267<br>H50.54/0131<br>H50.54/0216<br>H50.54/0313<br>H50.53/0157<br>H50.53/0289<br>H50.54/0161<br>H50.54/0242 |
| 2                      | MB050690 | MB050692 | ○<br>Break Pushe<br>r Bar Y Not<br>Cmd            | ○<br>Break Pushe<br>r Bar Z Not<br>Cmd                 |    |                      |                                                        | MB050694<br>○<br>Break Pushe<br>r Bar No Co<br>mmand       | [ MB050694 ]<br>H50.52/0110<br>H50.52/0292<br>H50.53/0285<br>H50.52/0179<br>H50.53/0214<br>H50.52/0218<br>H50.53/0262                                                                                                       |
| Position               |          |          |                                                   |                                                        |    |                      |                                                        |                                                            |                                                                                                                                                                                                                             |
| 3                      | MB051000 | MB051020 | ○<br>Break Pushe<br>r Bar Y Waiti<br>ng Position  | ○<br>Break Pushe<br>r Bar Z Stan<br>dby Position       |    |                      |                                                        | MB050740<br>○<br>[BKPb] Stan<br>dby Position               | [ MB050740 ]<br>L20.43/1219                                                                                                                                                                                                 |
| 4                      | MB051003 | MB051023 | ○<br>[BKPbY] Bre<br>aking Positi<br>on            | ○<br>Break Pushe<br>r Bar Z Start<br>Position          |    |                      |                                                        | MB050742<br>○<br>[BKPb] Brea<br>k Start Positi<br>on       | [ MB050742 ]<br>L20.43/1233                                                                                                                                                                                                 |
| 5                      | MB051003 | MB051024 | ○<br>[BKPbY] Bre<br>aking Positi<br>on            | ○<br>Break Pushe<br>r Bar Z End<br>Position            |    |                      |                                                        | MB050743<br>○<br>[BKPb] Brea<br>k Execute P<br>osition     | [ MB050743 ]<br>L20.43/1240                                                                                                                                                                                                 |
| 6                      | MB051008 | MB051023 | ○<br>Break Pushe<br>r Bar Y Last<br>Breaking P-   | ○<br>Break Pushe<br>r Bar Z Start<br>Position          |    |                      |                                                        | MB050748<br>○<br>[BKPb] Last<br>Break Start<br>Position    | [ MB050748 ]<br>L20.43/1261                                                                                                                                                                                                 |
| 7                      | MB051008 | MB051024 | ○<br>Break Pushe<br>r Bar Y Last<br>Breaking P-   | ○<br>Break Pushe<br>r Bar Z End<br>Position            |    |                      |                                                        | MB050749<br>○<br>[BKPb] Last<br>Break Execu<br>te Position | [ MB050749 ]<br>L20.43/1268                                                                                                                                                                                                 |
| 8                      | MB05100A | MB05102A | ○<br>Break Pushe<br>r Bar Y Clea<br>ning Start P- | ○<br>Break Pushe<br>r Bar Z Clea<br>ning Position      |    |                      |                                                        | MB05074A<br>○<br>[BKPb] Clea<br>ning Start Po<br>sition    | [ MB05074A ]<br>H30.20/0350<br>H30.50/0631<br>L20.43/1289                                                                                                                                                                   |
| 9                      | MB05100B | MB05102A | ○<br>Break Pushe<br>r Bar Y Clea<br>ning End P-   | ○<br>Break Pushe<br>r Bar Z Clea<br>ning Position      |    |                      |                                                        | MB05074B<br>○<br>[BKPb] Clea<br>ning End Po<br>sition      | [ MB05074B ]<br>L20.43/1296                                                                                                                                                                                                 |
| 10                     | END      |          |                                                   |                                                        |    |                      |                                                        |                                                            |                                                                                                                                                                                                                             |