




H50.47/1675

H50.47/1689

		POSITION STATUS								
		MTR All Standby Pos								
13	40/80	MB071000 MTR Y Standby Pos	MB071010 MTR X Standby Pos	MB071020 MTR Z Standby Pos	MB071030 MTR T Standby Pos		MB071320 MTR All Standby Pos	[MB071320] H99.02/0446	H99.02/0472	L20.47/1219
		MTR All Trun Pos								
14	50/81	MB071001 MTR Y Turning Pos	MB071020 MTR Z Standby Pos				MB071321 MTR All Turning Pos	[MB071321] L20.47/1226		
		MTR All Carry In Pos								
15	54/94	MB071002 MTR Y Carry In Pos	MB071012 MTR X Carry In Pos	MB071020 MTR Z Standby Pos	MB071032 MTR T Carry In Pos		MB071322 MTR All Carry In Pos	[MB071322] L20.47/1233		
		MTR All Carry Out Pos								
16	58/99	MB071003 MTR Y Carry Out Pos	MB071013 MTR X Carry Out Pos	MB071020 MTR Z Standby Pos	MB071033 MTR T Carry Out Pos		MB071323 MTR All Carry Out Pos	[MB071323] H99.02/0395	L20.47/1240	
		MTR All PreAlign Pos								
17	64/104	MB071004 MTR Y PreAlign Pos	MB071020 MTR Z Standby Pos	MB071024 MTR Z PreAlign Pos	MB071038 MTR T PreAlign Pos	MB071041 MPA LX PreAlign Pos	MB071051 MPA RX PreAlign Pos	MB071324 MTR All PreAlign Pos	[MB071324] H99.02/0209	H99.02/0241 L20.47/1247
		MTR All MCR Pos								
18	70/111	MB071005 MTR Y MCR Pos	MB071020 MTR Z Standby Pos	MB071025 MTR Z MCR Pos	MB071039 MTR T MCR Pos	MB071061 MMCR X MCR Pos		MB071325 MTR All MCR Pos	[MB071325] H99.02/0265 H99.02/0287 H99.02/0312	H99.02/0273 H99.02/0294 H99.02/0352 H99.02/0280 H99.02/0301 L20.47/1254
		Main PreAlign Camera Standby Pos								
19	77/117	MB071040 MPA LX Standby Pos	MB071050 MPA RX Standby Pos					MB071328 Main PreAlign Camera Standby Pos	[MB071328] L20.47/1275	
		Main PreAlign Camera PreAlign Pos								
20	80/120	MB071041 MPA LX PreAlign Pos	MB071051 MPA RX PreAlign Pos					MB071329 Main PreAlign Camera PreAlign Pos	[MB071329] L20.47/1282	
		Main Transfer Vacuum Status								
21	83/123						STORE	[WLFQD]Src GW49120	[WLFQD]Dest DW00040	
22	84/125	MB071840 MTR Area1 Vacuum On Sensor DB000400	MB071841 MTR Area2 Vacuum On Sensor DB000401	MB071842 MTR Area3 Vacuum On Sensor DB000402	MB071843 MTR Area4 Vacuum On Sensor DB000403	MB071844 MTR Area5 Vacuum On Sensor DB000404		MB071845 MTR Area6 Vacuum On Sensor DB000405	[MB071888] H30.15/0011 H50.47/0803 H50.57/0107 H50.57/0197 H99.02/0195 H99.02/0311 H99.02/0405	H30.15/0393 H50.52/0362 H50.57/0131 H50.57/0217 H99.02/0206 H99.02/0362 L20.47/0504 H30.15/0396 H50.57/0080 H50.57/0176 H50.57/0217 H99.02/0171 H99.02/0264 H99.02/0393

