

8 17/62	RCHK	[WLFQD]In ILB016 BKPBY1~M achine coord inate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	RCHK	[WLFQD]In ILB096 BKPBY2~M achine coord inate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	[MB05100A] H50.13/0036 H50.52/0463 H99.02/1431	H50.52/0150 H99.02/1358 L20.43/0841	H50.52/0268 H99.02/1373 L80.23/0102
									MB05100A		
Break Pusher Bar Y Cleaning End Position											
9 20/63		EXPRESSION 'Lower Limit Value' = '[Calc] BKPBY Cleaning End Position' - 'Offset' DL00020 = ML72846 - DL00000; 'Upper Limit Value' = '[Calc] BKPBY Cleaning End Position' + 'Offset' DL00022 = ML72846 + DL00000;							[DL00022]	.../0014 .../0011w .../0028w .../0037 .../0058w .../0067 .../0084 .../0105 .../0115w .../0122 .../0132w .../0139 .../0149w .../0156 .../0166w .../0173 .../0183w .../0190 .../0200w .../0207	.../0018 .../0045 .../0081w .../0101 .../0118 .../0135 .../0152 .../0169 .../0186 .../0203
10 21/99	RCHK	[WLFQD]In ILB016 BKPBY1~M achine coord inate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	RCHK	[WLFQD]In ILB096 BKPBY2~M achine coord inate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	[MB05100B] H50.13/0039	L20.43/0848	
									MB05100B		
Break Pusher Bar Z Axis											
11 24/110		EXPRESSION 'Lower Limit Value' = '[Calc] BKPBY Standby Position' - 'DL00004' DL00020 = ML73202 - DL00004; 'Upper Limit Value' = '[Calc] BKPBY Standby Position' + 'DL00004' DL00022 = ML73202 + DL00004;							[DL00022]	.../0014 .../0011w .../0028w .../0037 .../0058w .../0067 .../0084 .../0101 .../0105 .../0115w .../0122 .../0132w .../0139 .../0149w .../0156 .../0166w .../0173 .../0183w .../0190 .../0200w .../0207	.../0018 .../0045 .../0081w .../0101 .../0118 .../0135 .../0152 .../0169 .../0186 .../0203
12 25/116	RCHK	[WLFQD]In ILB116 BKPBY1~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	RCHK	[WLFQD]In ILB196 BKPBY2~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	[MB051020] H50.12/0210 H50.12/0226 H50.52/0188 H50.52/0301 H50.52/0529 H50.52/0822 H50.53/0219 H50.53/0611 H50.53/0619 H50.53/0646 H50.54/0164 H50.54/0243 H50.54/0677 L80.22/0614 L80.23/0027 L80.24/0052	H50.12/0216 H50.13/0022 H50.52/0235 H50.52/0397 H50.52/0590 H50.53/0124 H50.53/0268 H50.53/0619 H50.54/0087 H50.54/0190 H50.54/0279 H50.54/0314 L80.23/0002 L80.23/0038 L80.24/0075	H50.12/0221 H50.52/0148 H50.52/0266 H50.52/0461 H50.52/0775 H50.53/0158 H50.53/0290 H50.53/0639 H50.54/0132 H50.54/0217 H50.54/0314 L80.23/0008 L80.24/0029
									MB051020		
Break Pusher Bar Z Break Start Position											
13 28/127		EXPRESSION 'Lower Limit Value' = '[Calc] BKPBY1 Breaking Start Position' - 'DL00004' DL00020 = ML73214 - DL00004; 'Upper Limit Value' = '[Calc] BKPBY1 Breaking Start Position' + 'DL00004' DL00022 = ML73214 + DL00004;							[DL00022]	.../0014 .../0011w .../0028w .../0037 .../0058w .../0067 .../0084 .../0101 .../0105 .../0115w .../0122 .../0132w .../0139 .../0149w .../0156 .../0166w .../0173 .../0183w .../0190 .../0200w .../0207	.../0018 .../0045 .../0081w .../0101 .../0118 .../0135 .../0152 .../0169 .../0186 .../0203
14 29/133	RCHK	[WLFQD]In ILB116 BKPBY1~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	RCHK	[WLFQD]In ILB196 BKPBY2~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	[MB051023] H50.13/0025 H50.53/0640 H50.54/0133 H50.54/0218 H50.54/0315	H50.13/0031 H50.53/0647 H50.54/0165 H50.54/0244 H99.02/1394	H50.53/0384 H50.54/0088 H50.54/0191 H50.54/0280 L20.43/0897
									MB051023		
Break Pusher Bar Z Break End Position											
15 32/144		EXPRESSION 'Lower Limit Value' = '[Calc] BKPBY Breaking End Position' - 'DL00004' DL00020 = ML73218 - DL00004; 'Upper Limit Value' = '[Calc] BKPBY Breaking End Position' + 'DL00004' DL00022 = ML73218 + DL00004;							[DL00022]	.../0014 .../0011w .../0028w .../0037 .../0058w .../0067 .../0084 .../0101 .../0105 .../0115w .../0122 .../0132w .../0139 .../0149w .../0156 .../0166w .../0173 .../0183w .../0190 .../0200w .../0207	.../0018 .../0045 .../0081w .../0101 .../0118 .../0135 .../0152 .../0169 .../0186 .../0203
16 33/150	RCHK	[WLFQD]In ILB116 BKPBY1~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	RCHK	[WLFQD]In ILB196 BKPBY2~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	[MB051024] H50.13/0028	H50.13/0034	L20.43/0904
									MB051024		
Break Pusher Bar Z End Position											

17 38/161	Break Pusher Bar Z Last Break Start Position								[DL00022] .../0011w .../0028w .../0058w .../0084 .../0101 .../0118 .../0135 .../0152 .../0173 .../0190 .../0207	.../0014 .../0037 .../0067 .../0088 .../0105 .../0122 .../0139 .../0156 .../0183w .../0200w	.../0018 .../0045 .../0081w .../0098w .../0115w .../0132w .../0149w .../0169 .../0186 .../0203
			EXPRESSION 'Lower Limit Value' = '[Calc] BKPbZ Last Breaking Start Position' - 'DL00004' DL00020 = ML73234 - DL00004; 'Upper Limit Value' = '[Calc] BKPbZ Last Breaking Start Position' + 'DL00004' DL00022 = ML73234 + DL00004;								
18 37/167	RCHK	[WLFQD]In ILB116 BKPbZ1~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	RCHK	[WLFQD]In ILB196 BKPbZ2~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	[MB051028] H50.53/0434 H50.54/0166 H50.54/0245	H50.54/0089 H50.54/0192 H50.54/0281	H50.54/0134 H50.54/0219 H50.54/0316
Break Pusher Bar Z Last Break End Position											
19 40/178			EXPRESSION 'Lower Limit Value' = '[Calc] BKPbZ Last Breaking End Position' - 'DL00004' DL00020 = ML73238 - DL00004; 'Upper Limit Value' = '[Calc] BKPbZ Last Breaking End Position' + 'DL00004' DL00022 = ML73238 + DL00004;						[DL00022] .../0011w .../0028w .../0058w .../0084 .../0101 .../0118 .../0135 .../0152 .../0169 .../0190 .../0207	.../0014 .../0037 .../0067 .../0088 .../0105 .../0122 .../0139 .../0156 .../0173 .../0200w	.../0018 .../0045 .../0081w .../0098w .../0115w .../0132w .../0149w .../0166w .../0186 .../0203
20 41/184	RCHK	[WLFQD]In ILB116 BKPbZ1~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	RCHK	[WLFQD]In ILB196 BKPbZ2~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	[MB051029] H50.53/0037 H50.52/0267 H50.53/0291 H50.54/0678	H50.13/0040 H50.52/0462 H50.53/0620 L20.43/0953	H50.52/0149 H50.53/0220 H50.54/0193 L80.23/0044
Break Pusher Bar Z Cleaning Position											
21 44/195			EXPRESSION 'Lower Limit Value' = '[Calc] BKPbZ Cleaning Position' - 'DL00004' DL00020 = ML73242 - DL00004; 'Upper Limit Value' = '[Calc] BKPbZ Cleaning Position' + 'DL00004' DL00022 = ML73242 + DL00004;						[DL00022] .../0011w .../0028w .../0058w .../0084 .../0101 .../0118 .../0135 .../0152 .../0169 .../0186 .../0207	.../0014 .../0037 .../0067 .../0088 .../0105 .../0122 .../0139 .../0156 .../0173 .../0190	.../0018 .../0045 .../0081w .../0098w .../0115w .../0132w .../0149w .../0166w .../0183w .../0203
22 45/201	RCHK	[WLFQD]In ILB116 BKPbZ1~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	RCHK	[WLFQD]In ILB196 BKPbZ2~Ma chine coordi nate feedb-	[WLFQD]Lower DL00020 Lower Limit Value	[WLFQD]Upper DL00022 Upper Limit Value	[MB05102A] H50.13/0037 H50.52/0267 H50.53/0291 H50.54/0678	H50.13/0040 H50.52/0462 H50.53/0620 L20.43/0953	H50.52/0149 H50.53/0220 H50.54/0193 L80.23/0044
23 48/212			END						[MB05102A] H50.13/0037 H50.52/0267 H50.53/0291 H50.54/0678	H50.13/0040 H50.52/0462 H50.53/0620 L20.43/0953	H50.52/0149 H50.53/0220 H50.54/0193 L80.23/0044