

H20.30:ButtonTag_(Enable)					
EQP Parameter (0.1) MW86001					
0	MB00000F				MB860010
	Debug				---
					[MB860010] L20.50/0007
Axis Parameter (0.2) MW86002					
1	MB00000F				MB860020
	Debug				---
					[MB860020] L20.50/0009
All Standby Off (0.07) MW86007					
2	MB00000F				MB860070
	Debug				BTN_INT : 0 - 07 (1)
					[MB860070] L20.50/0019
All Standby On (0.08) MW86008					
3	MB1150910	MB1170910	MB1180910		MB860080
	전축 서보준비	전축 서보준비	전축 서보준비		BTN_INT : 0 - 08 (1)
					[MB860080] L20.50/0021
4	MB1150911	MB1170911	MB1180911		MB860081
	전축 서보 파워On	전축 서보 파워On	전축 서보 파워On		BTN_INT : 0 - 08 (2)
					[MB860081] L20.50/0022
5	MB1150912	MB1170912	MB1180912		MB860082
	No 알람(중)	No 알람(중)	No 알람(중)		BTN_INT : 0 - 08 (3)
					[MB860082] L20.50/0023
6	MB1150913	MB1170913	MB1180913		MB860083
	Jo 화면데이터 편조 중	Jo 화면데이터 편조 중	Jo 화면데이터 편조 중		BTN_INT : 0 - 08 (4)
					[MB860083] L20.50/0024
7	MB1150914	MB1170914	MB1180914		MB860084
	No 알람	No 알람	No 알람		BTN_INT : 0 - 08 (5)
					[MB860084] L20.50/0025
8	MB1150915	MB1170915	MB1180915		MB860085
	도어키내부 입력	도어키내부 입력	도어키내부 입력		BTN_INT : 0 - 08 (6)
					[MB860085] L20.50/0026
9	MB1150916	MB1170916	MB1180916		MB860086
	망치 전체도어 Clot e	망치 전체도어 Clot e	망치 전체도어 Clot e		BTN_INT : 0 - 08 (7)
					[MB860086] L20.50/0027
All Auto Run Start (0.09) MW86009					
10	MB1150919	MB1170919	MB1180919		MB860090
	운전준비 완료	운전준비 완료	운전준비 완료		BTN_INT : 0 - 09 (1)
					[MB860090] L20.50/0029
11	MB115091A	MB117091A	MB118091A		MB860091
	Jo PLC내부파라미터 경신	Jo PLC내부파라미터 경신	Jo PLC내부파라미터 경신		BTN_INT : 0 - 09 (2)
					[MB860091] L20.50/0030
12	MB115091B	MB117091B	MB118091B		MB860092
	자동모드	자동모드	자동모드		BTN_INT : 0 - 09 (3)
					[MB860092] L20.50/0031
13	MB115091C	MB117091C	MB118091C		MB860093
	Jo 화면데이터 편조 중	Jo 화면데이터 편조 중	Jo 화면데이터 편조 중		BTN_INT : 0 - 09 (4)
					[MB860093] L20.50/0032
14	MB115091D	MB117091D	MB118091D		MB860094
	No 알람	No 알람	No 알람		BTN_INT : 0 - 09 (5)
					[MB860094] L20.50/0033
15	MB115091E	MB117091E	MB118091E		MB860095
	ABS위치 설정완료	ABS위치 설정완료	ABS위치 설정완료		BTN_INT : 0 - 09 (6)
					[MB860095] L20.50/0034
16	MB115091F	MB117091F	MB118091F		MB860096
	공운전 / 운라인모드	공운전 / 운라인모드	공운전 / 운라인모드		BTN_INT : 0 - 09 (7)
					[MB860096] L20.50/0035
17	MB1150920	MB1170920	MB1180920		MB860097
	S1<->S2-1 레시프 Unmatch	S1<->S2-1 레시프 Unmatch	S1<->S2-1 레시프 Unmatch		BTN_INT : 0 - 09 (8)
					[MB860097] L20.50/0036
18	MB1150921	MB1170921	MB1180921		MB860098
	절입 On	절입 On	절입 On		BTN_INT : 0 - 09 (9)
					[MB860098] L20.50/0037
19	MB1150922	MB1170922	MB1180922		MB860099
	타칭모드 Off	타칭모드 Off	타칭모드 Off		BTN_INT : 0 - 09 (10)
					[MB860099] L20.50/0038
20	MB1150923	MB1170923	MB1180923		MB86009A
	S1<->S2-2 레시프 Unmatch	S1<->S2-2 레시프 Unmatch	S1<->S2-2 레시프 Unmatch		BTN_INT : 0 - 09 (11)
					[MB86009A] L20.50/0039
21	MB115000C	MB117000C	MB118000C		MB86009B
	[Link : S1] Online Mode	LINK : MSB2A Online Mode	LINK : MSB2B Online Mode		BTN_INT : 0 - 09 (12)
	MB115000C	MB117000C	MB118000C		
	[Link : S1] Online Mode	LINK : MSB2A Online Mode	LINK : MSB2B Online Mode		
					[MB86009B] L20.50/0040
22	MB1150925	MB1170925	MB1180925		MB86009C
	SC Chuck Move Permission	SC Chuck Move Permission	SC Chuck Move Permission		BTN_INT : 0 - 09 (13)
					[MB86009C] L20.50/0041
23	MB1150926	MB1170926	MB1180926		MB86009D
	원점복귀 완료	원점복귀 완료	원점복귀 완료		BTN_INT : 0 - 09 (14)
					[MB86009D] L20.50/0042
24	MB1150927	MB1170927	MB1180927		MB86009E
	운전정지	운전정지	운전정지		BTN_INT : 0 - 09 (15)
					[MB86009E] L20.50/0043
All Operation Stop (0.10) MW86010					
25	MB00000F				MB860100
	Debug				BTN_INT : 0 - 10 (1)
					[MB860100] L20.50/0045

[illegible]

P00004 L80.10 : BTN Interlock_(Equipment)

58 197/200	MB00003A Editing	MB032000 MPM010 Run / MPM010 Wor k Register 1	MB032300 MPM012 Run / MPM012 Wor k Register 1			MB860253 BTN_INT : 0 - 25 (4)	[MB860253] H80.20/0255 L20.50/0098	H80.21/0156	H80.22/0156
59 201/204	MB00000A Alarm					MB860254 BTN_INT : 0 - 25 (5)	[MB860254] H80.20/0257 L20.50/0099	H80.21/0158	H80.22/0158
60 203/205	MB00005F ABS Setting C mp	MB000053 All Servo Ori n Setting #1				MB860255 BTN_INT : 0 - 25 (6)	[MB860255] H80.20/0259 L20.50/0100	H80.21/0160	H80.22/0160
61 206/209	MB000800 MCTAG_Idling	MB000025 Online Mode				MB860256 BTN_INT : 0 - 25 (7)	[MB860256] H80.20/0261 L20.50/0101	H80.21/0162	H80.22/0162
		CB000620 Online Mode D el (0 : Unuse, 1 : Use)							
	MB000800 MCTAG_Idling	MB000025 Online Mode	CB000620 Online Mode D el (0 : Unuse, 1 : Use)						
	MB000800 MCTAG_Idling	MB000025 Online Mode	CB000620 Online Mode D el (0 : Unuse, 1 : Use)						
62 216/219	MB030680 SCT↔LCCT R escape No Unm atch					MB860257 BTN_INT : 0 - 25 (8)	[MB860257] H80.20/0263 L20.50/0102	H80.21/0164	H80.22/0164
	MB00002A Single Mode	MB000800 MCTAG_Idling							
63 220/223	MB000802 MCTAG_Cuttin g On					MB860258 BTN_INT : 0 - 25 (9)	[MB860258] H80.20/0265 L20.50/0103	H80.21/0166	H80.22/0166
	MB000800 MCTAG_Idling								
64 223/226	MB1150009 [Link : S1] Tea ching Key On	MB1170009 [Link : S2-1] Te aching Key On	MB045720 Teach Mode O ff			MB860259 BTN_INT : 0 - 25 (10)	[MB860259] H80.20/0267 L20.50/0104	H80.21/0168	H80.22/0168
		MB1180009 [Link : S2-2] Te aching Key On							
65 228/231	MB030681 SCT↔RCCT R escape No Unm atch					MB86025A BTN_INT : 0 - 25 (11)	[MB86025A] H80.20/0269 L20.50/0105	H80.21/0170	H80.22/0170
	MB00002A Single Mode	MB000800 MCTAG_Idling							
66 232/235	MB115000C [Link : S1] Onli ne Mode	MB117000C LINK : MSB2A Online Mode	MB118000C LINK : MSB2B Online Mode			MB86025B BTN_INT : 0 - 25 (12)	[MB86025B] H80.20/0271 L20.50/0106	H80.21/0172	H80.22/0172
		MB00000F Debug							
	MB115000C [Link : S1] Onli ne Mode	MB117000C LINK : MSB2A Online Mode	MB118000C LINK : MSB2B Online Mode						
	MB000800 MCTAG_Idling								
67 241/244	MB000027 Maintenance					MB86025C BTN_INT : 0 - 25 (13)	[MB86025C] H80.20/0273 L20.50/0107	H80.21/0174	H80.22/0174
68 243/246	MB000019 Returning to H ome					MB86025D BTN_INT : 0 - 25 (14)	[MB86025D] H80.20/0275 L20.50/0108	H80.21/0176	H80.22/0176
69 245/248	GBxxx Stopping	MSEE_017~ .Stop	MSEE_012~ .Stop	MSEE_015~ .Stop	MSEE_016~ .Stop	MB86025E BTN_INT : 0 - 25 (15)	[MB86025E] H80.20/0277 L20.50/0109	H80.21/0178	H80.22/0178
70 251/263	MB000181 SCT Use	==	[WLFQD]SrcA ML04552	[WLFQD]SrcB 00000			[MB86025F] L20.50/0110		
	MB000181 SCT Use	==	[WLFQD]SrcA ML04552	[WLFQD]SrcB 00000	==	[WLFQD]SrcA ML05052	[WLFQD]SrcB 00000		
						MB86025F BTN_INT : 0 - 25 (16)			
71 251/269	MB00000F Debug					MB860260 BTN_INT : 0 - 26 (1)	[MB860260] L20.50/0112		
72 259/271	MB00000F Debug					MB860270 BTN_INT : 0 - 27 (1)	[MB860270] L20.50/0114		

95	Panel Force Set (1.19) MW86051					[MB860510] L20.50/0165
	GBxxx				MB860510	
313/331	Stopping				BTN_INT : 1 - 19 (1)	
96	Scrap Don't Report Mode (1.20) MW86052					[MB860520] L20.50/0167
	MB00000F				MB860520	
315/333	Debug				BTN_INT : 1 - 20 (1)	
97	Upper 1 PIO Reset (1.26) MW86058					[MB860580] L20.50/0179
	MB000025				MB860580	
	Online Mode				BTN_INT : 1 - 26 (1)	
	CB000630					
	Inline Mode De l (0 : Unuse, 1 : Use)					
98	OnCoil					[MB860581] L20.50/0180
	Always ON					
98	GBxxx				MB860581	[MB860581] L20.50/0180
	Stopping				BTN_INT : 1 - 26 (2)	
99	Upper 2 PIO Reset (1.27) MW86059					[MB860590] L20.50/0182
	MB000025				MB860590	
	Online Mode				---	
	CB000630					
	Inline Mode De l (0 : Unuse, 1 : Use)					
100	OnCoil					[MB860591] L20.50/0183
	Always ON					
100	GBxxx				MB860591	[MB860591] L20.50/0183
	Stopping				---	
101	Lower 1 PIO Reset (1.28) MW86060					[MB860600] L20.50/0185
	MB000025				MB860600	
	Online Mode				BTN_INT : 1 - 28 (1)	
	CB000620					
	Online Mode De l (0 : Unuse, 1 : Use)					
102	CB000630					[MB860601] L20.50/0186
	Inline Mode De l (0 : Unuse, 1 : Use)					
102	GBxxx				MB860601	[MB860601] L20.50/0186
	Stopping				BTN_INT : 1 - 28 (2)	
103	Lower 2 PIO Reset (1.29) MW86061					[MB860610] L20.50/0188
	MB000025				MB860610	
	Online Mode				---	
	CB000620					
	Online Mode De l (0 : Unuse, 1 : Use)					
104	CB000630					[MB860611] L20.50/0189
	Inline Mode De l (0 : Unuse, 1 : Use)					
104	GBxxx				MB860611	[MB860611] L20.50/0189
	Stopping				---	
105	Lower 3 PIO Reset (1.30) MW86062					[MB860620] L20.50/0191
	MB000025				MB860620	
	Online Mode				BTN_INT : 1 - 30 (1)	
	CB000620					
	Online Mode De l (0 : Unuse, 1 : Use)					
106	CB000630					[MB860621] L20.50/0192
	Inline Mode De l (0 : Unuse, 1 : Use)					
106	GBxxx				MB860621	[MB860621] L20.50/0192
	Stopping				BTN_INT : 1 - 30 (2)	
107	Lower 4 PIO Reset (1.31) MW86063					[MB860630] L20.50/0194
	MB000025				MB860630	
	Online Mode				---	
	CB000620					
	Online Mode De l (0 : Unuse, 1 : Use)					
108	CB000630					[MB860631] L20.50/0195
	Inline Mode De l (0 : Unuse, 1 : Use)					
108	GBxxx				MB860631	[MB860631] L20.50/0195
	Stopping					

	0 Declaction (2.19) MW86083					
131	MB000800				MB860830	[MB860830]
408/426	MCTAG_Idling				---	L20.50/0243
	Offset Set Mode MW86086					
132	MB000800				MB860860	[MB860860]
410/428	MCTAG_Idling				---	L20.50/0249
	Load Measurement Mode MW86090					
133	MB000800				MB860900	[MB860900]
412/430	MCTAG_Idling				---	L20.50/0257
	Load Calibration MW86091					
134	MB000800				MB860910	[MB860910]
414/432	MCTAG_Idling				---	L20.50/0259
	첫장검사모드 MW86092					
135	MB000800				MB860920	[MB860920]
416/434	MCTAG_Idling				---	L20.50/0261
	Line Check MW86093					
136	MB000800				MB860930	[MB860930]
418/436	MCTAG_Idling				---	L20.50/0263
	Ionizer 1 On (6.00) MW86192					
137	MB00000F				MB861920	[MB861920]
420/438	Debug				BTN_INT : 6 - 00 (1)	L20.50/0340
	Ionizer 1 Off (6.01) MW86193					
138	MB00000F				MB861930	[MB861930]
422/440	Debug				BTN_INT : 6 - 01 (1)	L20.50/0342
	Ionizer 2 On (6.02) MW86194					
139	MB00000F				MB861940	[MB861940]
424/442	Debug				BTN_INT : 6 - 02 (1)	L20.50/0344
	Ionizer 2 Off (6.03) MW86195					
140	MB00000F				MB861950	[MB861950]
426/444	Debug				BTN_INT : 6 - 03 (1)	L20.50/0346
	Ionizer 3 On (6.04) MW86196					
141	MB00000F				MB861960	[MB861960]
428/446	Debug				BTN_INT : 6 - 04 (1)	L20.50/0348
	Ionizer 3 Off (6.05) MW86197					
142	MB00000F				MB861970	[MB861970]
430/448	Debug				BTN_INT : 6 - 05 (1)	L20.50/0350
	Ionizer 4 On (6.06) MW86198					
143	MB00000F				MB861980	[MB861980]
432/450	Debug				BTN_INT : 6 - 06 (1)	L20.50/0352
	Ionizer 4 Off (6.07) MW86199					
144	MB00000F				MB861990	[MB861990]
434/452	Debug				BTN_INT : 6 - 07 (1)	L20.50/0354
	Ionizer 5 On (6.08) MW86200					
145	MB00000F				MB862000	[MB862000]
436/454	Debug				BTN_INT : 6 - 08 (1)	L20.50/0356
	Ionizer 5 Off (6.09) MW86201					
146	MB00000F				MB862010	[MB862010]
438/456	Debug				BTN_INT : 6 - 09 (1)	L20.50/0358
	Ionizer 6 On (6.10) MW86202					
147	MB00000F				MB862020	[MB862020]
440/458	Debug				BTN_INT : 6 - 10 (1)	L20.50/0360
	Ionizer 6 Off (6.11) MW86203					
148	MB00000F				MB862030	[MB862030]
442/460	Debug				BTN_INT : 6 - 11 (1)	L20.50/0362
	Ionizer 7 On (6.12) MW86204					
149	MB00000F				MB862040	[MB862040]
444/462	Debug				BTN_INT : 6 - 12 (1)	L20.50/0364
	Ionizer 7 Off (6.13) MW86205					
150	MB00000F				MB862050	[MB862050]
446/464	Debug				BTN_INT : 6 - 13 (1)	L20.50/0366
	Ionizer 8 On (6.14) MW86206					
151	MB00000F				MB862060	[MB862060]
448/466	Debug				---	L20.50/0368
	Ionizer 8 Off (6.15) MW86207					
152	MB00000F				MB862070	[MB862070]
450/468	Debug				---	L20.50/0370
	Ionizer 9 On (6.16) MW86208					
153	MB00000F				MB862080	[MB862080]
452/470	Debug				---	L20.50/0372
	Ionizer 9 Off (6.17) MW86209					
154	MB00000F				MB862090	[MB862090]
454/472	Debug				---	L20.50/0374
	Dust Chather Remote On (7.00) MW86224					
155	MB00000F				MB862240	[MB862240]
456/474						L20.50/0404

Dust Chalthr Remote Off (7.01) MW86225									
156	MB00000F						MB862250	[MB862250]	
430/470	Debug						BTN_INT : 7 - 01 (1)	L20.50/0406	
SCT Break Table Hyper Clean L On (7.16) MW86240									
157	MB00000F						MB862400	[MB862400]	
430/470	Debug						---	L20.50/0436	
SCT Break Table Hyper Clean L Off (7.17) MW86241									
158	MB00000F						MB862410	[MB862410]	
432/480	Debug						---	L20.50/0438	
SCT Break Table Hyper Clean R On (7.18) MW86242									
159	MB00000F						MB862420	[MB862420]	
464/482	Debug						---	L20.50/0440	
SCT Break Table Hyper Clean R Off (7.19) MW86243									
160	MB00000F						MB862430	[MB862430]	
466/486	Debug						---	L20.50/0442	
161									
468/488									
END									