

		L80.15:BTN Interlock_Unit5 (SP)					
		ManualEnable(Sol)					
		=====					
		Vacuum					
		=====					
		Manual Interlock(Sol)(32.00)					
0	0/0	MB000080				MB870240	[MB870240] L20.55/0000
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.01)					
1	2/2	MB000080				MB870250	[MB870250] L20.55/0002
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.02)					
2	4/4	MB000080				MB870260	[MB870260] L20.55/0004
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.03)					
3	6/6	MB000080				MB870270	[MB870270] L20.55/0006
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.04)					
4	8/8	MB000080				MB870280	[MB870280] L20.55/0008
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.05)					
5	10/10	MB000080				MB870290	[MB870290] L20.55/0010
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.06)					
6	12/12	MB000080				MB870300	[MB870300] L20.55/0012
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.07)					
7	14/14	MB000080				MB870310	[MB870310] L20.55/0014
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.08)					
8	16/16	MB000080				MB870320	[MB870320] L20.55/0016
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.09)					
9	18/18	MB000080				MB870330	[MB870330] L20.55/0018
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.10)					
10	20/20	MB000080				MB870340	[MB870340] L20.55/0020
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.11)					
11	22/22	MB000080				MB870350	[MB870350] L20.55/0022
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.12)					
12	24/24	MB000080				MB870360	[MB870360] L20.55/0024
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.13)					
13	26/26	MB000080				MB870370	[MB870370] L20.55/0026
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.14)					
14	28/28	MB000080				MB870380	[MB870380] L20.55/0028
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.15)					
15	30/30	MB000080				MB870390	[MB870390] L20.55/0030
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.16)					
16	32/32	MB000080				MB870400	[MB870400] L20.55/0032
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.17)					
17	34/34	MB000080				MB870410	[MB870410] L20.55/0034
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.18)					
18	36/36	MB000080				MB870420	[MB870420] L20.55/0036
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.19)					
19	38/38	MB000080				MB870430	[MB870430] L20.55/0038
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.20)					
20	40/40	MB000080				MB870440	[MB870440] L20.55/0040
		Manual comm on IL(Sol)				---	
		Manual Interlock(Sol)(32.21)					
21	42/42	MB000080				MB870450	[MB870450] L20.55/0042
		Manual comm				---	

		Manual Interlock(Sol)(32.22)						
22	44/44	MB000080					MB870460	[MB870460] L20.55/0044
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(32.23)						
23	45/45	MB000080					MB870470	[MB870470] L20.55/0046
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(32.24)						
24	46/46	MB000080					MB870480	[MB870480] L20.55/0048
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(32.25)						
25	50/50	MB000080					MB870490	[MB870490] L20.55/0050
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(32.26)						
26	52/52	MB000080					MB870500	[MB870500] L20.55/0052
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(32.27)						
27	54/54	MB000080					MB870510	[MB870510] L20.55/0054
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(32.28)						
28	56/56	MB000080					MB870520	[MB870520] L20.55/0056
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(32.29)						
29	58/58	MB000080					MB870530	[MB870530] L20.55/0058
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(32.30)						
30	60/60	MB000080					MB870540	[MB870540] L20.55/0060
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(32.31)						
31	62/62	MB000080					MB870550	[MB870550] L20.55/0062
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.00)						
32	64/64	MB000080					MB870560	[MB870560] L20.55/0064
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.01)						
33	66/66	MB000080					MB870570	[MB870570] L20.55/0066
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.02)						
34	68/68	MB000080					MB870580	[MB870580] L20.55/0068
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.03)						
35	70/70	MB000080					MB870590	[MB870590] L20.55/0070
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.04)						
36	72/72	MB000080					MB870600	[MB870600] L20.55/0072
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.05)						
37	74/74	MB000080					MB870610	[MB870610] L20.55/0074
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.06)						
38	76/76	MB000080					MB870620	[MB870620] L20.55/0076
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.07)						
39	78/78	MB000080					MB870630	[MB870630] L20.55/0078
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.08)						
40	80/80	MB000080					MB870640	[MB870640] L20.55/0080
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.09)						
41	82/82	MB000080					MB870650	[MB870650] L20.55/0082
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.10)						
42	84/84	MB000080					MB870660	[MB870660] L20.55/0084
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.11)						
43	86/86	MB000080					MB870670	[MB870670] L20.55/0086
		Manual comm on IL(Sol)					---	
		Manual Interlock(Sol)(33.12)						
44	88/88	MB000080					MB870680	[MB870680] L20.55/0088
		Manual comm on IL(Sol)					---	

	Manual Interlock(Sol)(33.13)						
45	MB000080					MB870690	[MB870690] L20.55/0090
90/90	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.14)						
46	MB000080					MB870700	[MB870700] L20.55/0092
92/92	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.15)						
47	MB000080					MB870710	[MB870710] L20.55/0094
94/94	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.16)						
48	MB000080					MB870720	[MB870720] L20.55/0096
96/96	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.17)						
49	MB000080					MB870730	[MB870730] L20.55/0098
98/98	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.18)						
50	MB000080					MB870740	[MB870740] L20.55/0100
100/100	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.19)						
51	MB000080					MB870750	[MB870750] L20.55/0102
102/102	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.20)						
52	MB000080					MB870760	[MB870760] L20.55/0104
104/104	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.21)						
53	MB000080					MB870770	[MB870770] L20.55/0106
106/106	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.22)						
54	MB000080					MB870780	[MB870780] L20.55/0108
108/108	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.23)						
55	MB000080					MB870790	[MB870790] L20.55/0110
110/110	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.24)						
56	MB000080					MB870800	[MB870800] L20.55/0112
112/112	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.25)						
57	MB000080					MB870810	[MB870810] L20.55/0114
114/114	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.26)						
58	MB000080					MB870820	[MB870820] L20.55/0116
116/116	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.27)						
59	MB000080					MB870830	[MB870830] L20.55/0118
118/118	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.28)						
60	MB000080					MB870840	[MB870840] L20.55/0120
120/120	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.29)						
61	MB000080					MB870850	[MB870850] L20.55/0122
122/122	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.30)						
62	MB000080					MB870860	[MB870860] L20.55/0124
124/124	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(33.31)						
63	MB000080					MB870870	[MB870870] L20.55/0126
126/126	Manual comm on IL(Sol)					---	
	Blow						
	Manual Interlock(Sol)(34.00)						
64	MB000080					MB870880	[MB870880] L20.55/0128
128/128	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(34.01)						
65	MB000080					MB870890	[MB870890] L20.55/0130
130/130	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(34.02)						
66	MB000080					MB870900	[MB870900] L20.55/0132
132/132	Manual comm on IL(Sol)					---	

67	Manual Interlock(Sol)(34.03)						MB870910	[MB870910] L20.55/0134
	MB000080							
134/134	Manual comm on IL(Sol)						---	
68	Manual Interlock(Sol)(34.04)						MB870920	[MB870920] L20.55/0136
	MB000080							
136/136	Manual comm on IL(Sol)						---	
69	Manual Interlock(Sol)(34.05)						MB870930	[MB870930] L20.55/0138
	MB000080							
138/138	Manual comm on IL(Sol)						---	
70	Manual Interlock(Sol)(34.06)						MB870940	[MB870940] L20.55/0140
	MB000080							
140/140	Manual comm on IL(Sol)						---	
71	Manual Interlock(Sol)(34.07)						MB870950	[MB870950] L20.55/0142
	MB000080							
142/142	Manual comm on IL(Sol)						---	
72	Manual Interlock(Sol)(34.08)						MB870960	[MB870960] L20.55/0144
	MB000080							
144/144	Manual comm on IL(Sol)						---	
73	Manual Interlock(Sol)(34.09)						MB870970	[MB870970] L20.55/0146
	MB000080							
146/146	Manual comm on IL(Sol)						---	
74	Manual Interlock(Sol)(34.10)						MB870980	[MB870980] L20.55/0148
	MB000080							
148/148	Manual comm on IL(Sol)						---	
75	Manual Interlock(Sol)(34.11)						MB870990	[MB870990] L20.55/0150
	MB000080							
150/150	Manual comm on IL(Sol)						---	
76	Manual Interlock(Sol)(34.12)						MB871000	[MB871000] L20.55/0152
	MB000080							
152/152	Manual comm on IL(Sol)						---	
77	Manual Interlock(Sol)(34.13)						MB871010	[MB871010] L20.55/0154
	MB000080							
154/154	Manual comm on IL(Sol)						---	
78	Manual Interlock(Sol)(34.14)						MB871020	[MB871020] L20.55/0156
	MB000080							
156/156	Manual comm on IL(Sol)						---	
79	Manual Interlock(Sol)(34.15)						MB871030	[MB871030] L20.55/0158
	MB000080							
158/158	Manual comm on IL(Sol)						---	
80	Manual Interlock(Sol)(34.16)						MB871040	[MB871040] L20.55/0160
	MB000080							
160/160	Manual comm on IL(Sol)						---	
81	Manual Interlock(Sol)(34.17)						MB871050	[MB871050] L20.55/0162
	MB000080							
162/162	Manual comm on IL(Sol)						---	
82	Manual Interlock(Sol)(34.18)						MB871060	[MB871060] L20.55/0164
	MB000080							
164/164	Manual comm on IL(Sol)						---	
83	Manual Interlock(Sol)(34.19)						MB871070	[MB871070] L20.55/0166
	MB000080							
166/166	Manual comm on IL(Sol)						---	
84	Manual Interlock(Sol)(34.20)						MB871080	[MB871080] L20.55/0168
	MB000080							
168/168	Manual comm on IL(Sol)						---	
85	Manual Interlock(Sol)(34.21)						MB871090	[MB871090] L20.55/0170
	MB000080							
170/170	Manual comm on IL(Sol)						---	
86	Manual Interlock(Sol)(34.22)						MB871100	[MB871100] L20.55/0172
	MB000080							
172/172	Manual comm on IL(Sol)						---	
87	Manual Interlock(Sol)(34.23)						MB871110	[MB871110] L20.55/0174
	MB000080							
174/174	Manual comm on IL(Sol)						---	
88	Manual Interlock(Sol)(34.24)						MB871120	[MB871120] L20.55/0176
	MB000080							
176/176	Manual comm on IL(Sol)						---	
89	Manual Interlock(Sol)(34.25)						MB871130	[MB871130] L20.55/0178
	MB000080							
178/178	Manual comm on IL(Sol)						---	

90	Manual Interlock(Sol)(34.26)						[MB871140] L20.55/0180
	MB000080					MB871140	
180/180	Manual comm on IL(Sol)					---	
91	Manual Interlock(Sol)(34.27)						[MB871150] L20.55/0182
	MB000080					MB871150	
182/182	Manual comm on IL(Sol)					---	
92	Manual Interlock(Sol)(34.28)						[MB871160] L20.55/0184
	MB000080					MB871160	
184/184	Manual comm on IL(Sol)					---	
93	Manual Interlock(Sol)(34.29)						[MB871170] L20.55/0186
	MB000080					MB871170	
186/186	Manual comm on IL(Sol)					---	
94	Manual Interlock(Sol)(34.30)						[MB871180] L20.55/0188
	MB000080					MB871180	
188/188	Manual comm on IL(Sol)					---	
95	Manual Interlock(Sol)(34.31)						[MB871190] L20.55/0190
	MB000080					MB871190	
190/190	Manual comm on IL(Sol)					---	
96	Manual Interlock(Sol)(35.00)						[MB871200] L20.55/0192
	MB000080					MB871200	
192/192	Manual comm on IL(Sol)					---	
97	Manual Interlock(Sol)(35.01)						[MB871210] L20.55/0194
	MB000080					MB871210	
194/194	Manual comm on IL(Sol)					---	
98	Manual Interlock(Sol)(35.02)						[MB871220] L20.55/0196
	MB000080					MB871220	
196/196	Manual comm on IL(Sol)					---	
99	Manual Interlock(Sol)(35.03)						[MB871230] L20.55/0198
	MB000080					MB871230	
198/198	Manual comm on IL(Sol)					---	
100	Manual Interlock(Sol)(35.04)						[MB871240] L20.55/0200
	MB000080					MB871240	
200/200	Manual comm on IL(Sol)					---	
101	Manual Interlock(Sol)(35.05)						[MB871250] L20.55/0202
	MB000080					MB871250	
202/202	Manual comm on IL(Sol)					---	
102	Manual Interlock(Sol)(35.06)						[MB871260] L20.55/0204
	MB000080					MB871260	
204/204	Manual comm on IL(Sol)					---	
103	Manual Interlock(Sol)(35.07)						[MB871270] L20.55/0206
	MB000080					MB871270	
206/206	Manual comm on IL(Sol)					---	
104	Manual Interlock(Sol)(35.08)						[MB871280] L20.55/0208
	MB000080					MB871280	
208/208	Manual comm on IL(Sol)					---	
105	Manual Interlock(Sol)(35.09)						[MB871290] L20.55/0210
	MB000080					MB871290	
210/210	Manual comm on IL(Sol)					---	
106	Manual Interlock(Sol)(35.10)						[MB871300] L20.55/0212
	MB000080					MB871300	
212/212	Manual comm on IL(Sol)					---	
107	Manual Interlock(Sol)(35.11)						[MB871310] L20.55/0214
	MB000080					MB871310	
214/214	Manual comm on IL(Sol)					---	
108	Manual Interlock(Sol)(35.12)						[MB871320] L20.55/0216
	MB000080					MB871320	
216/216	Manual comm on IL(Sol)					---	
109	Manual Interlock(Sol)(35.13)						[MB871330] L20.55/0218
	MB000080					MB871330	
218/218	Manual comm on IL(Sol)					---	
110	Manual Interlock(Sol)(35.14)						[MB871340] L20.55/0220
	MB000080					MB871340	
220/220	Manual comm on IL(Sol)					---	
111	Manual Interlock(Sol)(35.15)						[MB871350] L20.55/0222
	MB000080					MB871350	
222/222	Manual comm on IL(Sol)					---	
112	Manual Interlock(Sol)(35.16)						[MB871360] L20.55/0224
	MB000080					MB871360	
224/224	Manual comm on IL(Sol)					---	

113 220/220	Manual Interlock(Sol)(35.17)						[MB871370] L20.55/0226
	MB000080					MB871370	
	Manual comm on IL(Sol)					---	
114 228/228	Manual Interlock(Sol)(35.18)						[MB871380] L20.55/0228
	MB000080					MB871380	
	Manual comm on IL(Sol)					---	
115 230/230	Manual Interlock(Sol)(35.19)						[MB871390] L20.55/0230
	MB000080					MB871390	
	Manual comm on IL(Sol)					---	
116 232/232	Manual Interlock(Sol)(35.20)						[MB871400] L20.55/0232
	MB000080					MB871400	
	Manual comm on IL(Sol)					---	
117 234/234	Manual Interlock(Sol)(35.21)						[MB871410] L20.55/0234
	MB000080					MB871410	
	Manual comm on IL(Sol)					---	
118 236/236	Manual Interlock(Sol)(35.22)						[MB871420] L20.55/0236
	MB000080					MB871420	
	Manual comm on IL(Sol)					---	
119 238/238	Manual Interlock(Sol)(35.23)						[MB871430] L20.55/0238
	MB000080					MB871430	
	Manual comm on IL(Sol)					---	
120 240/240	Manual Interlock(Sol)(35.24)						[MB871440] L20.55/0240
	MB000080					MB871440	
	Manual comm on IL(Sol)					---	
121 242/242	Manual Interlock(Sol)(35.25)						[MB871450] L20.55/0242
	MB000080					MB871450	
	Manual comm on IL(Sol)					---	
122 244/244	Manual Interlock(Sol)(35.26)						[MB871460] L20.55/0244
	MB000080					MB871460	
	Manual comm on IL(Sol)					---	
123 246/246	Manual Interlock(Sol)(35.27)						[MB871470] L20.55/0246
	MB000080					MB871470	
	Manual comm on IL(Sol)					---	
124 248/248	Manual Interlock(Sol)(35.28)						[MB871480] L20.55/0248
	MB000080					MB871480	
	Manual comm on IL(Sol)					---	
125 250/250	Manual Interlock(Sol)(35.29)						[MB871490] L20.55/0250
	MB000080					MB871490	
	Manual comm on IL(Sol)					---	
126 252/252	Manual Interlock(Sol)(35.30)						[MB871500] L20.55/0252
	MB000080					MB871500	
	Manual comm on IL(Sol)					---	
127 254/254	Manual Interlock(Sol)(35.31)						[MB871510] L20.55/0254
	MB000080					MB871510	
	Manual comm on IL(Sol)					---	
128 256/256	Cylinder Manual Interlock(Sol)(36.00)						[MB871520] L20.55/0256
	MB000080					MB871520	
	Manual comm on IL(Sol)					---	
129 258/258	Manual Interlock(Sol)(36.01)						[MB871530] L20.55/0258
	MB000080					MB871530	
	Manual comm on IL(Sol)					---	
130 260/260	Manual Interlock(Sol)(36.02)						[MB871540] L20.55/0260
	MB000080					MB871540	
	Manual comm on IL(Sol)					---	
131 262/262	Manual Interlock(Sol)(36.03)						[MB871550] L20.55/0262
	MB000080					MB871550	
	Manual comm on IL(Sol)					---	
132 264/264	Manual Interlock(Sol)(36.04)						[MB871560] L20.55/0264
	MB000080					MB871560	
	Manual comm on IL(Sol)					---	
133 266/266	Manual Interlock(Sol)(36.05)						[MB871570] L20.55/0266
	MB000080					MB871570	
	Manual comm on IL(Sol)					---	
134 268/268	Manual Interlock(Sol)(36.06)						[MB871580] L20.55/0268
	MB000080					MB871580	
	Manual comm on IL(Sol)					---	

Manual Interlock(Sol)(36.07)									
135	MB000080							MB871590	[MB871590] L20.55/0270
210/270	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.08)									
136	MB000080							MB871600	[MB871600] L20.55/0272
212/272	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.09)									
137	MB000080							MB871610	[MB871610] L20.55/0274
214/274	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.10)									
138	MB000080							MB871620	[MB871620] L20.55/0276
216/276	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.11)									
139	MB000080							MB871630	[MB871630] L20.55/0278
218/278	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.12)									
140	MB000080							MB871640	[MB871640] L20.55/0280
220/280	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.13)									
141	MB000080							MB871650	[MB871650] L20.55/0282
222/282	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.14)									
142	MB000080							MB871660	[MB871660] L20.55/0284
224/284	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.15)									
143	MB000080							MB871670	[MB871670] L20.55/0286
226/286	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.16)									
144	MB000080							MB871680	[MB871680] L20.55/0288
228/288	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.17)									
145	MB000080							MB871690	[MB871690] L20.55/0290
230/290	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.18)									
146	MB000080							MB871700	[MB871700] L20.55/0292
232/292	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.19)									
147	MB000080							MB871710	[MB871710] L20.55/0294
234/294	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.20)									
148	MB000080							MB871720	[MB871720] L20.55/0296
236/296	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.21)									
149	MB000080							MB871730	[MB871730] L20.55/0298
238/298	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.22)									
150	MB000080							MB871740	[MB871740] L20.55/0300
300/300	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.23)									
151	MB000080							MB871750	[MB871750] L20.55/0302
302/302	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.24)									
152	MB000080							MB871760	[MB871760] L20.55/0304
304/304	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.25)									
153	MB000080							MB871770	[MB871770] L20.55/0306
306/306	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.26)									
154	MB000080							MB871780	[MB871780] L20.55/0308
308/308	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.27)									
155	MB000080							MB871790	[MB871790] L20.55/0310
310/310	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.28)									
156	MB000080							MB871800	[MB871800] L20.55/0312
312/312	Manual comm on IL(Sol)							---	
Manual Interlock(Sol)(36.29)									
157	MB000080							MB871810	[MB871810] L20.55/0314
314/314	Manual comm on IL(Sol)							---	

	Manual Interlock(Sol)(36.30)						
158	MB000080					MB871820	[MB871820] L20.55/0316
316/316	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(36.31)						
159	MB000080					MB871830	[MB871830] L20.55/0318
318/318	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.00)						
160	MB000080					MB871840	[MB871840] L20.55/0320
320/320	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.01)						
161	MB000080					MB871850	[MB871850] L20.55/0322
322/322	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.02)						
162	MB000080					MB871860	[MB871860] L20.55/0324
324/324	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.03)						
163	MB000080					MB871870	[MB871870] L20.55/0326
326/326	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.04)						
164	MB000080					MB871880	[MB871880] L20.55/0328
328/328	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.05)						
165	MB000080					MB871890	[MB871890] L20.55/0330
330/330	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.06)						
166	MB000080					MB871900	[MB871900] L20.55/0332
332/332	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.07)						
167	MB000080					MB871910	[MB871910] L20.55/0334
334/334	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.08)						
168	MB000080					MB871920	[MB871920] L20.55/0336
336/336	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.09)						
169	MB000080					MB871930	[MB871930] L20.55/0338
338/338	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.10)						
170	MB000080					MB871940	[MB871940] L20.55/0340
340/340	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.11)						
171	MB000080					MB871950	[MB871950] L20.55/0342
342/342	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.12)						
172	MB000080					MB871960	[MB871960] L20.55/0344
344/344	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.13)						
173	MB000080					MB871970	[MB871970] L20.55/0346
346/346	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.14)						
174	MB000080					MB871980	[MB871980] L20.55/0348
348/348	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.15)						
175	MB000080					MB871990	[MB871990] L20.55/0350
350/350	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.16)						
176	MB000080					MB872000	[MB872000] L20.55/0352
352/352	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.17)						
177	MB000080					MB872010	[MB872010] L20.55/0354
354/354	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.18)						
178	MB000080					MB872020	[MB872020] L20.55/0356
356/356	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.19)						
179	MB000080					MB872030	[MB872030] L20.55/0358
358/358	Manual comm on IL(Sol)					---	
	Manual Interlock(Sol)(37.20)						
180	MB000080					MB872040	[MB872040] L20.55/0360
360/360	Manual comm on IL(Sol)					---	

