

aaa local authentication

To specify the method lists to use for local authentication and authorization from a Lightweight Directory Access Protocol (LDAP) server, use the **aaa local authentication** command in global configuration mode. To return to the default value, use the **no** form of this command.

aaa local authentication *{method-list-name | default}* **authorization** *{method-list-name | default}*
no aaa local authentication *{method-list-name | default}* **authorization** *{method-list-name | default}*

Syntax Description

<i>method-list-name</i>	Name of the AAA method list.
default	Uses the default AAA method list.

Command Default

Local LDAP-based authentication is disabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
15.3(1)S	This command was introduced.
15.3(1)T	This command was integrated into Cisco IOS Release 15.3(1)T.
Cisco IOS XE Release 3.2SE	This command was integrated into Cisco IOS XE Release 3.2SE.

Usage Guidelines

Use the **aaa local authentication** command to retrieve Extensible Authentication Protocol (EAP) credentials from local or remote LDAP servers.

The following example shows how to configure local authentication to use the method list named EAP_LIST:

```
aaa new-model
aaa local authentication EAP_LIST authorization EAP_LIST
```

Related Commands

aaa new-model	Enables the AAA access control model.
ldap server	Defines an LDAP server.

access-session closed

To prevent preauthentication access on a port, use the **access-session closed** command in interface configuration mode. To return to the default value, use the **no** form of this command.

access-session closed
no access-session closed

Syntax Description

This command has no arguments or keywords.

Command Default

Disabled (access is open on the port).

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 3.2SE	This command was introduced.

Usage Guidelines

The **access-session closed** command closes access to a port, preventing clients or devices from gaining network access before authentication is performed.

The following example shows how to set port 1/0/2 to closed access.

```
interface GigabitEthernet 1/0/2
 access-session host-mode single-host
 access-session closed
 access-session port-control auto
 access-session control-direction in
```

Related Commands

access-session control-direction	Sets the direction of authentication control on a port.
access-session host-mode	Allows hosts to gain access to a controlled port.
access-session port-control	Sets the authorization state of a port.

access-session host-mode

To allow hosts to gain access to a controlled port, use the **access-session host-mode** command in interface configuration mode. To return to the default value, use the **no** form of this command.

access-session host-mode {**multi-auth** | **multi-domain** | **multi-host** | **single-host**}
no access-session host-mode

Syntax Description	multi-auth	Specifies that multiple clients can be authenticated on the port at any given time. This is the default value.
	multi-domain	Specifies that only one client per domain (DATA or VOICE) can be authenticated at a time.
	multi-host	Specifies that after the first client is authenticated all subsequent clients are allowed access.
	single-host	Specifies that only one client can be authenticated on a port at any given time. A security violation occurs if more than one client is detected.

Command Default	Access to a port is multi-auth.
------------------------	---------------------------------

Command Modes	Interface configuration (config-if)
----------------------	-------------------------------------

Command History	Release	Modification
	Cisco IOS XE Release 3.2SE	This command was introduced.

Usage Guidelines	Before you use this command, you must enable the access-session port-control auto command.
	In multi-host mode, only one of the attached hosts has to be successfully authorized for all hosts to be granted network access. If the port becomes unauthorized (reauthentication fails or an Extensible Authentication Protocol over LAN (EAPOL) logoff message is received), all attached clients are denied access to the network.
	You can use the show access-session interface command to verify the port setting.

Example

The following example shows how to authenticate a single client at a time on port 1/0/2:

```
interface GigabitEthernet 1/0/2
 access-session host-mode single-host
 access-session closed
 access-session port-control auto
 access-session control-direction in
```

Related Commands	access-session closed	Prevents preauthentication access on a port.
	access-session control-direction	Sets the direction of authentication control on a port.
	access-session port-control	Sets the authorization state of a port.

show access-session	Displays information about authentication sessions.
----------------------------	---

guest-lan

To configure the wireless guest LAN, use the **guest-lan** command in global configuration mode. To remove the wireless guest LAN configuration, use the **no** form of this command.

guest-lan *profile-name* [*lan-id*]
no guest-lan *profile-name* [*lan-id*]

Syntax Description

<i>profile-name</i>	Specifies the wireless guest profile name.
<i>lan-id</i>	(Optional) Specifies the guest LAN identifier. The range is from 1 to 5.

Command Default

The wireless guest LAN is not configured.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Release 3.3SE	This command was introduced.

Usage Guidelines

Use the **guest-lan** command to specify a wireless guest profile. This wireless guest profile is used in the **tunnel type capwap** command to configure a CAPWAP tunnel within a service template and configure wired guest access for guest users of an enterprise network.

Example

The following example shows how to configure access to tunnel a VLAN :

```
Device# configure terminal
Device(config)# guest-lan guest-lan-name 1
```

Related Commands

tunnel type capwap	Configures a CAPWAP tunnel in a service template.
---------------------------	---