

2.1.2.97 tftp ipv6

Function

The **tftp ipv6** command uploads the local file to the TFTP server or download the file from the TFTP server to the local machine.

Format

tftp ipv6 [**-a** *source-ipv6-address*] *tftp-server-ipv6* [[**vpn-instance** *vpn-instance-name*] | **public-net**] [**-oi** { *interface-name* | *interface-type interface-number* }] { **get** | **put** } *source-filename* [*destination-filename*]

Parameters

Parameter	Description	Value
-a <i>source-ipv6-address</i>	Specifies the source IPv6 address of the local machine.	The value is a 32-digit hexadecimal number, in the format of X:X:X:X:X:X:X.
<i>tftp-server-ipv6</i>	Specifies the IPv6 address or host name for the IPv6 TFTP server. To view the mapping between the IPv6 address and host name, run the display dns dynamic-host or display ip host command.	The value is a string case-sensitive characters, spaces not supported.
vpn-instance <i>vpn-instance-name</i>	Specifies the VPN instance name for the TFTP server.	The value is a string of 1 to 31 case-sensitive characters, spaces not supported. In addition, the VPN instance name must not be _public_. When double quotation marks are used around the string, spaces are allowed in the string.
public-net	Indicates that the TFTP server on the public network is connected.	-
-oi <i>interface-type interface-number</i>	Specifies the source interface type and number.	-
get	Specifies the downloading files from the remote TFTP server.	-

Parameter	Description	Value
put	Specifies the uploading local files to the remote TFTP server.	-
<i>source-filename</i>	Specifies the source file name.	Source file name is string data type. The string length range is from 1 to 255 characters. It can contain alphanumeric and special characters.
<i>destination-filename</i>	Specifies the destination file name.	Destination file name is string data type. The string length range is from 1 to 255 characters. It can contain alphanumeric and special characters.

Views

User view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

Specify the valid source IP address to communicate with the server.

Configuration Impact

If you do not specify the destination file name, the source file name is considered as destination file name.

Precautions

This command can be used only after the weak security algorithm/protocol feature package (WEAKEA) has been installed using the **install feature-software WEAKEA** command.

Example

```
# Obtain data from the peer TFTP server.  
<HUAWEI> tftp ipv6 fe80::250:daff:fe91:e058 -oi 100GE 1/0/1 get filetoget filetoget
```