

clear ip pim snooping vlan



Note This command is not applicable on C9500X-28C8D model of Cisco Catalyst 9500 Series Switches

To delete the Protocol Independent Multicast (PIM) snooping entries on a specific VLAN, use the **clear ip pim snooping vlan** command in user EXEC or privileged EXEC mode.

clear ip pim snooping vlan *vlan-id* [**neighbor** | **statistics** | **mroute** [*source-ipgroup-ip*]]

Syntax Description	vlan <i>vlan-id</i>	VLAN ID. Valid values are from 1—4094.
	neighbor	Deletes all the neighbors.
	statistics	Deletes information about the VLAN statistics.
	mroute <i>group-addr src-addr</i>	Deletes the mroute entries in the specified group and the source IP address.

Command Default This command has no default settings.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Examples This example shows how to clear the IP PIM-snooping entries on a specific VLAN:

```
Router# clear ip pim snooping vlan 1001
```

Related Commands	Command	Description
	ip pim snooping	Enables PIM snooping globally.
	show ip pim snooping	Displays information about IP PIM snooping.