

KEENOVO SILICONE HEATER BED INSTALLATION INSTRUCTIONS

kenovo RTV instructions

Applying a Keenovo silicone heater pad to a metal bed using high-temperature RTV silicone requires carefully prepping the metal

1. Surface Preparation

- Clean thoroughly: Wipe down the aluminium or metal build plate with a degreasing solvent (like isopropyl alcohol or brake cleaner). Do *not* use acetone.
- Scuff the surface (Optional but recommended): Lightly scuff the mounting area with fine-grit sandpaper (around 400-600 grit) to improve the bond. Wipe clean again to remove any machining dust or debris.

2. Attaching the Heater

- Apply Pressure: Carefully place one edge down and slowly roll the rest of the pad onto the bed. Immediately apply heavy, even pressure across the entire surface using a Plastic Spatula or roller to push out any trapped air bubbles.

• 3. Applying RTV Silicone (Edge Sealing)

- Tape boundaries: Apply masking tape around the edges of the heater where you do *not* want the RTV silicone to spread.
- Apply RTV: Use a High-Temp RTV Silicone (like Loctite 5399 or a red automotive high-temp gasket maker). Smear a thin layer under the edges and apply a thick, continuous bead around the entire perimeter to seal it.
- Remove tape & weigh down: Carefully remove the masking tape while the silicone is still wet, then place an evenly distributed weight (like a flat piece of wood or cardboard topped with books) across the whole bed.
- Cure Time: Let the bed cure for the full manufacturer's recommended time (usually 48 hours) before turning on the heater.

4. APPLYING RTV SILICONE (EDGE SEALING)

Tape boundaries: Apply masking tape around the outer edges of the heater pad 6mm away .

Apply RTV: Smear high-temp RTV silicone under the edges and apply a continuous bead around the perimeter.

Cure Time: Place an evenly distributed weight on top and let it cure for a full 24 hours before powering on.