
Napa Hall IT Guide

- 1. Napa Hall Connections
- 2. Connecting Laptop to Projector via HDMI
- 3. Connecting Laptop to Projector via VGA
- 4. Connecting Laptop to Projector via ShareLink Pro (App)
- 7. Connecting Laptop to Projector via ShareLink Pro (Web Browser)
- 13. Handheld Microphone
- 14. Lapel Microphone



Napa Hall Connections

 Every Napa Hall Podium comes equipped with an Ethernet Cable, HDMI Cable and a VGA and Audio Cable.



Connecting Laptop to Projector Via HDMI

 Connect the **podiums** HDMI cable into the HDMI port on your **computer**.



2. Switch the source on the touchscreen to Laptop HDMI.



Connecting Laptop to Projector Via VGA

- Connect the **podiums** VGA cable into the VGA port on your computer.
- Connect the **podiums** Audio cable into the Audio port on your computer.



Switch the source on the touchscreen to Laptop VGA.



Connecting Laptop to ShareLink Pro (App)

1. Switch the source on the touchscreen to ShareLink.




2. You will see the **IP Address** at the bottom of the screen. **Need a better picture.**




Connecting Laptop to ShareLink Pro (App)

3. Open the ShareLink Pro app and click the Plus Sign.




4. Enter the IP Address and click Next




Connecting Laptop to ShareLink Pro (App)

5. Click the Plus Sign to start sharing your screen.



6. Select the **option** you want to share.




1. Switch the source on the touchscreen to ShareLink.



You will see the IP Address at the bottom of the screen.Need a better picture.




3. Open your internet browser and enter the **IP Address** in the **address bar** of your internet browser.




4. You will be redirected to this web page, click share.




5. If you get an **error** saying your **connection is not private.** Click advanced and proceed.




6. Enter your name and click **Connect**.




- 7. You will be given the option to share a **Chrome Tab**, a Window, or your Entire Screen.
- 8. Sharing a **Chrome Tab** allows you to pick any open **Chrome Tab** and display it on the projector.
- 9. Click **Share Tab Audio** to have sound play from the projector speakers.
- 10. Click **Share** to display the **Chrome Tab** on the projector.



- 11. You will be given the option to share a Chrome Tab, a **Window**, or your Entire Screen.
- 12. Sharing a **Window** allows you to pick any open **Window** and display it on the projector.
- 13. Click **Share** to display the **Window** on the projector.



- 14. You will be given the option to share a Chrome Tab, a Window, or your **Entire Screen**.
- 15. Sharing your **Entire Screen** allows you to display everything on your laptop screen to the projector.
- 16. Click **Share System Audio** to have sound play from the projector speakers.
- 17. Click **Share** to display the **Window** on the projector.



Handheld Microphone

- 1. Every Napa Hall Podium comes equipped with a **Handheld Microphone** and a Lapel Microphone.
- **2. Pull** the **Handheld Microphone** out of its dock.
- **3. Turn on** the handheld microphone by **moving** the power button up to the **"on" position**.



Lapel Microphone

- 1. Every Napa Hall Podium comes equipped with a Handheld Microphone and a **Lapel Microphone**.
- 2. Pull the Lapel Microphone out of its dock.
- **3. Turn on** the handheld microphone by **moving** the power button to the **right** to the **"on" position**.

