## Yamaha Station

## Setup & Strike, Troubleshooting Tips



**OVERVIEW:** The Yamaha CS 700 AV Video Sound Collaboration System is an all-in-one video conferencing system that features a sound bar with built-in speakers, microphone, and a wide-angle camera. It integrates with various streaming apps, including Zoom.



## Setting up the Yamaha Station



- Attach and assemble the Yamaha bar with the stand.
- 2 ) Plug in the USB connection from the Yamaha to the computer (i.e., PC, instructor's device).
- Plug in the power adapter into the wall outlet.
- Give it a few seconds to warm up and you will hear a chime.
- **5** ) Connect with the instructor on how they want the camera placed (i.e., facing instructor or facing students) and audio setup (i.e., Yamaha as a speaker source? Play speakers in the room? Switch between podium mic and Yamaha mic?)
- 6) If using a streaming app, configure audio and video settings to pick up video and/or audio from the Yamaha station, as desired by the instructor.



Striking the Yamaha Station: Reverse the above-listed steps and place the disassembled Yamaha station into a case provided by your designated co-pilot, and return it to them.



## **Troubleshooting with the Yamaha station**



**Basics:** Be sure to let the Yamaha station to warm up and load (could take up to 1 minute)

**Signal Flow:** Is the USB plugged into the right computer? Is the right source selected on the streaming app?

**Volume control:** Is the volume of the Yamaha muted on the video or audio?

**Streaming App:** Not Zoom? Look for camera and mic icons.

Need help? Connect with your designated co-pilot.



