TROUBLESHOOTING GUIDE

Keyboard typing wrong letters

KB Home > User Troubleshooting > Keyboard typing wrong letters

In Windows, make sure keyboard language is set to English (United States) - US Keyboard.

• The easiest way to do this is usually: look at the bottom-right corner of the Windows desktop, left-click where it says "ENG" (or something similar), and a list of options should come up.

The Numlock key might be on

- Ask them to look in the top-right section of the keyboard. Either on the number pad, or just to the left of it, do they see a key called "Numlock"?
- If yes, trying hitting that key and see if it turns a light on the keyboard off or on.
- Make sure that light on the keyboard is off, and see if that fixes the problem of the keyboard "typing the wrong letters."

Keywords: #keyboard #gibberish #messed #up #haunted #can't #type #password #numbers #won't #Canada #FR #CAFR #Canadian #French #language #login #log #in #fail

Keyboard wrong letters changelog

See all

+ New \vee \boxplus Edit in grid view extstyle extstyle

Title ∨	Date Updated: \lor	Updated by: ∨
Page created	12/27/2022	lan Swain