




0000 0
0001 1 - LOAD BYTE
0010 2 - SEND INIT BIT
0011 3 - SEND BYTE
0100 4 - SEND BYTE
0101 5 - SEND BYTE
0110 6 - SEND BYTE
0111 7 - SEND BYTE
1000 8 - SEND BYTE
1001 9 - SEND BYTE
1010 A - SEND BYTE
1011 B - SEND END BIT / SEQ_RST

0000 0
0001 1
0010 2
0011 3
0100 4
0101 5
0110 6
0111 7
1000 8
1001 9
1010 A
1011 B
1100 C
1101 D
1110 E
1111 F

CLR_SW 0000 0100 0x08
CR_SW 0000 1101 0x0D

CR_SW
CLR_SW
BIT_3
BIT_2
BIT_0
BIT_2

TITLE: 53S8 Hexadecimal Keypad		REV: 1.1
EasyEDA	Company: Rumidom	Sheet: 1/1
	Date: 2026-07-14	Drawn By: jr.robertocv