

0000 0
 0001 1 - LOAD BYTE
 0010 2 - SEND INIT BIT
 0011 3 - SEND DATA BIT 0
 0100 4 - SEND DATA BIT 1
 0101 5 - SEND DATA BIT 2
 0110 6 - SEND DATA BIT 3
 0111 7 - SEND DATA BIT 4
 1000 8 - SEND DATA BIT 5
 1001 9 - SEND DATA BIT 6
 1010 A - SEND DATA BIT 7
 1011 B - SEND END BIT
 1100 C - KEYPAD_RST

0000 0
 0001 1
 0010 2
 0011 3
 0100 4
 0101 5
 0110 6
 0111 7
 1000 8
 1001 9
 1010 A
 1011 B
 1100 C
 1101 D
 1110 E
 1111 F

CLR_SW 0000 0100 0x08
 CR_SW 0000 1101 0x0D

TITLE: 53S8 Hexadecimal Keypad		REV: 1.4
Company:	Sheet: 1/1	
	Date:	Drawn By: Rumidom