This file describes how to construct the Jet chassis using Actobotics

Chassis Frame

1. Locate the Actobotics component 'dual mount A' along with 4 6-32x1/4" screws.



Figure 1: dual mount a

2. Attach the 'dual mount A' into the end of a 12" Actobotics channel. The mount should sit flush with the end of the channel.




Figure 2: dual mount channel

3. Turn the channel on its side and attach the channel to another 12" channel. One channel should be open to the side and the other channel should be open downward.




Figure 3: dual mount channel1




Figure 4:

4. Repeat with another 12" channel to obtain a U-shaped structure. 2 of the channel pieces should be open to the center.




Figure 5:

5. Locate the quad pillow block along with 4 6-32x1/4" screws.



Figure 6:

6. Attach the quad pillow block to the center of a 12" channel. This quad pillow block will be the lower bearing for the caster wheels.




Figure 7:

7. Attach that the channel with the quad pillow block to the other 3 channel. This will complete the rectangular frame. The front of the robot will be the channel without the quad pillow block.




Figure 8:




Figure 9:

Motors

8. For the motors, you will need the 50:1 12 gearmotor and the $37\mathrm{mm}$ clamping motor mount.



Figure 10:

9. Secure the motor into the mount. Spin the motor in the mount so that the shaft is as close as possible to the flat part of the motor mount.




Figure 11:

Wheels

10. Attach hub adaptor D to the wheels.





11. Attach the clamping hub to the hub adaptor.



Figure 12:

12. Attach the motor shaft to the clamping hub. Repeat the steps for the second wheel and motor.



Figure 13:

Caster Wheel

10. Connect the 2 1/4" parallel tube clamps to the 1.5" channel as shown.




Figure 14:

11. Connect 8mm flanged standoff A to the 1.5" channel.



Figure 15:

12. Secure the 5" shaft to the parallel tube clamps. Also install the 1/4" shaft clamp collar on the 1/4" shafting. The lip edge of the clamp collar should face up.



Figure 16:

13. Install the skate wheels on to the standoffs.



Figure 17:

Final Assembly

14. Attach the motor mounts to the side channel of the frame.




Figure 18:

15. Attach the caster to the frame. Use a flanged bearing as the top bearing and secure the caster with a 1/4" shaft clamping collar.




Figure 19:




Figure 20:




Figure 21:

⊕⊕SThis work is licensed by Cal Poly San Luis Obispo and NVIDIA (2016) under a Creative Commons Attribution-NonCommercial 4.0 License.