

Interfaces of the R - Control IP 4

The device can be integrated into other systems in several ways. This page helps you choose — each interface has its own document with a quick start and examples.

Which interface do I need?

I want to ...	Use	Document
integrate the device into Home Assistant	MQTT	MQTT
connect a PLC or building management system	Modbus TCP	Modbus
switch and configure from my own software	HTTP/JSON API	REST
be notified when something happens	Webhook	Webhook
follow state changes in real time	WebSocket	WebSocket
keep an existing installation running	HTTP or UDP legacy	HTTP legacy · UDP legacy

When in doubt: For your own application the **HTTP/JSON API** is the right starting point. It can do everything the web interface can and needs no additional infrastructure.

At a glance

	Direction	You need	Can switch	Real time
HTTP/JSON API	you ask the device	nothing	yes	no (polling)
MQTT	both directions	a broker	yes	yes
Modbus TCP	you ask the device	Modbus master	yes	no (polling)
Webhook	device reports to you	a reachable URL	no	yes
WebSocket	both directions	WebSocket client	yes	yes
HTTP/UDP legacy	you ask the device	nothing	yes	no

The legacy interfaces exist for compatibility only and offer no modern protection. For new projects use one of the others.

Enabling

Except for the HTTP/JSON API and WebSocket (always available), all interfaces have to be enabled first:

Web interface → **Settings** → **Interfaces**

Each interface there also links to its manual.

Languages and formats

Every document is available as Markdown ([md/](#)) and PDF ([pdf/](#)), in German ([_DE](#)) and English ([_EN](#)).

Internal documents

Document	Content
REST – full version	Not for customers. All endpoints including production, provisioning, factory lock and NTC calibration

The customer edition of the REST documentation deliberately omits everything that is not needed in the field. When a shared endpoint changes, **update both documents**.