TINSPOL MOTORS

18608 BISHOP GAUL

EMAIL: tinspolent@gmail.com

CONTACT: 0242779099/0776556717

SERVICE MENU

A SERVICE [every 5 000kms]

Drive belts	-Inspect and adjust as required
Engine oil	-Replace
Engine oil filter	-Replace
Cooling system	-Check level and top up if required
Idle speed	-Check and adjust as required
Air filter	-Clean and inspect
Fuel filter, fuel lines and hoses	-Check for leaks
Battery electrolyte	-check level and top up if required
Brake fluid	-Check level and top up if required
Clutch fluid	-Check and top if required
Power steering fluid	-Check level and top up if required
LABOUR	2 HOURS

B SERVICE [EVERY 10 000KMs]

Drive Belts	-Inspect and adjust as required
Engine oil	-Replace
Engine oil filter	-Replace
Cooling system	-Check level and top up if required
Idle speed	-Check and adjust as required
Air filter	-Clean and inspect

Fuel filter/ Spark plugs	-replace
Fuel lines and hoses	-Check for leaks
Heater plugs	-Inspect and adjust as required
Battery electrolyte	-Check level and top up if required
Brake and clutch pedals required	-Check for free play and adjust if
Brake fluid	-Check level and top up if required
Clutch fluid	-Check level and top up if required
Parking Brake	-Inspect and adjust as required
<u>Disc brakes</u>	-Inspect
Drum brakes	-Inspect
Power steering lines and fluid	-Check level and top up if required
Gearbox oil level	-Check level and top up if required
LABOUR	-3HOURS

C SERVICE [EVERY 20 000KMs]

<u>Drive belts</u>	-Inspect and adjust as required
Engine oil	-Replace
Engine oil filter	-Replace
Cooling system	-check level and top up if required
Idle speed	-Check and adjust as required
Idle mixture (leaded fuel)	-Check and adjust as required
Air filter	-Replace
Fuel filter/ Spark plugs	-Replace
Ignition timing	-check and adjust as required
Spark plugs, heater plugs	-Inspect and adjust as required
Evaporated system (if fitted)	-Inspect

Battery electrolyte required	-Check level and top up if
Brake and clutch pedals required	-Check for free play and adjust if
Brake lines, hoses and connectors	-Inspect for condition and leaks
Brake fluid required	-Check level and top up if
Clutch fluid required	-Check level and top up if
Parking brake	-Inspect and adjust as required
Disc brakes	-Inspect
Drum brakes	-Inspect
Power brake unit and hoses	-Inspect for condition and leaks
Power steering fluids and lines	-Inspect for condition and leaks
Steering operations and gear housing	-Inspect
Steering linkages, racking guides and tire rod ends	-Inspect
Gear box oil level	-Check level and top up if
<u>required</u>	
Bolts and nuts on chassis and body	-Tighten
LABOUR	-4HOURS