





Arduino Interface



I2C Pull-up resistors



Expansion Board Headers





RAB-nRF54LM20
Rev1

QR
CODE



RUTRONIK
SOLUTIONS



RoHS



P1

R1 SB23
R2 SB24
SB13
SB15

SCL

SDA

VDD

GND

SCK

MISO

MOSI

CS

ARD0

ARD1

SB18

SB21

SB19

SB22

SB1

SB7

P5

ARD2

ARD3

ARD4

ARD5

ARD6

ARD7

TX

RX

SB11

SB17

SB2

SB6

SB8

SB12

SB9

SB10

P3

VDD

VDD

5V

GND

GND

GND

GND

GND

P4

A7

ARD8

ARD9

A4

A5

A6

SB4

SB16

SB20

SB14

SB3

SB5

