

Prof. N. B. Kanirkar Associate Professor, ECED, SVNIT.





DIGITAL COMMUNICATION

- Prof. N. B. Kanirkar



Introduction of Electronic Communication

What is Electronic Communication?

"The systems and processes that are used to convey information from a source to a destination efficiently and reliably, especially by means of electricity or radio waves."







Milestones in the history of electronic communication.

When?	Where or Who?	What?	
1837	Samuel Morse	Invention of the telegraph (patented in 1844).	
1843	Alexander Bain	Invention of facsimile.	
1866	United States and England	The first transatlantic telegraph cable laid.	
1876	Alexander Bell	Invention of the telephone.	
1877	Thomas Edison	Invention of the phonograph.	
1879	George Eastman	Invention of photography.	
1887	Heinrich Hertz (German)	Discovery of radio waves.	
1887	Guglielmo Marconi (Italian)	Demonstration of "wireless" communications by radio waves.	
1901	Marconi (Italian)	First transatlantic radio contact made.	
1903	John Fleming	Invention of the two-electrode vacuum tube rectifier.	
1906	Reginald Fessenden	Invention of amplitude modulation; first electronic voice communication demonstrated.	
1906	Lee de Forest	Invention of the triode vacuum tube.	
1914	Hiram P. Maxim	Founding of American Radio Relay League, the first amateur radio organization.	
1920	KDKA Pittsburgh	First radio broadcast.	
1923	Vladimir Zworykin	Invention and demonstration of television.	
1933–1939	Edwin Armstrong	Invention of the superheterodyne receiver and frequency modulation.	





Milestones in the history of electronic communication.

1939	United States	First use of two-way radio (walkie talkies)	
	And the second of the second o	First use of two-way radio (walkie-talkies).	
1940–1945	Britain, United	Invention and perfection of radar	
	States	(World War II).	
1948	John von Neumann	Creation of the first stored program	
All and the	and others	electronic digital computer.	
1948	Bell Laboratories	Invention of transistor.	
1953	RCA/NBC	First color TV broadcast.	
1958-1959	Jack Kilby (Texas	Invention of integrated circuits.	
	Instruments) and		
	Robert Noyce		
	(Fairchild)		
1958-1962	United States	First communication satellite tested.	
1961	United States	Citizens band radio first used.	
1973–1976	Metcalfe	Ethernet and first LANs.	
1975	United States	First personal computers.	
1977	United States	First use of fiber-optic cable.	
1982	United States	TCP/IP protocol adopted.	
1982-1990	United States	Internet development and first use.	
1983	United States	Cellular telephone networks.	
1993	United States	First browser Mosaic.	
1995	United States	Global Positioning System deployed.	
1996-2001	Worldwide	First smartphones by BlackBerry, Nokia, Palm.	
1997	United States	First wireless LANs.	
2000	Worldwide	Third-generation digital cell phones.	
2009	Worldwide	First fourth-generation LTE cellular networks.	
2009	Worldwide	First 100 Gb/s fiber optical networks.	
2003	Worldwide	i iist 100 db/s liber optical lietworks.	





Harry Nyquist (1928)



"Certain topics in telegraph transmission theory", Trans. AIEE, vol. 47, pp. 617–644, Apr. 1928

Sampling Theorem

Continuous-time Discrete-time



Historical Review

- 1838: telegraph (S. Morse)
- 1876: telephone (A. Bell)
- □ 1895: radio by Marconi
- 1901: trans-atlantic communication




Nobel Prize for Physics (1909)

- Early 20th century:
 - Most communication systems are analog.
 - Engineering designs are ad-hoc, tailored for each specific application



Claude Shannon (1948)



"A Mathematical Theory of Communication", Bell System Technical Journal. 1948

Information Theory

Fundamental limits of source compression rate and channel transmission rate

Analog communication




Digital communication





Frequency Spectrum





Frequency Spectrum

Radio Frequency Spectrum: Ranges

Designation	Abbreviation	Frequencies	Wavelengths
Very Low Frequency	VLF	3 kHz - 30 kHz	100 km - 10 km
Low Frequency	LF	30 kHz - 300 kHz	10 km - 1 km
Medium Frequency	MF	300 kHz - 3 MHz	1 km - 100 m
High Frequency	HF	3 MHz - 30 MHz	100 m - 10 m
Very High Frequency	VHF	30 MHz - 300 MHz	10 m - 1 m
Ultra High Frequency	UHF	300 MHz - 3 GHz	1 m - 100 mm
Super High Frequency	SHF	3 GHz - 30 GHz	100 mm - 10 mm
Extremely High Frequency	EHF	30 GHz - 300 GHz	10 mm - 1 mm

	Frequency	Common Uses	
VLF	3-30 kHz	underwater communications	
LF	30-300 kHz	00 kHz AM radio	
MF	300-3000 kHz	AM radio	
		AM radio, long distance aviation	
HF	3-30 MHz	communications	
		FM radio, television, short range avaiation	
VHF	30-300 MHz	communications, weather radio	
		television, mobile phones, wireless	
UHF	300-3000 MHz	networks, Bluetooth, satellite radio, GPS	
		satellite television and radio, radar	
SHF	3-30 GHz	systems, radio astronomy	
EHF	30-300 GHz radio astronomy, full body scanners		





Radio Spectrum



EVOLVING MOBILE TECHNOLOGY

- 1G: Short for first generation wireless telephone technology. Mobile phone was first launched in the 1980s in this technology. Radio signals on 1G networks were analog, where information is transmitted by modulating a continuous signal, like sound waves. Used frequency band 824-894 MHz
- 2G: Short for second generation wireless telephone technology. Mobile phone in India was launched based on this technology. Radio signals on 2G networks are digital. It allows data services for mobile phones, including text messages and downloading of ringtones. Uses 1800 MHz band
- 3G: Short for third-generation wireless telephone technology. It supports services like mobile TV and high-resolution video. Uses 2.1 GHz band

WAYS TO FULFILL DEMAND Telecom industry is looking towards new sources, including: 108 MHz from the broadcasting frequency of 700 MHz band Available GSM ■ 100 MHz from 2.3-2.4 GHz band spectrum in India is 25 ■ 190 MHz from 2.5 -2.69 GHz Available CDMA MHz in 900 MHz band 200 MHz from 3.4-3.6 GHz band spectrum in India is 20 and 75 MHz in 1800 S band spectrum 2G uses MHz in 800 MHz band 2-4 GHz MHz band 1800 MHz band 1 GHz 3G uses 400 GHZ 2100 MHz GHz 5 GHz 50 GHz 9 kHz band 500 MHz 2 GHz Weather Signals sent in radar this zone can Wi-Fi Cell phones AM radio GPS only be short Satellite radio networks 535 - 1700 kHz Semi-permeable zone Permeable zone toll tags Frequencies in this zone Frequencies in this zone are considered do not penetrate PLine-of-sight zone valuable because they can penetrate through dense objects through dense objects like buildings Frequencies in this easily zone travel long distances but are easily blocked Highest Lowest Microwaves Infrared Light Ultraviolet Gamma rays frequencies frequencies RADIO WAVE SPECTRUM Distance from 400 GHz 9 kHz crest to crest High frequency wavelength wavelength

frequency

BANDS AVAILABLE FOR MOBILE PHONE SERVICES

2100 band (2.1 GHz) = 1920-1980 MHz/2110-2170 MHz

800 band = 824-844/869-889 MHz

900 band = 890-915 MHz/935-960 MHz

1800 band = 1710-1785/1805-1880 MHz

Wavelength



MEASURE OF FREQUENCY

Frequency is number of waves per

second. It is measured in hertz.

1 kilohertz (kHz) = 1000 hertz


1 gigahertz (GHz) = 1000 MHz

1 megahertz (MHz) = 1000 kHz

1 hertz = waves per second



Basic Communication










General Model of all Communication Systems




A general model of all communication systems.





Extended Block Diagram








Basic Elements of a Communication System

Basic Elements of a Communication System

- Free space
- Wireline
- Twisted Pair
- Coaxial Cable
- Optical Fiber etc.



Nonlinearity

Interference

Noise


Multiplexing or Shared usages








Block Diagram of Complex Comm. System







Basic View of Communication System







Transmitter

The first step in sending a message is to convert it into electronic form suitable for transmission. For voice messages, a microphone is used to translate the sound into an electronic *audio* signal. For TV, a camera converts the light information in the scene to a video signal. In computer systems, the message is typed on a keyboard and converted to binary codes that can be stored in memory or transmitted serially. Transducers convert physical characteristics (temperature, pressure, light intensity, and so on) into electrical signals.

The *transmitter* itself is a collection of electronic components and circuits designed to convert the electrical signal to a signal suitable for transmission over a given communication medium. Transmitters are made up of oscillators, amplifiers, tuned circuits and filters, modulators, frequency mixers, frequency synthesizers, and other circuits. The original intelligence signal usually modulates a higher-frequency carrier sine wave generated by the transmitter, and the combination is raised in amplitude by power amplifiers, resulting in a signal that is compatible with the selected transmission medium.





Communication Channel

Communication Channel

The *communication channel* is the medium by which the electronic signal is sent from one place to another. Many different types of media are used in communication systems, including wire conductors, fiber-optic cable, and free space.

Electrical Conductors. In its simplest form, the medium may simply be a pair of wires that carry a voice signal from a microphone to a headset. It may be a coaxial cable such as that used to carry cable TV signals. Or it may be a twisted-pair cable used in a local-area network (LAN).

Optical Media. The communication medium may also be a fiber-optic cable or "light pipe" that carries the message on a light wave. These are widely used today to carry long-distance calls and all Internet communications. The information is converted to digital form that can be used to turn a laser diode off and on at high speeds. Alternatively, audio or video analog signals can be used to vary the amplitude of the light.

Free Space. When free space is the medium, the resulting system is known as radio. Also known *as wireless, radio* is the broad general term applied to any form of wireless communication from one point to another. Radio makes use of the electromagnetic spectrum. Intelligence signals are converted to electric and magnetic fields that propagate nearly instantaneously through space over long distances. Communication by visible or infrared light also occurs in free space.





Receivers & Transceivers

Receivers

A receiver is a collection of electronic components and circuits that accepts the transmitted message from the channel and converts it back to a form understandable by humans. Receivers contain amplifiers, oscillators, mixers, tuned circuits and filters, and a demodulator or detector that recovers the original intelligence signal from the modulated carrier. The output is the original signal, which is then read out or displayed. It may be a voice signal sent to a speaker, a video signal that is fed to an LCD screen for display, or binary data that is received by a computer and then printed out or displayed on a video monitor.

Transceivers

Most electronic communication is two-way, and so both parties must have both a transmitter and a receiver. As a result, most communication equipment incorporates circuits that both send and receive. These units are commonly referred to as *transceivers*. All the transmitter and receiver circuits are packaged within a single housing and usually share some common circuits such as the power supply. Telephones, handheld radios, cellular telephones, and computer modems are examples of transceivers.





Attenuation & Noise

Attenuation

Signal *attenuation*, or degradation, is inevitable no matter what the medium of transmission. Attenuation is proportional to the square of the distance between the transmitter and receiver. Media are also frequency-selective, in that a given medium will act as a low-pass filter to a transmitted signal, distorting digital pulses in addition to greatly reducing signal amplitude over long distances. Thus considerable signal amplification, in both the transmitter and the receiver, is required for successful transmission. Any medium also slows signal propagation to a speed slower than the speed of light.


Noise

Noise is mentioned here because it is the bane of all electronic communications. Its effect is experienced in the receiver part of any communications system. For that reason, we cover noise at that more appropriate time in Chapter . While some noise can be filtered out, the general way to minimize noise is to use components that contribute less noise and to lower their temperatures. The measure of noise is usually expressed in terms of the signal-to-noise (S/N) ratio (SNR), which is the signal power divided by the noise power and can be stated numerically or in terms of decibels (dB). Obviously, a very high SNR is preferred for best performance.






Types of Electronic Communication




Simplex communication.








Types of Electronic Communication



Duplex communication

- (a) Full duplex (simultaneous two-way).
- (b) Half duplex (one way at a time).







Types of Electronic Communication

Simplex

The simplest way in which electronic communication is conducted is one-way communications, normally referred to as *simplex communication*. Examples are shown in Fig. The most common forms of simplex communication are radio and TV broadcasting. Another example of one-way communication is transmission to a remotely controlled vehicle like a toy car or an unmanned aerial vehicle (UAV or drone).

Full Duplex

The bulk of electronic communication is two-way, or *duplex communication*. Typical duplex applications are shown in Fig. For example, people communicating with one another over the telephone can talk and listen simultaneously, as Fig. +(a) illustrates. This is called *full duplex communication*.

Half Duplex

The form of two-way communication in which only one party transmits at a time is known as half duplex communication [see Fig. +(b)]. The communication is two-way, but the direction alternates: the communicating parties take turns transmitting and receiving. Most radio transmissions, such as those used in the military, fire, police, aircraft, marine, and other services, are half duplex communication. Citizens band (CB), Family Radio, and amateur radio communication are also half duplex.











