

TWO-TONE DESK SHELF

A small two-colour wood organizer for desk or counter





PLEASE READ BEFORE YOU START

Read every step before you begin. Lay all panels and hardware out on the floor.

All wooden panels are two-tone (■■). Match the colour blocks as shown on the diagram.

Work on a flat, stable surface. Protect the panels with a blanket or cardboard.


Two people make the job easier and safer, especially when standing the unit up.

Keep this manual and any spare screws with the product for future adjustments.

WHAT'S IN THE BOX

Parts & hardware

Match every number and letter to the diagram before you start



PANELS & PARTS (1–14)

1	Panel 1	× 1	8	Side panel	× 2
2	Panel 2	× 1	9	Side panel	× 2
3	Panel 3	× 1	10	Top / base panel	× 2
4	Panel 4	× 1	11	Connector fitting	× 1
5	Shelf board	× 2	12	Connector fitting	× 1
6	Two-tone panel	× 2	13	Connector fitting	× 1
7	Two-tone panel	× 2	14	Back panel	× 2


HARDWARE & TOOLS (A–J)

A	Cam lock (×4)	F	Bolt (×6)
B	Wood screw (×14)	G	Screwdriver (tool)
C	Wooden dowel Ø 6 × 30	H	Set screw (×2)
D	Self-tapping screw (×	I	Wood screw (×4)
E	Long screw (×6)	J	Connector screw (×6)

STEP 1 OF 10

Prepare Panel 1

Get your starting panel ready



YOU WILL NEED

You will need: 1×1

1. Take Panel 1 and lay it flat on the protected surface.
2. Check that its pre-drilled holes face up and are clear of dust.
3. Keep the other panels nearby in the order they will be used.

TIP

Lay panels on a blanket so the two-tone surfaces are not scratched.

CHECK

Panel 1 is clean, flat and within easy reach.


NEXT

Step 2 — Build the basic frame

STEP 2 OF 10

Build the basic frame

Join panels 1–5



YOU WILL NEED

You will need: 1×1 · 2×1 · 3×1 · 4×1 · 5×2 · J×6

1. Bring Panels 1, 2, 3, 4 and the two Shelf boards (5) together.
2. Use 6 × J connector screws to join them into the basic frame.
3. Start each screw by hand, then tighten with the screwdriver (G).
4. Keep the frame square before the screws are fully tight.

TIP

Tighten screws only finger-tight first, then go round again to square it up.

CHECK

The frame stands square with no twisted panels.


NEXT

Step 3 — Fit Panels 8 and 9

STEP 3 OF 10

Fit Panels 8 and 9

Add the side panels with cam locks



YOU WILL NEED

You will need: 8×2 · 9×2 · A×4

1. Position Side panels 8 and 9 against the frame.
2. Insert 4 × A cam locks into their holes.
3. Turn each cam lock with the screwdriver until it locks the panel in place.

TIP

Cam locks click when seated – do not force them past the stop.

CHECK

Side panels 8 and 9 are flush and locked.


NEXT

Step 4 — Dowel Panels 1, 3, 8, 9 and 10

STEP 4 OF 10

Dowel Panels 1, 3, 8, 9 and 10

Align with dowels



YOU WILL NEED

You will need: 1×1 · 3×1 · 8×2 · 9×2 · 10×2 · C×4

1. Line up Panels 1, 3, 8, 9 and the two Top/base panels (10).
2. Push 4 × C Ø 6×30 dowels into the matching holes.
3. Tap gently so the panels sit flush against each other.

TIP

If a dowel will not seat, reverse and re-align – never hammer it in.

CHECK

Joints are flush; no panel is proud of its neighbour.


NEXT

Step 5 — Secure Panels 1 and 3

STEP 5 OF 10

Secure Panels 1 and 3

Screw the structure tight



YOU WILL NEED

You will need: 1×1 · 3×1 · B×6 · E×6 · F×6

1. Align Panels 1 and 3 and hold them together.
2. Drive 6 × B wood screws, 6 × E long screws and 6 × F bolts.
3. Tighten evenly so the structure does not rack.

TIP

Work diagonally across the joint for an even, square result.

CHECK

Panels 1 and 3 are rigid with no movement.


NEXT

Step 6 — Fit Panel 14

STEP 6 OF 10

Fit Panel 14

Attach the back panel



YOU WILL NEED

You will need: 14×2 · D×4

1. Place the Back panel (14) in position.
2. Fix it with 4 × D self-tapping screws.
3. Make sure it sits flat against the frame.

TIP

Back panels add most of the unit's rigidity – keep them square.

CHECK

Back panel 14 is flush and firmly fixed.


NEXT

Step 7 — Fit Panel 10 to 14

STEP 7 OF 10

Fit Panel 10 to 14

Close the top / base



YOU WILL NEED

You will need: 10×2 · 14×2 · D×4

1. Bring the Top/base panel (10) to the Back panel (14).
2. Secure with 4 × D self-tapping screws.
3. Confirm the unit is level before continuing.

TIP

Rest the unit on a level surface to check it does not rock.

CHECK

Top/base panel is level and secure.


NEXT

Step 8 — Install Fittings 11, 12, 13

STEP 8 OF 10

Install Fittings 11, 12, 13

Add the connector fittings



YOU WILL NEED

You will need: 11×1 · 12×1 · 13×1 · I×4

1. Position fittings 11, 12 and 13 where the drawing shows.
2. Fix them with 4 × I wood screws.
3. Seat each fitting fully before tightening.

TIP

Loose fittings rattle later – snug them up now.

CHECK

Fittings 11–13 are fixed and do not move.


NEXT

Step 9 — Reinforce Fittings

STEP 9 OF 10

Reinforce Fittings

Dowel the fittings



YOU WILL NEED

You will need: 11×1 · 12×1 · 13×1 · C×6

1. Reinforce fittings 11, 12 and 13 with 6 × C Ø 6×30 dowels.
2. Push each dowel home so the fitting is locked.
3. Check the fit is tight and even.

TIP

Dowels here stop the fittings from twisting under load.

CHECK

Fittings are locked with dowels, no play.


NEXT

Step 10 — Fit Two-Tone Panels 6 and 7

STEP 10 OF 10

Fit Two-Tone Panels 6 and 7

Finish the colour-block face



YOU WILL NEED

You will need: 6×2 · 7×2 · B×2 · C×2 · D×2 · H×2

1. Place the two-tone Panels 6 and 7 as shown.
2. Secure them with B, C, D and H fasteners per the drawing.
3. Line the colour blocks up so the two-tone face reads cleanly.

TIP

Step back and check the colour blocks align before the final tighten.

CHECK

Two-tone panels 6 and 7 are aligned and fixed; unit complete.

NEXT

Finishing touches and care (page 12)

AFTER ASSEMBLY

Care, checks and safe use

A few minutes of care keeps the shelf solid and safe

CARE AND MAINTENANCE

Max load
Do not load above the rated weight. Spread weight evenly across the shelves.

Placement
Stand the shelf on a flat, level desk, well away from the front edge.

Stability
Re-tighten all screws after the first week and every few months.

Cleaning
Wipe with a soft, slightly damp cloth. Do not use harsh chemicals or soak.

Surface

SAFETY WARNINGS

- Never let the shelf overhang the edge of the desk.
- Do not climb on or stand the shelf on its side as a step.
- Keep the unit away from heat sources and direct sunlight.
- Inspect screws and fittings regularly; tighten if loose.
- Keep small fittings away from young children during assembly.

USING YOUR SHELF

- Place the shelf where you will use it before loading it.
- Load the heavier items on the lower shelves for stability.
- Adjust the feet / level so it does not rock.
- Keep the screwdriver handy for periodic re-tightening.

NEED HELP?

If a part is missing or damaged, or if a step is unclear, contact us before returning the shelf. Quote the model name and the part number or hardware letter from this manual.

Seller contact _____

Order no. _____

Model **Two-Tone Desk Shelf · Small**