

Memory

CS1021 – Introduction to Computing I


Dr Jonathan Dukes | jdukes@tcd.ie School of Computer Science and Statistics A processing unit or processor which performs operations on data

Memory, which stores:

Data: representing text, images, videos, sensor readings, π , audio, etc. ...

Instructions: Programs are composed of sequences of instructions that control the actions of the processing unit

So far, all of our data has been stored in registers, internal to the Processing Unit ("processor" or "CPU")




Design and write an assembly language program to convert a string stored in memory to UPPER CASE

String – sequence of ASCII characters stored in consecutive memory locations

"hello"

```
char = first character in string
while (char not past end of string)
{
    if (char ≥ 'a' AND char ≤ 'z')
    {
        char = char - 0x20
    }
    char = next character
}
```




ARM7TDMI is based on a "Load – Store Architecture"

Cannot directly perform operations (e.g. addition, subtraction, comparison, ...) on values in memory

Only way to operate on a value stored in memory is to load it into a register, then operate on the register

Only way to change a value in memory is to store the value from a register into memory



```
char = first character in string
while (char not past end of string)
{
    if (char ≥ 'a' AND char ≤ 'z')
    {
        char = char - 0x20
    }
    char = next character
}
```

```
address = address of first character
char = Memory.byte[address]

while (char not past end of string)
{
    if (char ≥ 'a' AND char ≤ 'z')
    {
        char = char - 0x20
        Memory.byte[address] = char
    }

    address = address + 1
    char = Memory.byte[address]
}
```

char = Memory.byte[address]


refine

Load the byte-size contents of memory at address address into the variable char

My pseudo-code notation ... you are free to use your own! How do we know when we have reached the end of the string?

NULL terminated strings use the code 0 (ASCII NULL character code) to denote the end of a string

```
address = address of first character
char = Memory.byte[address]
while (char \neq 0)
       if (char ≥ 'a' AND char ≤ 'z')
             char = char - 0x20
             Memory.byte[address] = char
       address = address + 1
       char = Memory.byte[address]
```



```
LDR r1, =0xA1000138
                            ; address = 0xA1000138
      LDRB r0, [r1]
                            ; char = Memory.byte[address]
     CMP r0, #0
                            ; while ( char != 0 )
whStr
      BEQ eWhStr
                            ; if (char >= 'a'
      CMP r0, #'a'
      BLO endifLC
                              AND
                            ; char <= 'z')
      CMP r0, #'z'
      BHI endifLC
      SUB r0, r0, #0x20
                            ; char = char - 0x20
      STRB r0, [r1]
                             ; Memory.byte[address] = char
endifLC
      ADD r1, r1, #1
                            ; address++;
      LDRB r0, [r1]
                            ; char = Memory.byte[address]
          whStr
eWhStr
```

```
LDR r1, =0xA1000138 ; address = 0xA1000138
whStr LDRB r0, [r1]
                        ; while ( (char = Memory.byte[address])
                         ! = 0 )
     CMP r0, #0
     BEQ eWhStr
     CMP r0, #'a'
                        ; if (char >= 'a'
     BLO endifLC
                         AND
                        ; char <= 'z')
     CMP r0, #'z'
     BHI endifLC
                        ; char = char - 0x20
     SUB r0, r0, #0x20
                        ; Memory.byte[address] = char
     STRB r0, [r1]
endifLC
     ADD r1, r1, #1
                        ; address++;
     B whStr
eWhStr
```

Load a word-, half-word- or byte-size value from a specified address into a register

```
LDR load word
```

LDRH load half-word

LDRB load byte

Store a word-, half-word- or byte-size value from a register into memory at a specified address

STR store word

STRH store half-word

STRB store byte

Design and write an assembly language program that will calculate the sum of 10 word-size values stored in memory

```
address = address of first word-size value
sum = 0
count = 0;
while (count < 10)
     sum = sum + Memory.word[address]
     address = address + 4
     count = count + 1
```

```
start
      LDR R1, =testdata
                               ; address = address of first word-wize value
           R0, =0
      LDR
                               ; sum = 0
           R4 = 0
                               ; count = 0
      LDR
                               ; while (count < 10)
whSum
           R4, #10
      CMP
            eWhSum
      BHS
           R5, [R1]
                               ; num = Memory.byte[address]
      LDR
           R0, R0, R5 ; sum = sum + num
      ADD
           R1, R1, #4 ; address = address + 4
      ADD
           R4, R4, #1; count = count + 1
      ADD
           whSum
      В
eWhSum
stop
            stop
      TestData, DATA, READWRITE
AREA
       ; sequence of 10 word-size values
testdata
      DCD
            56,23,407,298,4,75,84,37,92,43
```

Use the assembler to initialise contents of memory

Example: instead of manually writing a test string into memory, the string can be included with program machine code by the assembler

```
AREA UpperCaseString, CODE, READONLY
        IMPORT main
        EXPORT start
start
              r1, =teststr
                                       ; address = teststr
        LDR
        <rest of program>
                                       • • •
               TestData, DATA, READWRITE
               "hello",0
                                       ; NULL terminated test string
teststr DCB
        END
```

DCD, DCW and DCB are assembler directives. They are not instructions and no machine code is produced.

Other data declaration examples:

8 word-size values

```
mywords

DCD 0x4D1F4004, 0x10301030, 0x141030D4, 0xE4503003

DCD 0x4AB345F0, 0x3049FDEA, 0x0400D4F8, 0x34FD303A
```

Lotto numbers as byte values

```
draw DCB 32, 43, 10, 11, 14, 15
bonus DCB 7
```

2 half-word values

values DCW	407, -208	
------------	-----------	--

AREA directive

Marks the beginning of a section and specifies attributes for the section

Sections are indivisible sequences of instructions and/or data

Attribute examples: CODE, READONLY, DATA, READWRITE

Attributes define how a section is loaded into memory

Programs must contain at least one CODE section


END directive

Tells the assembler to stop processing the source file

IMPORT / EXPORT directives

EXPORT directive exports labels for use by other assemblies

IMPORT directive allows one assembly to use a label exported by another assembly



Byte, half-word and word at address 0xA0000D8

LDR r0, =0xA00000D8


LDRB r1, [r0]

LDR r0, =0xA00000D8

LDRH r1, [r0]

LDR r0, =0xA00000D8

LDR r1, [r0]



ARM7TDMI expects all memory accesses to be aligned

Examples:

Address Examples

Word aligned	0x0000000, 0x00001008, 0xA100000C
Not word aligned	0x0000001, 0x00001006, 0xA100000F
Half-word aligned	0x0000000, 0x00001002, 0xA100000A
Not half-word aligned	0x0000003, 0x00001001, 0xA100000B


See ARM Architecture Reference Manual Section A2.8

Unaligned accesses are permitted but the result is unlikely to be what was intended


Unaligned accesses are supported by later ARM architecture versions


Little-endian byte ordering – least-significant byte of word or half-word stored at lower address in memory

Big-endian byte ordering – most-significant byte of word or half-word stored at lower address in memory



Sign extension performed when loading signed bytes or half-words to facilitate correct subsequent 32-bit signed arithmetic





Design and write an ARM Assembly Language program to compare two strings stored in memory. The program should store in R0 ...

- == 0 if the strings are the same
- < 0 if the first non-matching character in the first string precedes the corresponding character in the second string
- > 0 if the first non-matching character in the first string succeeds the corresponding character in the second string

Suggested approach

Consider some examples to explore the problem

Develop with a pseudo-code solution

Translate the pseudo-code solution to ARM Assembly Language

Pseudo-code solution

```
ch1 = Memory.byte[adr1];
ch2 = Memory.byte[adr2];
while (ch1 != 0 \&\& ch1 == ch2)
  adr1++;
  adr2++;
  ch1 = Memory.byte[adr1];
  ch2 = Memory.byte[adr2];
result = ch1 - ch2;
```

```
start
           R4, =str1
                                 ; adr1 = start address of str1
       LDR
            R5, = str2
                                 ; adr2 = start address of str2
       LDR
            R6, [R4]
                                 ; ch1 = Memory.byte[adr1]
       LDRB
       LDRB
            R7, [R5]
                                 ; ch2 = Memory.byte[adr2]
            R6, #0
                                 ; while (ch1 != NULL
whCmp
       CMP
            ewhCmp
       BEQ
                                         & &
                                         ch1 != ch2)
       CMP
            R6, R7
            ewhCmp
       BNE
            R4, R4, #1
                                 ; adr1++
       ADD
            R5, R5, #1
       ADD
                                 ; adr2++
            R6, [R4]
                                 ; ch1 = Memory.byte[adr1]
       LDRB
                                 ; ch2 = Memory.byte[adr2]
       LDRB
            R7, [R5]
            whCmp
ewhCmp
            R0, R6, R7 ; result = ch1 - ch2
       SUB
       В
stop
            stop
       AREA
            Strings, DATA, READWRITE
       DCB
             "Beets",0
str1
             "Bests",0
       DCB
str2
```

Design and write an ARM Assembly Language program to determine if a set, A, is a subset of another set, B. Sets A and B are stored in memory as unordered sequences of unique word-size values, along with the size of each set.

```
AREA Sets, DATA, READWRITE

Asize DCD 3
Aelems DCD 6, 10, 8
Bsize DCD 8
Belems DCD 3, 14, 8, 6, 7, 10, 12, 14
```