AIRCRAFT MAINTENANCE MANUAL

HIGHLIGHTS

REVISION NO. 75 Jun 01/15

Pages which have been revised are outlined below, together with the Highlights of the Revision $\boldsymbol{\theta}$

CH/SE/SU C	REASON FOR CHANGE	EFFECTIVITY
PAGES		

CHAPTER 11

L.E.P. 1- 3 T. OF C.	Revised to Reflect this revision indicating new,revised, and/or deleted pages Revised to reflect this revision
11-00-00 1, 3- 4, 7-	Minor additions and amplification DELETED PLACARD AND MARKING DESCRIPTIONS DUE TO REDUNDANCY WITH OTHER MANUALS. FOR PROCURABLE PLACARDS, REFER TO IPC. FOR MARKINGS, REFER TO ENGINEERING DRAWINGS.
11-20-00 1, 7	Mod.2968M8171 removed No definition Mod.7416S8335 removed KEEL BEAM - STINGER CUTOUT MODIFICATION Minor additions and amplification DELETED PLACARD AND MARKING DESCRIPTIONS DUE TO REDUNDANCY WITH OTHER MANUALS. FOR PROCURABLE PLACARDS, REFER TO IPC. FOR MARKINGS, REFER TO ENGINEERING DRAWINGS.
11-21-21 1- 3	Topic cancelled
11-21-24 1- 2	Topic cancelled
11-21-27 1- 3	Topic cancelled
11-21-28 1- 3	Topic cancelled
11-21-29 1- 4	Topic cancelled
11-21-31 1- 2	Topic cancelled

11-HIGHLIGHTS REVISION NO. 75 Page 1 of 4 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

CH/SE/SU C PAGES		EFFECTIVITY
11-21-32 1- 4	Topic cancelled	
11-21-34 1- 2	Topic cancelled	
11-21-35 1- 2	Topic cancelled	
11-21-38 1- 11	Topic cancelled	
11-21-52 1- 2	Effectivity updated at the bottom of the page Mod.0001x0567 removed TECHNICAL PUBLICATION-BASIC MODIFICATION. Mod.5512S6431 removed PLACARDS AND MARKINGS - ADD EXTERIOR MARKINGS IN FRENCH ON PAX CREW DOORS AND EMERGENCY EXITS. SB 52-2039 01 removed DOORS - PASSENGER/CREW AND CARGO COMPARTMENT DOORS - INTRODUCE RESIDUAL PRESSURE WARNING SYSTEM	
11-21-53 1- 4	Topic cancelled	
11-21-54 1- 2	Topic cancelled	
11-22-32 1- 19	Topic cancelled	
11-23-00 1	Topic cancelled	
11-23-27 1- 4	Topic cancelled	
11-23-28 1- 4	Topic cancelled	
11-23-29 1- 4	Topic cancelled	
11-23-57 1- 3	Topic cancelled	

11-HIGHLIGHTS REVISION NO. 75 Page 2 of 4 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

CH/SE/SU C PAGES	REASON FOR CHANGE	EFFECTIVITY
11-24-26 1- 3	Topic cancelled	
11-24-71 01 1- 14	Topic cancelled	
11-25-00 1	Topic cancelled	
11-25-27 1- 2	Topic cancelled	
11-25-28 1- 2	Topic cancelled	
11-25-55 1- 4	Topic cancelled	
11-31-00 1	Topic cancelled	
11-31-11 1- 7	Topic cancelled	
11-31-21 1- 2	Topic cancelled	
11-32-11 1- 2	Topic cancelled	
11-32-25 1- 12	Effectivity updated at the bottom of the page Mod.0001x0057 removed TECHNICAL PUBLICATION-BASIC MODIFICATION. Mod.5391D4510 removed EQUIPMENT/FURNISHINGS - PAX COMPARTMENT - INSTALL A THREE CLASS CABIN LAYOUT Mod.7226D6487 removed EQUIPMENT/FURNISHINGS - PAX COMPARTMENT - INSTALL A MIXED CLASS CABIN LAYOUT FOR OS2 VERSION Mod.8756D8989 removed EQUIPMENT/FURNISHINGS -PAX COMPARTMENT-MODIFY FIRST AID KIT PLACARD - SB 25-2137 removed No definition SB 25-2155 01 removed EQUIPMENT/FURNISHINGS - PASSENGER COMPARTMENT	

11-HIGHLIGHTS REVISION NO. 75 Page 3 of 4 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

CH/SE/SU C PAGES	REASON FOR CHANGE	EFFECTIVITY
	- INSTALL PLACARDS ON DOOR OF LAVATORY A	
11-32-52 1- 9	Topic cancelled	
11-33-27 1- 3	Topic cancelled	
11-33-35 1- 2	Topic cancelled	
11-34-29 1- 5	Topic cancelled	
11-35-25 1- 15	Topic cancelled	
11-36-35 1- 21	Topic cancelled	

AIRCRAFT MAINTENANCE MANUAL

CHAPTER 11

PLACARDS AND MARKING

LIST OF EFFECTIVE PAGES

N, R or D indicates pages which are New, Revised or Deleted respectively Remove and insert the affected pages and complete the Record of Revisions and the Record of Temporary Revisions as necessary

CH/SE/SU	С	PAGE	DATE	CH/SE/SU	С	PAGE	DATE	CH/SE/SU	С	PAGE	DATE
RECORD				11-21-21	D	1		11-21-52	D	7	
OF TEMP.				11-21-21	D			11-21-52	D	8	
REVISION				11-21-21	D			11-21-52	D	9	
KLVIJION				11-21-24	D			11-21-52	D	10	
L.E.P.	R	1- 3	Jun01/15	11-21-24	D			11-21-52	D	11	
T. of C.	R		Jun01/15	11-21-27	D			11-21-52	D	12	
T. of C.	D			11-21-27	D			11-21-52	D	13	
T. of C.	D			11-21-27	D			11-21-52	D	14	
				11-21-28	D			11-21-52	D	15	
11-00-00	R	1	Jun01/15	11-21-28	D			11-21-52	D	16	
11-00-00			Dec01/89	11-21-28	D			11-21-52	D	17	
11-00-00	R		Jun01/15	11-21-29	D			11-21-52	D	18	
11-00-00	R		Jun01/15	11-21-29	D			11-21-52	D	19	
11-00-00			Jun01/10	11-21-29	D			11-21-52	D	20	
11-00-00			Jun01/10	11-21-29	D			11-21-52	D	21	
11-00-00	R		Jun01/15	11-21-31	D			11-21-52	D	22	
11-00-00	R		Jun01/15	11-21-31	D			11-21-52	D	23	
11-00-00	R			11-21-32	D			11-21-53	D	1	
11-00-00	R		Jun01/15	11-21-32	D			11-21-53	D	2	
11-00-00	R			11-21-32	D			11-21-53	D	3	
11-00-00	R		Jun01/15	11-21-32	D			11-21-53	D	4	
11-00-00	R		Jun01/15	11-21-34	D			11-21-54	D	1	
11-00-00	R		Jun01/15	11-21-34	D			11-21-54	D	2	
11-00-00	R		Jun01/15	11-21-35	D			, .		_	
11-00-00			Jun01/10	11-21-35	D			11-22-32	D	1	
11-00-00	R		Jun01/15	11-21-38	D			11-22-32	D	2	
11-00-00	N			11-21-38	D			11-22-32	D	3	
00 00		.0	001101713	11-21-38	D			11-22-32	D	4	
11-20-00	R	1	Jun01/15	11-21-38	D			11-22-32	D	5	
11-20-00	•		Jun01/96	11-21-38	D			11-22-32	D	6	
11-20-00			Jun01/13	11-21-38	D			11-22-32	D	7	
11-20-00			Jun01/08	11-21-38	D			11-22-32	D	8	
11-20-00		5		11-21-38	D			11-22-32	D	9	
11-20-00		6		11-21-38	D			11-22-32	D	10	
11-20-00	R		Jun01/15	11-21-38	D			11-22-32	D	11	
11-20-00	D	_		11-21-38	D			11-22-32	D	12	
11-20-00	D			11-21-52	R		Jun01/15	11-22-32	D	13	
11-20-00	D			11-21-52	R		Jun01/15	11-22-32	D	14	
11-20-00	D			11-21-52	D			11-22-32	D	15	
11-20-00	D			11-21-52	D			11-22-32	D	16	
11-20-00	D			11-21-52	D			11-22-32	D	17	
11-20-00	D			11-21-52	D			11-22-32	D	18	

11-L.E.P. Page 1 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

CH/SE/SU C	PAGE	DATE	CH/SE/SU	С	PAGE	DATE	CH/SE/SU	С	PAGE	DATE
11-22-32 D	19		11-31-11	D	4		11-32-25	D	43	
== 0=			11-31-11	D	5		11-32-52	D	1	
11-23-00 D	1		11-31-11	D	6		11-32-52	D	2	
11-23-27 D	1		11-31-11	D	7		11-32-52	D	3	
11-23-27 D	2		11-31-21	D	1		11-32-52	D	4	
11-23-27 D	3		11-31-21	D	2		11-32-52	D	5	
11-23-27 D	4						11-32-52	D	6	
11-23-28 D	1		11-32-11	D			11-32-52	D	7	
11-23-28 D	2		11-32-11	D	2		11-32-52	D	8	
11-23-28 D	3		11-32-25	R		Jun01/15	11-32-52	D	9	
11-23-28 D	4		11-32-25	R		Jun01/15				
11-23-29 D	1		11-32-25	R			11-33-27	D	1	
11-23-29 D	2		11-32-25	R		Jun01/15	11-33-27	D	2	
11-23-29 D	3		11-32-25	R			11-33-27	D	3	
11-23-29 D	4		11-32-25	R		Jun01/15	11-33-35	D	1	
11-23-57 D			11-32-25	R			11-33-35	D	2	
11-23-57 D			11-32-25	R				_		
11-23-57 D	3		11-32-25	R		Jun01/15	11-34-29	D	1	
44 27 27			11-32-25	R			11-34-29	D	2	
11-24-26 D			11-32-25	R		Jun01/15	11-34-29	D	3	
11-24-26 D			11-32-25	R		Jun01/15	11-34-29	D	4	
11-24-26 D	3 1		11-32-25	D	13		11-34-29	D	5	
11-24-71 01 D 11-24-71 01 D	2		11-32-25 11-32-25	D	14 15		11-35-25		1	
11-24-71 01 D	3		11-32-25	D D	16		11-35-25	D D	1 2	
11-24-71 01 D	4		11-32-25	D	17		11-35-25	D	3	
11-24-71 01 D	5		11-32-25	D	18		11-35-25	D	4	
11-24-71 01 D	6		11-32-25	D	19		11-35-25	D	5	
11-24-71 01 D	7		11-32-25	D	20		11-35-25	D	6	
11-24-71 01 D	8		11-32-25	D	21		11-35-25	D	7	
11-24-71 01 D	9		11-32-25	D	22		11-35-25	D	8	
11-24-71 01 D	10		11-32-25	D	23		11-35-25	D	9	
11-24-71 01 D	11		11-32-25	D	24		11-35-25	D	10	
11-24-71 01 D	12		11-32-25	D	25		11-35-25	D	11	
11-24-71 01 D			11-32-25	D	_		11-35-25	D	_	
11-24-71 01 D	14		11-32-25	D	27		11-35-25	D	13	
			11-32-25	D	28		11-35-25	D	14	
11-25-00 D	1		11-32-25	D	29		11-35-25	D	15	
11-25-27 D	1		11-32-25	D	30					
11-25-27 D	2		11-32-25	D	31		11-36-35	D	1	
11-25-28 D	1		11-32-25	D	32		11-36-35	D	2	
11-25-28 D	2		11-32-25	D	33		11-36-35	D	3	
11-25-55 D	1		11-32-25	D	34		11-36-35	D	4	
11-25-55 D	2		11-32-25	D	35		11-36-35	D	5	
11-25-55 D			11-32-25	D	36		11-36-35	D	6	
11-25-55 D	4		11-32-25	D	37		11-36-35	D	7	
44.74.00			11-32-25	D	38		11-36-35	D	8	
11-31-00 D			11-32-25	D	39		11-36-35	D	9	
11-31-11 D			11-32-25	D	40		11-36-35	D	10	
11-31-11 D			11-32-25	D	41		11-36-35	D	11	
11-31-11 D	3		11-32-25	D	42		11-36-35	D	12	

11-L.E.P. Page 2 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

CH/SE/SU	C	PAGE	DATE	CH/SE/SU	C	PAGE	DATE	CH/SE/SU	C	PAGE	DATE
11-36-35	D	13									
11-36-35	D	14									
11-36-35	D	15									
11-36-35	D	16									
11-36-35	D	17									
11-36-35	D	18									
11-36-35	D	19									
11-36-35	D	20									
11-36-35	D	21									
11-37-00		1	Jun01/07								
11-37-00		2	Dec01/89								
11-37-00		3	Dec01/95								

AIRCRAFT MAINTENANCE MANUAL

CHAPTER 11

PLACARDS AND MARKING

TABLE OF CONTENTS

	SUBJECT		<u>C</u> <u>PAGE</u>	EFFECTIV ITY
	PLACARDS AND MARKINGS	11-00-00	_	
	General			ALL
	Labels		-	ALL
	Label Replacement		=	ALL
	Labels removal			ALL
	Cabin placards removal		3	ALL
	Decals		4	ALL
	Placards on Panels		7	ALL
	Identification Bands on Metal		7	ALL
	Lines			
	Labels on Heat Resistant Ducting		8	ALL
	Labels on Laminated Tubing		8	ALL
	ESSO Labels		9	ALL
	<pre>\$\$0 (Scotchcal Labels)</pre>		9	ALL
	FOTOFOIL Labels		10	ALL
	B.S.B. (DUROFIX) Labels		10	ALL
	DISA (SUPRAFIX) Labels		11	ALL
	Marking Paints		17	ALL
	Apply Marking Paints with		17	ALL
	Stencils			
	EXTERIOR PLACARDS AND MARKINGS	11-20-00		
	General	0 00	1	ALL
R	INTERIOR PLACARDS AND MARKINGS	11-32-25	•	
R	Equipment/Furnishings	11 JL LJ	1	401-401,404-500,
	COCAUA-DA-072 *			401-401,404-500,
	OCCION DA CIL		'	401 401,404 300,
	EQUIPMENT COMPARTMENTS, ZONES 171/172	11-37-00		
	AND 311/314			
	General		1	ALL

AIRCRAFT MAINTENANCE MANUAL

PLACARDS AND MARKINGS - GENERAL

1. General

R

R

R

R R

R

R R

R

R R

R

R

R

R R

R This chapter gives information and maintenance procedures related to placards and markings.

Information about placards and the description and location of the markings are available from the sources that follow:

- All placards and markings that are installed on the aircraft at the time of delivery are in e-drawing on Airbus World.
- Procurable Airbus-proprietary placards and markings are available in the Illustrated Parts Catalog (IPC).
- Placards and Markings that are necessary for EASA Type Certification are given in the document "A3XX EASA required placards and marking". This document is available on Airbus World.

NOTE : The name of the EASA document is different for different aircraft. For the A310:

A310 - EASA required Placards and Markings.

For the A300-600:

A300-600 - EASA required Placards and Markings.

- Maintenance Procedures for removal and installation of placards and markings are available in the Aircraft Maintenance Manual (AMM).

2. Labels

There are three types of labels:

A. General

- (1)Standard type No.1 label
- (2)Standard type No.2 label
- (3)FOTOFOIL type No.3

Standard No.1 and 2 labels are in plastic material with white letters on black matt finish.

Type No.3 labels are in 0.076 mm (0.002 in.) metal foil for use in skydrol zones with white letters on black matt finish.

B. Dimensions

(Ref. Fig. 001)

3. Label Replacement

Label replacement according to type and purpose is dealt with below.

- Decals
- Nameplates (For example on circuit breaker panel)
- Identification bands on metal lines
- Labels on heat resistant ducting
- Labels on laminations
- ESSO labels
- SSO (SCOTCHCAL) labels
- FOTOFOIL labels
- BSB (DUROFIX) labels

EFFECTIVITY: ALL

11-00-00


Page 1 Jun 01/15

KSSU

11 00 00 0 AAMO - 17

©A310

AIRCRAFT MAINTENANCE MANUAL



Dimensions of Labels Figure 001

EFFECTIVITY:	ALL		
KSSU			

11-00-00

AIRCRAFT MAINTENANCE MANUAL

- DISA (SUPRAFIX) labels
- Metal identification plates
- Labels on landing gear
- Cabin placards

NOTE: 1. This list is not restrictive

2. Installation or replacement of labels or instruction placards attached by various types of threaded fasteners or rivets are not dealt with below since no special procedure is involved.

A. Labels removal

WARNING: USE SOLVANTS/CLEANING AGENTS, SEALANTS AND OTHER SPECIAL MATERIALS ONLY WITH A GOOD SUPPLY OF AIR.

OBEY THE MANUFACTURERS INSTRUCTIONS.

PUT ON PROTE TIVE CLOTHING. DO NOT GET THEM IN YOUR MOUTH.

DO NOT SMOKE.

DO NOT BREATHE THE GAS.

THESE MATERIALS ARE POISONOUS, FLAMMABLE AND SKIN IRRITANT. GET MEDICAL HELP IF YOUR SKIN OR EYES BECOME IRRITATED.

(1) Equipment and Materials

DESIGNATION ______

(1)Material No. 19-003

USA AMS 3819 LINT-FREE COTTON CLOTH

(Ref. 20-31-00)

(2)Material No. 19-011

SCOTCH BRITE PADS (Ref. 20-31-00) Abrasive cloth, grade 240

(2)Procedure

(a)Job set-up

1 Get access to the area where you must remove the decal.

- (b)Removal
 - 1 Stripping:
 - Apply masking tape or masking paper on the area adjacent to the decal location.
 - Rub the marking surface with CLEANING AGENTS (Material No. 19-011) to remove the varnish.
 - Rub the marking surface with Abrasive cloth, grade 240.
 - Clean the rubbed area with CLEANING AGENTS (Material No. 19-003).
 - 2 Painting:
- Apply paint where necessary (Ref. TASK51-75-10, P. Block 801). (c)Close-up
 - 1 Make sure that the work area is clean and clear of tool(s) and other items.
- B. Cabin placards removal

WARNING: USE SOLVANTS/CLEANING AGENTS, SEALANTS AND OTHER SPECIAL MATERIALS ONLY WITH A GOOD SUPPLY OF AIR. OBEY THE MANUFACTURERS INSTRUCTIONS. PUT ON PROTECTIVE CLOTHING.

EFFECTIVITY: ALL

11-00-00

KSSU

AIRCRAFT MAINTENANCE MANUAL

DO NOT GET THEM IN YOUR MOUTH.

DO NOT SMOKE.

DO NOT BREATHE THE GAS.

THESE MATERIALS ARE POISONOUS, FLAMMABLE AND SKIN IRRITANT.

GET MEDICAL HELP IF YOUR SKIN OR EYES BECOME IRRITATED.

(1) Equipment and Materials

ITEM	DESIGNATION
(1)Material No. 19-003	USA AMS 3819 LINT-FREE COTTON CLOTH (Ref. 20-31-00)
(2)Material No. 11-002	USA MIL-PRF-680 DRY CLEANING SOLVENT (VARSOL/WHITE SPIRIT) (Ref. 20-31-00)

(2)Procedure

- (a)Job set-up
 - 1 Get access to the area where you must remove the decal.
- (b)Removal
 - 1 Removal of the Placard
- CAUTION : DO NOT USE A METAL SCRAPER TO REMOVE THE UNWANTED

MATERIAL. A METAL SCRAPER CAN CAUSE DAMAGE TO THE SURFACE

OF THE COMPONENT.

Remove the placard with a plastic scraper.

2 Cleaning

Remove unwanted glue with CLEANING AGENTS (Material No. 19-003) soaked with CLEANING AGENTS (Material No. 11-002) then thoroughly dry out.

(c)Close-up

Make sure that the work area is clean and clear of tool(s) and other items.

C. Decals

(1) Application over even or irregular surfaces (Ref. Fig. 002, 003)

NOTE: To prevent scribe marks on the aircraft skin, use scissors or a cutter with a plate between the film and the aircraft skin (0.6 mm (0.0236 in.) thick minimum with metal and 2 mm (0.0787 in.) thick minimum with hard plastic). You can also use a couppy cutter or spare blades.

- (a)Decals applied over a joint between two surfaces which move with respect to each other.
 - $\underline{\mathbf{1}}$ With gaps of 0.1 in. and greater, cut the decal at the center of the gap and wrap the decal around both edges. See Method A.
 - With gaps of less than 0.1 in., cut the decal flush with the front or upper edge of the joint and wrap the decal around the rear or lower edge. See Method B.
- (b)Decals applied across lap joints
 - 1 The decal, when it is applied, is wrapped smoothly and continuously around the edge of the lap joint. See Method C (preferred method).
- (c)Decals applied to exterior emergency exit handles. See Method E.


EFFECTIVITY: ALL


11-00-00


R

KSSU

AIRCRAFT MAINTENANCE MANUAL







Application of Decals Figure 002


EFFECTIVITY: ALL
KSSU

R

11-00-00

Page 5 Jun 01/10

AIRCRAFT MAINTENANCE MANUAL



Application of Decals Figure 003

EFFECTIVITY: ALL

11-00-00

AIRCRAFT MAINTENANCE MANUAL

- 1 Before removing the backing paper, place the decal on the handle and slit the decal overlap around each rounded corner.
- $\underline{2}$ Remove the backing paper and apply the decal, pressing the overlap around the edges of the handle.
- (d)Cut decals, except pressure sensitive Polyester, around the heads of fasteners on removable panels and punch the decal into the recessed slot. Cut and remove an area of film, of pressure sensitive polyester decals the approximate size of a protruding-head rivet or fastener. Press the decal film firmly in place around the rivet or fastener. Allow the adhesive to cure for 1/2 hour before sealing edges.
- (e)Puncture the decal film, with a sharp pointed instrument, at each rivet, of decals applied over pressurized areas.
- D. Placards on Panels

(1)General

These are SPRINT 639 self-adhesive placards affixed to Plexiglas surfaces.

(2) Equipment and Materials

DESIGNATION

(1) Material No. 11-002 Cleaning Agents (Ref. 20-31-00)

(3)Procedure

(a) Job set-up

- 1 Clean and degrease Plexiglas surface to which placard is to be affixed, using Material No.11-002 then thoroughly dry out.
- 2 Any drilling of holes or trimming of placard called for shall be performed prior to installation
- (b)Installation
 - 1 Starting at one end, peel off the protective backing paper over 1 cm (0.4 in.) approx. and fold back.
 - 2 Affix peeled end to Plexiglas and gradually remove backing paper while pressing down the placard on to the Plexiglas.
 - 3 Carefully smooth out placard working from the center outwards.
 - NOTE: Do not soil adhesive contact surface of placard, refrain from fingering that surface.
- E. Identification Bands on Metal Lines
 - (1) Equipment and Materials

DESIGNATION

Cleaning Agents (Ref. 20-31-00) Cleaning Agents (Ref. 20-31-00) Structure Paints (Ref. 20-31-00) (a)Material No. 11-003 (b)Material No. 11-004 (c)Material No. 16-003

(2)Procedure

(a)Job set-up

1 Clean surface to which band is to be affixed using Material No.11-004 or alternatively Material No.11-003 then thoroughly dry out.

EFFECTIVITY: ALL

11-00-00

AIRCRAFT MAINTENANCE MANUAL

2 Band must be approximately 5 mm (0.2 in.) longer than circumference of metal line.

(b)Installation

- 1 Remove backing paper.
- $\overline{2}$ Affix band by evenly unrolling and gradually smoothing out to prevent formation of air bubbles.
- 3 Overlap band ends and smooth out.
- (c)Protective finish

Apply two coats of Material No.16-003 to band, overlapping edge of band by 1 cm (0.4 in.) approx. using a soft hair brush.

NOTE: In the event that Material No.16-003 protective finish becomes damaged, two coats of Material No.16-016 shall be applied to prevent attack of adhesive by fluid (e.g. hydraulic fluid) and subsequent separation of band.

If film of material No.16-003 is excessively damaged, replace band and renew protective finish.

F. Labels on Heat Resistant Ducting

(1)Equipment and Materials

DESIGNATION

(a)Material No. 08-004

Bonding and Adhesive Compounds (Ref. 20-31-00) Cleaning Agents (Ref. 20-31-00)

(b)Material No. 11-004

(2)Procedure

(a) Job set-up

- 1 Degrease and clean surface to which label is to be affixed using Material No.11-004, then thoroughly dry out.
- (b)Installation
 - 1 Label to be affixed to fabric impregnated with silicone synthetic rubber.

Affix label with Material No.08-004 as per Vendor instructions.

- 2 Label to be affixed to fabric impregnated with Viton synthetic rubber.
 - Material No.08-004 shall be applied only after Viton coating has been treated with a bond coat comprising MB primer of the same composition.
 - Primer must be left to dry for 30 minutes prior to affixing label.
- G. Labels on Laminated Tubing
 - (1)Equipment and Materials

DESIGNATION

(a)Material No. 11-004

Cleaning Agents (Ref. 20-31-00)

(2)Procedure

- (a) Job set-up
 - 1 Degrease and clean surface to which label is to be affixed using Material No.11-004, then thoroughly dry out.
- (b)Installation

EFFECTIVITY: ALL

11-00-00

AIRCRAFT MAINTENANCE MANUAL

- 1 Remove backing paper.
- 2 Affix label and smooth out working from center outwards to prevent formation of air bubbles.
- 3 Smooth out whole surface.
- H. ESSO Labels

(1) Equipment and Materials

DESIGNATION ______ Cleaning Agents (Ref. 20-31-00) Cleaning Agents (Ref. 20-31-00) (a)Material No. 11-003

(2)Procedure

(a) Job set-up

(b)Material No. 11-004

- 1 Degrease and clean the surfaces to which ESSO labels are to be affixed using Material No.11-003 or Material No.11-004 then thoroughly dry
- (b)Installation
 - 1 Remove protective backing.
 - 2 Using a clean brush, apply coat of Material No.11-003 to adhesive film on back of label.
 - 3 As soon as adhesive softens and becomes tacky, install label and press down on same especially around the edges.
- I. SSO (Scotchcal Labels)

(1) Equipment and Materials

______ TTFM DESIGNATION ______ Bonding and Adhesive Compounds (Ref. 20-31-00) Cleaning Agents (Ref. 20-31-00) (a)Material No. 08-017 (b)Material No. 11-002 (c)Material No. 11-003 Cleaning Agents (Ref. 20-31-00) (d) Emery Cloth, Grade 350

- (2)Procedure (General)
 - (a) Job set-up
 - 1 Clean surface to which label is to be affixed using Material No.11-003, then thoroughly dry out.
 - (b)Installation
 - 1 Remove protective backing paper from label.
 - 2 Position label and apply heavy pressure.
 - (c)Maintenance and cleaning
 - 1 These labels can be cleaned with soapy water.
 - 2 Oil stains can be removed with Material No.11-002.
- (3)Procedure in Presence of Skydrol
 - (a) Job set-up
 - 1 Roughen surface to which label is to be applied using Grade 350 emery cloth and then clean with Material No.11-003, then thoroughly dry out.
 - 2 Remove protective backing, then remove adhesive with pad dipped in

EFFECTIVITY: ALL

AIRCRAFT MAINTENANCE MANUAL

Material No.11-003.

- (b)Installation
 - 1 Using a brush, apply coat of Material No.08-017.
 - $\overline{2}$ Affix label and apply light pressure to label for about 30 seconds.

J. FOTOFOIL Labels

(1) Equipment and Materials

ITEM	DESIGNATION
(a)Material No. 08-010 (b)Material No. 11-003	Bonding and Adhesive Compounds (Ref. 20-31-00) Cleaning Agents (Ref. 20-31-00)

(2)Procedure

- (a)Job set-up
 - 1 Roughen surface to which label is to be affixed using emery cloth, and clean with Material No.11-003 then thoroughly dry out.
 - $\underline{2}$ Apply coat of Material No.08-010 to surface to which label is to be affixed.
 - <u>MOTE</u>: When label is to be affixed to a cylindrical component, temporarily install a tie strap and leave in position until Material No.08-010 is fully dry.

K. B.S.B. (DUROFIX) Labels

NOTE: Do not use in areas painted with Material No. 07-004.

NOTE: This procedure is related to the installation of the DUROFIX labels (Material No. 05-136) (Marking by reactivable transfer label).

(1) Equipment and Materials

ITEM	DESIGNATION
(a)	Lukewarm Water
(b)	Needle
(c)	Plastic Container
(d)	Plastic Scraper
(e)	Rubber Roller
(f)	Soft Hair Brush
(g)	Sponge
(h)Material No. 11-003	Cleaning Agents (Ref. 20-31-00)
(i)Material No. 05-029	Special Materials (Ref. 20-31-00)
(j)Material No. 07-018	Lacquers (Ref. 20-31-00)
(k)Material No. 11-016	Cleaning Solvent (Ref. 20-31-00)
(l)Material No. 19-003	Lint-Free Cotton Cloth (Ref. 20-31-00)
(2)Procedure	
(a)Job set-up	

NOTE: The labels shall not be installed if paint has not cured for 24 hours minimum at ambient temperature.

1 Thoroughly clean surface to which label is to be affixed using lint-free cotton cloth (Material No. 19-003) soaked in cleaning

EFFECTIVITY: ALL

11-00-00

Page 10 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

agents (Material No. 11-003 or 11-016) and allow to dry.

2 Prepare the bonding material:

NOTE : Obey the manufacturer's instructions and the safety precautions to use bonding material.

- a If the paint is new, do the step that follows:
 - Mix one volume of lukewarm water (by volume) $30 \text{ to } 40^{\circ}\text{C}$ (86 to 104°F) with one volume of the fixative special materials (Material No. 05-029 in a plastic container.
- \underline{b} If the paint is not new, do the steps that follow:
 - Apply the fixative special materials (Material No. 05-029) on the paint of the applicable area.
 - Mix two volumes of lukewarm water (by volume) 30 to 40°C (86 to 104°F) with one volume of the fixative special materials (Material No. 05-029) in a plastic container.
- <u>3</u> Prior to application, immerse the labels for 15 to 20 seconds in the above-mentioned mixture.

(b)Installation

- 1 Offer-up label above its location with markings facing contact surface.
- 2 Apply one end of label to support while lifting the other end stretched tight to prevent formation of wrinkles.
- Press the label against the surface with a plastic scraper. Start from the center and press towards the edges. Be careful to prevent formation of wrinkles or air pockets. To complete the operation apply a strong pressure on all the surface with a rubber roller.
- 4 As you do these operations, remove the unwanted solution with a moist sponge.

(c)Close-up

- 1 Apply the moist sponge on the backing paper of the label.
- 2 Wait for 2 minutes and remove backing paper.

(d)Check

If label is not correctly affixed;

1 If label is wet:

Remove label and repeat procedure with a new label.

2 If label is dry:

Wet label with a lint-free cotton cloth (Material No. 19-003) soaked with cleaning agents (Material No. 11-003). Remove label with a plastic scraper or cleaning agents (Material No. 11-016) and repeat procedure.

NOTE : Maximum adhesion is achieved after three or four days, do not clean label area during this period.

(e)Protective finish

In areas which may be exposed to hydraulic fluid contamination, apply lacquer (Material No. 07-018) on label, using a soft hair brush.

<u>NOTE</u>: Apply the lacquer only after labels have dried for 24 hours minimum at ambient temperature.

L. DISA (SUPRAFIX) Labels

 $\underline{\text{NOTE}}$: Do not use in areas painted with Material No. 07-004. $\underline{\text{NOTE}}$: This procedure is related to the installation of the

EFFECTIVITY: ALL

11-00-00

R

KSSU

Page 11 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

DISA FRS labels (SUPRAFIX FRS Material No. 05-135) (Marking by reactivable transfer label).

(1) Equipment and Materials

ITEM	DESIGNATION
(a)	Lukewarm Water
(b)	Needle
(c)	Plastic Container
(d)	Plastic Scraper
(e)	Rubber Roller
(f)	Soft Hair Brush
(g)	Sponge
(h)Material No. 11-003	Cleaning Agents (Ref. 20-31-00)
(i)Material No. 11-016	Cleaning Solvent (Ref. 20-31-00)
(j)Material No. 11-026	Cleaning Solvent (Ref. 20-31-00)
(k)Material No. 05-137	Special Materials (Ref. 20-31-00)
(l)Material No. 07-018	Lacquers (Ref. 20-31-00)
(m)Material No. 19-003	Lint-Free Cotton Cloth (Ref. 20-31-00)

(2)Procedure

(a) Job set-up

NOTE: The labels shall not be installed if paint has not cured for 24 hours minimum at ambient temperature.

- Thoroughly clean surface to which label is to be affixed using lint free cotton cloth (Material No. 19-003) soaked in cleaning agents (Material No. 11-003 or 11-016 or 11-026) and allow to dry.
- 2 Prepare the bonding material:
 - <u>a</u> Put fixative (Material No. 05-137) in a plastic container (large enough not to fold the label) at 17 to 23°C (62.6 to 73.4°F).
 - \underline{b} Prior to application, immerse the labels for 30 to 45 seconds in the above-mentioned preparation.

(b)Installation

- <u>1</u> Offer-up label above its location with markings facing contact surface.
- 2 Apply one end of label to support while lifting the other end stretched tight to prevent formation of wrinkles.
- Press the label against the surface with a plastic scraper. Start from the center and press towards the edges. Be careful to prevent formation of wrinkles or air pockets. To complete the operation apply a strong pressure on all the surface with a rubber roller.
- 4 As you do these operations, remove the unwanted solution with a moist sponge.

(c)Close-up

- 1 Apply the moist sponge on the backing paper of the label.
- 2 Wait for 2 minutes and remove backing paper.
- 3 Gently remove the remaining compound from the label surface and around the label with a sponge soaked in water.
- 4 Make holes in the air pockets, if any, with a needle.

EFFECTIVITY: ALL

11-00-00

Page 12 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

(d)Check

If label is not correctly affixed;

1 If label is wet:

Remove label and repeat procedure with a new label.

2 If label is dry:

Wet label with a lint-free cotton cloth (Material No. 19-003) soaked with cleaning agents (Material No. 11-003). Remove label with a plastic scraper or cleaning agents (Material No. 11-016 or 11-026) and repeat procedure.

<u>NOTE</u>: Maximum adhesion is achieved after three or four days, do not clean label area during this period.

(e)Protective finish

In areas which may be exposed to hydraulic fluid contamination, apply of lacquer (Material No. 07-018) on label, using a soft hair brush.

 ${\underline{\mathtt{NOTE}}}$: This procedure is recommended to improve the durability of

the labels applied on external surfaces.

NOTE : Apply the lacquer only after labels have dried for 24 hours minimum at ambiant temperature.

M. Installation of Metal Identification plates

(1)General

- Leveling point identification plates
- Rudder neutral position identification
- Alpha probe adjustment tool positioning identification, etc.

(2) Equipment and Materials

ITEM DESIGNATION

(1) Material No. 11-003 Cleaning Agents (Ref. 20-31-00)
(2) Material No. 09-008 Sealants (Ref. 20-31-00)
(3) Abrasive Paper, Grade 500

(3)Procedure

(a)Job set-up

- Sand structure surface with abrasive paper grade 500.
- Clean surface and plate with Material No. 11-003.
- Check planeity of contact surfaces. If insufficient, slightly curve plates for better adherence.
- Prepare Material No. 09-008.

(b)Installation

- Apply Material No. 09-008 with a brush preferably on the plate.
- Install plate at its exact location, making certain that it perfectly adheres to mating surface.
- N. Installation of Labels on Landing Gear

(1) Equipment and Materials

ITEM DESIGNATION

(a)Material No. 08-001 Bonding and Adhesive Compounds (Ref. 20-31-00)
(b)Material No. 11-003 Cleaning Agents (Ref. 20-31-00)
(c)Material No. 07-018 Aerodur Clearcoat U.V.R (Ref. 20-31-00)

EFFECTIVITY: ALL

11-00-00

. 00 00

R

KSSU

© A310

AIRCRAFT MAINTENANCE MANUAL

ITEM	DESIGNATION
(d)	Abrasive Paper, Grade 500
(e)	B rush
(2)Procedure (a)Job set-up	

- Lightly abrade the paint surface with fine-grit type abrasive paper, such as P500 grade paper, to get a matt finish applicable for bonding.
- Clean surfaces and plates with Material No. 11-003.
- Check planeity of contact surfaces . If insufficient, slightly curve plates for better adherence.
- (b)Installation

Apply Material No. 08-001 on plates and install.

Apply two coats of Material No. 07-018 on labels, using a soft hair hrush.

O. Installation of the Reference Triangle

(1)General

This procedure gives the information to bond the reference triangles on the fuselage and tail cone.

(2) Equipment and materials

ITEM	DESIGNATION				
(a)Material No. 08-001 (b)Material No. 11-003 (c) (d) (e)	Bonding and Adhesive Compounds (Ref. 20-31-00) Cleaning Agents (Ref. 20-31-00) Adhesive Tape Lint-free Cotton Cloth Non Metallic Spatola				
Referenced Procedures - 27-21-00, P. Block 501 - 27-31-00, P. Block 501	Rudder Elevator				

(3) Job set-up

- (a)Before you install the reference triangle, make sure that the rudder and/or the elevator are in the correct position.
 - for the rudder (Ref. 27-21-00, P. Block 501)
 - for the elevator (Ref. 27-31-00, P. Block 501).
- (b)Preparation of the contact surfaces
 - Clean the contact surfaces with a lint-free cloth soaked with CLEANING AGENTS (Material No. 11-003).
 - Remove the remaining adhesive compound with non-metallic spatula.
 - Use adhesive tape to show the limits of the bonded area.
 - Do a check of the condition of the contact surfaces and rework it if necessary (Ref. SRM 512110, P. Block 001) and (Ref. SRM 512310, P. Block 001).
 - Apply finish paint on the contact surfaces.

EFFECTIVITY: ALL

11-00-00

KSSU

Page 14 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

- Remove the adhesive tape.
- Clean the contact surfaces with a lint-free cloth soaked with CLEANING AGENTS (Material No. 11-003).
- Use adhesive tape to show the limits of the bonded area.
- Rub the contact surfaces with emery paper grade 320 to make the surface mat.
- Remove the adhesive tape.
- Clean the contact surfaces with a lint-free cloth soaked with CLEANING AGENTS (Material No. 11-003).

(4)Procedure

- (a) Remove the protection paper from the reference triangle.
- (b)Install the reference triangle with BONDING AND ADHESIVE COMPOUNDS (Material No. 08-001).
- (c)Use adhesive tape to hold the reference triangle during cure time. (5)Close-up
 - (a) Make sure that the work area is clean and clear of tool(s) and other items.
- P. Installation of the Cabin placards

<u>WARNING</u>: USE SOLVANTS/CLEANING AGENTS, SEALANTS AND OTHER SPECIAL MATERIALS ONLY WITH A GOOD SUPPLY OF AIR.

OBEY THE MANUFACTURERS INSTRUCTIONS.

PUT ON PROTECTIVE CLOTHING.
DO NOT GET THEM IN YOUR MOUTH.

DO NOT SMOKE.

DO NOT BREATHE THE GAS.

THESE MATERIALS ARE POISONOUS, FLAMMABLE AND SKIN IRRITANT. GET MEDICAL HELP IF YOUR SKIN OR EYES BECOME IRRITATED.

(1) Equipment and Materials

ITEM

DESIGNATION

(1)Material No. 11-002

USA MIL-PRF-680 DRY CLEANING SOLVENT (VARSOL/WHITE SPIRIT) (Ref. 20-31-00)

(2)Procedure

- (a) Job set-up
 - 1 Cleaning

Clean and degrease the surface on which you will bond the placard with CLEANING AGENTS (Materials No. 11-002)

then fully dry the surface.

NOTE: You must drill the holes or cut the placard before you install it.

(Ref. Fig. 004)

(b)Installation

- $\underline{\mathbf{1}}$ Make sure that the adjacent placards are aligned vertically and/or horizontally.
- 2 If applicable, put the placard 20mm (0.7874 in.) from the edge

EFFECTIVITY: ALL


11-00-00

R


KSSU


Page 15 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL











NOTE: 1 CONTIGUOUS LABELS MUST BE IN VERTICAL AND/OR HORIZONTAL ALIGNMENT

Installation of Cabin placards Figure 004

EFFECTIVITY: ALL

11-00-00

Page 16 Jun 01/10

Printed in France

AIRCRAFT MAINTENANCE MANUAL

of its location or the end of corners.

3 Do not bond the placards around the corners.

4 Apply pressure on the placard against the surface (specially around the edges) and at the same time gradually remove the backing paper.

<u>5</u> Carefully apply pressure on the placard from the center to the sides.

NOTE : Do not cause contamination to the mating surface of the placard. Do not touch this surface with your fingers.

(c)Close-up

Make sure that the work area is clean and clear of tool(s) and other items.

4. Marking Paints

A. Apply Marking Paints with Stencils
(1) Equipment and Materials

ITEM	DESIGNATION				
(a)Material No. 07-018 (b)Material No. 11-003 (c)Material No. 11-010 (d) (e) (f) (g)	Paints For Details (Ref. 20-31-00) Cleaning Agents (Ref. 20-31-00) Cleaning Agents (Ref. 20-31-00) Access Platform Brush Masking Film Tape				

(2) Job set-up

- 1 Put an access platform in position in the work area.
- Clean surface to which paint is to be applied using Material No. 11-010 or Material No. 11-003 if the paint is fully cured, and let it dry.

(3)Procedure

(a)Installation

<u>NOTE</u>: The base paint must be sufficiently dry (the paint manufacturer gives the indications "dry to tape" or "maskable drying time") before you apply the paint with a stencil.

1 Put the masking film or tape in position.

2 Refer to the supplier's instructions to mix the paint.

NOTE : For more information about the coatings (Ref. SRM 51-23-10, P. Block 001).

3 Apply the paint as a spray or with a brush.

NOTE : Make sure that you keep the contrast between the color of the base paint and the marking.

4 Remove all the masking material and touch up as necessary.

(b)Protective finish

1 When the paint is dry, apply Material No. 07-018 if necessary. (4)Close-up

EFFECTIVITY: ALL

11-00-00

Page 17 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

- (a)Remove the access platform(s).
- (b) Make sure that the work area is clean and clear of tool(s) and other items.

EFFECTIVITY: ALL

11-00-00

R

KSSU

Page 18 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

EXTERIOR PLACARDS AND MARKINGS

	1.	Gener	<u>`al</u>							
R		This	chapter	gives	data	about	the	painted	exterior	markings.

2. Equipment and Materials

ITEM

DESIGNATION

A. Material No. 05-052

Special Materials (Ref. 20-31-00)

- 3. Hoisting and Jacking Points
 - A. Jacking Points

(Ref. Fig. 001)

- B. Hoisting Points
 - (1)Markings on fuselage and doors

(Ref. Fig. 002)

- (2) Markings on wing (Ref. Fig. 003)
- (3) Markings on trimmable horizontal stabilizer (Ref. Fig. 004)
- (4) Markings on vertical stabilizer

(Ref. Fig. 005)

NOTE: All hoisting point holes are blanked off by material No. 05-052. (Ref. Fig. 006). Blanking is performed after complete painting of aircraft.

Each blanking sheet is painted in the same color as the area in which it is located.


EFFECTIVITY: ALL


11-20-00


Page 1 Jun 01/15

KSSU

©A310AIRCRAFT MAINTENANCE MANUAL








Location of Jacking Points Figure 001


EFFECTIVITY: ALL

11-20-00

Page 2 Jun 01/96

AIRCRAFT MAINTENANCE MANUAL








Location of Hoisting Points on Fuselage and Doors Figure 002

R EFFECTIVITY: ALL

11-20-00

©A310AIRCRAFT MAINTENANCE MANUAL




Location of Hoisting Points on Wing R Figure 003

R	EFFECTIVITY: ALL
	KSSU

11-20-00

AIRCRAFT MAINTENANCE MANUAL



Location of Hoisting Points on the Trimmable Horizontal
Stabilizer
Figure 004


R Figure 004

R EFFECTIVITY: ALL

KSSU

11-20-00

AIRCRAFT MAINTENANCE MANUAL




Location of Hoisting Points on Vertical Stabilizer Figure 005

EFFECTIVITY: ALL

R

11-20-00



Blanking of Hoisting Points Figure 006

EFFECTIVITY: ALL
KSSU

11-20-00

AIRCRAFT MAINTENANCE MANUAL

**ON A/C 226-226, 229-249, 401-401,

Post SB 11-2002 For A/C 226-226,229-249,401-401,
(Ref. Fig. 001)

EFFECTIVITY: 226-226, 229-249, 401-401,


11-21-52


KSSU


Page 1 Jun 01/15

© A310

AIRCRAFT MAINTENANCE MANUAL







Marking of Pressurization on Passenger/Crew Doors Figure 001

R EFFECTIVITY: 226-226, 229-249, 401-401,
KSSU

11-21-52

AIRCRAFT MAINTENANCE MANUAL

```
R **ON A/C 401-401, 404-500,
R Post COCAUA-DA25-072
                             For A/C 401-401,404-500,
               EQUIPMENT/FURNISHINGS - INTERIOR PLACARDS AND MARKINGS
R
 **ON A/C 401-401, 404-500,
R Post COCAUA-DA25-072 For A/C 401-401,404-500,
R
  1. General
     This subject provides information concerning the interior placards and
     markings located on equipment/furnishings within the passenger compartment.
R **ON A/C 401-401, 404-500,
                           For A/C 401-401,404-500,
R Post COCAUA-DA25-072
    B. Passenger Compartment - Locations
  **ON A/C 401-401, 404-500,
                             For A/C 401-401,404-500,
  Post COCAUA-DA25-072
    A. Passenger Compartment - Placards/Markings (Ref. Fig. 001)
    B. Lavatory Y - Placards/Markings (Ref. Fig. 002)
    C. Seat Identification and Seatrow Numbering - Locations (Ref. Fig.
                                                                        003)
    D. Seat Identification and Seatrow Numbering - Placards/Markings
```

|EFFECTIVITY: 401-401, 404-500,

(Ref. Fig. 004)

11-32-25

KSSU


ØA310AIRCRAFT MAINTENANCE MANUAL


INTENTIONALLY BLANK

R KSSU

11-32-25

©A310AIRCRAFT MAINTENANCE MANUAL






EFFECTIVITY: 401-401, 404-500,
KSSU

Printed in France

11-32-25

Page 3- 4 Jun 01/15

©A310AIRCRAFT MAINTENANCE MANUAL



Lavatory Y - Placards/Markings Figure 002


R EFFECTIVITY: 401-401, 404-500,

R SSU

Page 5- 6
Jun 01/15

Printed in France

©A310AIRCRAFT MAINTENANCE MANUAL



Seat Identification and Seatrow Numbering - Locations Figure 003

EFFECTIVITY: 401-401, 404-500,

KSSU

Printed in France

11-32-25

Page 7- 8 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

			40	29	1 B 1 A	63	22 B 22 A	97	12 K 12 J	131	30 K 30 J
1		15	18	30	1 A Life vest under your seat 1 B	64	22 A Life vest under your sest 22 B	98	12 J Commonweal Premier 12 K	132	30 J Lile vest under your seat 30 K
				31	2 B 2 A	65	23 B 23 A	99	14 K 14 J	133	10 E 10 D
2	2	16	19	32	2 A Schulmmeste unter hrom Str. 2 B	66	23 A Schulmments onter Brown Etc. 23 B	100	14 J Life veet under your seet 14 K	134	10 D Schulmmeste unter From Str. 10 E
				33	3 B 3 A	67	24 B 24 A	101	15 K 15 J	135	11 E 11 D
3	2	17	20	34	3 A Life veet under your seet 3 B	68	24 A Life vest under your seet 24 B	102	15 J Bolintenmonto unter Brown Str. 15 K	136	11 D Life yest under your seet 11 E
3	3	4.1	20	35	4 B 4 A	69	25 B 25 A	103	16 K 16 J	137	12 E 12 D
				36	4 A Scholmmundo unter From Str. 4 B	70	25 A Schildenments unter Front Str. 25 B	104	16 J Life veet under your seet 16 K	138	12 D Schriftermouth unter From Str. 12 E
4	4	18	21	37	5 B 5 A	71	26 B 26 A	105	17 K 17 J	139	14 E 14 D
				38	5 A Life vest under your seet 5 B	72	26 A Life vest under your sest 26 B	106	17 J Schulesmoods Unter Brem Str. 17 K	140	14 D Life vest under your sest 14 E
5	5	19	22	39	9 B 9 A	73	27 B 27 A	107	18 K 18 J	141	15 E 15 D
	U			40	9 A Life veet under your seet 9 B	74	27 A Schrobernsons unter Brenn Str. 27 B	108	18 J Life vest under your sest 18 K	142	15 D Schwinswesia unter from Stz 15 E
,	0	20	00	41	10 B 10 A	75	28 B 28 A	109	19 K 19 J	143	16 E 16 D
6	8	20	23	42	10 A Schwingenson unter from Siz 10 B	76	28 A Life vest under your seet 28 B	110	19 J Scholmenwoods under Streen Stiz 19 K	144	16 D Life vest under your cost 16 E
				43	11 B 11 A	77	29 B 29 A	111	20 K 20 J	145	17 E 17 D
7	9	21	24	44	11 A Life vest under your sest 11 B	78	29 A Schubermeets unter Burn Sitz 29 B	112	20 J Lile vest under your seat 20 K	146	17 D Schulermoods unter brom Stz 17 E
				45	12 B 12 A	79	30 B 30 A	113	21 K 21 J	147	18 E 18 D
8	10	22	25	46	12 A Schulturmoodo unter freem Siz 12 B	80	30 A Life vest under your seat 30 B	114	21 J Schwinsenwede unter Brem Stz 21 K	148	18 D Life vest under your seat 18 E
			20	47	14 B 14 A	81	1K 1J	115	22 K 22 J	149	21 E 21 D
				48	14 A Lile vest under your sest 14 B	82	1 J Life vest under your seat 1 K	116	22 J Life vest under your seet 22 K	150	21 D Schulmmunds unter from Stz 21 E
9	111	23	26	49	15 B 15 A	83	2 K 2 J	117	23 K 23 J	151	22 E 22 D
				50 51	15 A Schwimmento unter trees 8tz 15 B	84	2 J Schulermeete trier liven Stz. 2 K	118	23 J Schminsmede unter Brem Stz 23 K	152	22 D Life veet under your seet 22 E
10	12	24	27	51	16 B 16 A	85	3 K 3 J	119	24 K 24 J	153	23 E 23 D
				52 53	16 A Lile veet under your seet 16 B	86	3 ULife veet under your seet 3 K	120	24 J Life veet under your seed 24 K	154	23 D Schwinsons was from the 23 E
11	14	25	20	54		87	4 K 4 J	121	25 K 25 J 25 K	155	24 E 24 D Life veet under your seet 24 E
11	14:	25	28	55		88	4 J Schulmmeete unter liven Bit. 4 K	122		156	
					18 B 18 A	89	5 K 5 J	123	26 K 26 J	157	25 E 25 D
12	15	26	29	5 6 5 7	18 A Life veet under your east 18 B	90	5 U Life vest under your seet 5 K	124	26 J Life vest under your seat 26 K	158	
				58	19 B 19 A Schwingmannin unter From State 19 B	91	9 K 9 J	125	27 K 27 J Scholmonous unter Bren Str. 27 K	159	26 E 26 D
13	16	27	30			92	9 J Lillo vest under your east 9 K	126		160	26 D Life veet under your seet 26 E
,,	Ш	٠,		59 40	20 B 20 A	93	10 K 10 J	127	28 K 28 J	161	27 E 27 D
				60 61	20 A Life vest under your sest 20 B	94	10 J Schulormoods unter Bram Siz 10 K	128	28 J Life veet under your seet 28 K	162	27 D Schulmmundo unter hvom Stz 27 E
14		28		61	21 B 21 A	95		129	29 K 29 J		
				62	21 A Statement was been Siz 21 B	96	11 J Life vest under your seet 11 K	130	29 J Backstonments unter from Str. 29 K		

Seat Identification and Seatrow Numbering -Placards/Markings (Sheet 1/2) Figure 004

EFFECTIVITY: 401-401, 404-500,

KSSU


R

11-32-25

Page 9- 10 Jun 01/15

Printed in France

AIRCRAFT MAINTENANCE MANUAL



Seat Identification and Seatrow Numbering - Placards/Markings (Sheet 2/2)
Figure 004

EFFECTIVITY: 401-401, 404-500,

196 26 F Life vest under your sest 26 G

11-32-25

Page 11- 12 Jun 01/15

AIRCRAFT MAINTENANCE MANUAL

EQUIPMENT COMPARTMENT, ZONES 171/172 AND 311/314

1. General


This subject provides information concerning placards and markings located equipment compartment, zones 171/172 and 311/314.

- A. Zone 171/172 (1)Cable Cover (Ref. Fig. 001)
- B. Zone 313/314
 (1)Tailcone (Ref. Fig. 002)

EFFECTIVITY: ALL

11-37-00

AIRCRAFT MAINTENANCE MANUAL




Cable Cover Figure 001

EFFECTIVITY: ALL

11.37.00

Page 2 Dec 01/89

AIRCRAFT MAINTENANCE MANUAL



Tailcone Figure 002

R EFFECTIVITY: ALL

11.37.00

Page 3 Dec 01/95