
p-n-Junction



- Diffusion of e⁻ from n-side and h⁺ from p-side
- Recombination on other side, free charges disappear around junction ("depletion")
- Neutral p- or n-Si becomes charged → E-Field
- External field can increase or decrease depletion zone
- Depletion is what we want for detectors!