A Basic Silicon Detector

- Take a p-n-diode
- Segment it
- Apply a voltage
- Wait for a MIP to deposit charge
- Charges separate and drift in E-field
- This gives a signal in the p-strips

n-type Si-bulk

