

DIGITIZING SONOBUOY RECORDINGS

Digitization Equipment:

Toshiba laptop Computer

* Raven Software for recording

Soundblaster Creative Extigy audio input

SONY DAT Recorder

DAT tapes

FILE NAMING STRUCTURE:

1625_SBDAT05_031102_1430.wav

1625 = Cruise Number

SBDAT05 = DAT Tape Name/Number

031102 = date (YYMMDD)

1430 = Time (military time 24 hrs)

*Remember to put an “_” (underscore)
between each of these components.

In Raven, the List File will look like this:

Cruise#_SBDATXX_<yy><ll><dd>_<hh><mm>.txt

Ex,

1625_SBDAT01_<yy><ll><dd>_<hh><mm>.txt

And the Sound Files will look like this:

CRUISEYr_SHIP_SBDATXX_<yy><ll><dd>_<hh><mm>.wav

Ex, 1625_SBDAT01_<yy><ll><dd>_<hh><mm>.wav

Digitization Instructions:

1. Create folder on external hard drive: <F: swfsc sonobuoys external>

Folder naming structure: (CRUISE#_SBDATxx)

2. Rewind DAT Tape to beginning
3. Excel File: Record DAT start date/time (from DAT)
4. Excel File: Record Tape Name
5. Excel File: Record HD Folder Name
6. Raven: Open Workspace: SONOBUOY DIGITIZATION

(This will select most of the appropriate selections, but double-check by:)

Open Recorder, set options:

Record to: File Sequence (save as?)

Device: Soundblaster Extigy

Sample Rate: 48000 Hz

Channels: both (left, right)

Sample Format: 16-bit signed PCM

File Format: wav

Sample Size: 16 bits

File Size: 10 minutes

Directory: choose the correct folder for that SBDAT tape!

Appropriate naming structure

Ex:(CRUISE#_SBDATxx_<yy><ll><dd>_<hh><mm>.wav)

Start Time: OTHER (choose appropriate start date/time for the tape)

7. Excel: Initial File Name
8. Start Recording
9. Confirm that recording is saving to file
10. Confirm that you hear something on the phones
11. Occasionally check recording to see that it is all ok.
12. At end of tape, stop the recording on the computer (immediately! So, need to time it!)
13. Check that all files are in folder, and that they all contain data
14. Excel: Enter in name of all digitized files
15. Go on to next recording!