BUOY PREPARATION

- 1. Day Before. Turn on SPOT transmitters, check (https://maps.findmespot.com/s/7PN0). Vacuum pump Spot cylinder (8-10psi).
- 2. Assemble High Flyer
- 3. Attach bridle from orange line to High Flyer (1 above/1below float) (zip tie)
- 4. Lay line on deck (no tangles!)
- Attach weight to line below recorder (zip tie)
- Turn on Recorder (see green light).
 - Point remote at clear end of Recorder, press START
 - RED will light, then GREEN will light, then GREEN will blink 1x/4sec (hard to see in direct sunlight).
 - After 2 min, will go into SLEEP MODE
 - Will flash briefly every 20 min (hard to see)



DEPLOYMENT

- 1. Prepare buoy for deployment (see other side)
- 2. Note Array ID (yellow tag at top of array)
- 3. Discuss plan with crew, check satellite reception online
- 4. Double-check buoy preparation, recorder is ON
- 5. Location Specs: >200m depth, far from shipping lanes
- 6. Slow vessel to 2-3knots, prepare to deploy OFF STERN
- 7. Prepare anchor (loop line for deploy- but will go in LAST!)
- 8. Lower High Flyer into water
- 9. Pay out line at vessel speed (no excess line)
- 10. Lower recorder into water (gentle! Do not toss!)
- 11. Lower anchor into water (do not toss!)
- 12. Mark time/Lat/Long and Array ID, send to Shannon

