### Arlo Camera

switch motion sound rssi battery

### **Arrival Sensor**

presence battery tone

### **Button**

numberOfButtons pushed held doubleTapped button temperature battery

#### **Contact Sensor**

contact temperature battery

#### Dimmer

switch level

# **Dome Motion Sensor**

motion temperature illuminance battery

## **DomeAeon Plug**

switch power voltage current energy acceleration

## **Garage Door**

door contact

### **Iris Smart Plug**

switch power voltage ACFrequency

#### **IrisV3 Motion Sensor**

motion temperature humidity battery

## **Iris Z-Wave Repeater**

status lastRefresh deviceMSR lastMsgRcvd

### **Keypad**

motion temperature battery tamper alarm

#### Lock

lock lockCodes codeChanged codeLength maxCodes battery

#### **Moisture Sensor**

water temperature battery

#### **Motion Sensor**

motion temperature battery

### **Multipurpose Sensor**

contact temperature battery acceleration threeAxis

### **Omnipurpose Sensor**

motion temperature humidity illuminance ultravioletIndex tamper battery

### **Pocket Socket**

switch power

### **Power Meter**

power

#### **Presence Sensor**

presence battery

### **Ring Doorbell**

numberOfButtons pushed motion

#### **RGB Bulb**

switch level hue saturation RGB color colorMode colorTemperature

#### **Shock Sensor**

shock battery

#### Siren

switch alarm battery

### **Smart Smoke/CO**

smoke carbonMonoxide battery temperature humidity switch level hue saturation pressure

#### **Smoke/CO Detector**

smoke carbonMonoxide battery

#### **Switch**

switch

#### **Thermostat**

coolingSetpoint heatingSetpoint schedule supportedThermostatFanModes supportedThermostatModes temperature thermostatFanMode thermostatMode thermostatOperatingState thermostatSetpoint

### Window Shade

switch position windowShade